

> 101.11:
- 6115-320-34

TM 5-6115-320-34

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

TECHNICAL MANUAL

**DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE MANUAL**

**GENERATOR SET, GAS TURBINE ENGINE: 45 KW,
AC, 120/208 240/416 V, 3 PHASE, 4 WIRE,**

**SKID MOUNTED: WINTERIZED
(AIRESEARCH MODEL GTGE 70-6-1)**

FSN 6115-075-1639

UNIVERSITY OF VIRGINIA LIBRARY



X004815943

This copy is a reprint which includes current pages from Changes 1.

UNIVERSITY OF VIRGINIA
ALDERMAN LIBRARY
JAN 11 1991
GOVERNMENT DOCUMENTS

HEADQUARTERS, DEPARTMENT OF THE ARMY

OCTOBER 1971

WARNING


**Be sure generator set is properly grounded before operation.
Serious injury or death may result
from electrical shock if set is not grounded.**

WARNING

**Turbine or compressor failures caused by foreign material
entering the generator set may cause injury to personnel
in the immediate area.
During engine start, do not stand or work
in stand clear areas.**

WARNING

**When the unit is operating, stand clear of exhaust stream.
Ear plugs should also be worn.**



CHANGE }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 29 September 1971

Direct Support and General Support Maintenance Manual
**GENERATOR SET, GAS TURBINE ENGINE: 45 KW, AC, 120/208, 240/416V, 3-PHASE, 4-WIRE,
SKID MOUNTED; WINTERIZED (AIRESEARCH MODEL GTGE 70-6-1) FSN 6115-075-1639**

TM 5-6115-320-34, 29 October 1971, is changed as follows:

Page 1-1, paragraph 1-5. At end of paragraph add the following note.

NOTE

Adjust paralleling and electrical frequency capabilities removed by MWO 5-6115-320-50/1.

Paragraph 1-6b(1) is superseded as follows:

(1) *Fuel Control unit.*

ManufacturerAiresearch Manufacturing Co.

Fuel inlet pressure at 100 percent rpm ...15.0 to 16.0 psig.


Paragraph 1-6b(2) is rescinded.

Page 1-2. Paragraph 1-6b(13), line 3, is changed to read "Fuel discharge pressure, 400 ± 50 psig".

Page 2-12, table 2-2, Troubleshooting. Steps and 23 are superseded as follows:

<i>Malfunction</i>	<i>Probable cause</i>	<i>Corrective action</i>
22. Voltage droop cannot be adjusted.	a. Voltage droop potentiometer defective.	a. Replace voltage droop potentiometer.
	b. Current transformer (CT4) defective.	b. Perform test procedure (para 4-4). If malfunction is indicated replace current transformer CT4 (fig. 4-4)
23. Not used after application of MWO 5-6115-320-50/1.		

Page 3-2. Figure 3-1 is superseded as follows:



ME 6115-320-34/3-1 C1

Figure 3-1. Engine wiring harness identification.
(ME 6115-320-34/3-1, C1)

Page 3-7. Paragraph 3-5b is superseded as follows :

b. Remove fuel control unit as shown on figure 3-5(1).

Paragraph 3-5e is added as follows :

e. *Adjustment.* The fuel scheduling and governor pump assembly may be adjusted for engine governed speed and acceleration as follows :

(1) *Engine governed speed adjustment.* The governed speed of turbine engine is adjusted by rotating the governor adjustment screw (fig. 3-5(2)). If a new governor is installed, fuel control exchanged, or the governor setting has been disturbed for any reason, adjust the engine governor speed as follows :

(a) Control the engine speed at 41,000 rpm (4,203 analyzer tachometer indication) by adjusting the by-pass valve on the engine analyzer (fig. 2-3). If the governor is set at an rpm less than 41,000 adjust the by-pass valve to control speed slightly below the governor setting.

(b) Remove lockwire and loosen nut on governor adjustment screw (fig. 3-5(2)).

(c) Rotate governor adjustment screw clockwise to increase rpm and counterclockwise to decrease rpm as required to set governed speed to 41,000 rpm. (4,203 analyzed tachometer indication) or 402 ± 1 HZ generator frequency as observed on analyzer frequency meter (fig. 2-3). If governor setting is below 41,000 rpm, make adjustment in small increments (one eighth turn or less) and control the rpm increase with the analyzer by-pass valve (fig. 2-3) until governed speed of 41,000 rpm is attained.

(d) Tighten locknut and install lockwire to secure adjustment position. Close the by-pass valve and disconnect engine analyzer air by-pass hoses from the engine and connect engine control air lines for normal operation. Verify that engine governed speed is between 40,902 and 41,106 rpm (4,192 to 4,213 analyzer tachometer indication) or 402 ± 1 hertz generator frequency as observed on analyzer frequency meter.

(2) *Engine acceleration time adjustment.* Acceleration time of the engine should be between 20 seconds and 30 seconds maximum and is adjusted by rotating the acceleration adjustment screw (fig. 3-5(2)). The engine analyzer should be used during adjustment to check that exhaust gas temperatures do not exceed 635°C . If acceleration is slow (more than 30 seconds to 95 percent of governed speed) and exhaust gas temperature is below 635°C , adjust as follows :


(a) Remove lockwire and loosen nut on acceleration adjustment screw (fig. 3-5(2)).

(b) Rotate acceleration adjustment screw clockwise in small increments (one eighth turn or less) and start engine. Check acceleration time and exhaust gas temperature. Continue adjustments until acceleration time is 30 seconds or less and exhaust gas temperature does not exceed 635°C .


(c) In the event that acceleration time is less than 20 seconds, follow procedure outlined in (1) above, except rotate the acceleration adjustment screw counterclockwise.

(d) Tighten locknut and install lockwire to secure adjustment position.

Figure 3-5 is superseded as follows :



*Figure 3-5. Fuel control removal and installation (sheet 1 of 2).
(ME 6115-320-34/3-5(1), C1*



ME 6115-320-34/3-5 (2) C1

*Figure 3-5. Fuel control accelerator and governor adjustment (sheet 2 of 2).
ME 6115-320-34/3-5(2), C1*

Page 4-5. Paragraph 4-3a(2) is superseded as follows:

(2) The load anticipator is not used after application of MWO 5-6115-320-50/1.

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

BRUCE PALMER, JR.
General, U. S. Army
Acting Chief of Staff

Distribution:

To be distributed in accordance with DA Form 12-25D, (qty rqr block no. 739) Direct and General Support maintenance requirements for Generator Sets, Engine Driven 45 KW. 60 HZ.

- Inverter
- MFD 75 W VDC
- 8 MHY 2.5 AMPS.
- Pump
- Noise Suppression) 0.1 MFD 500 VAC-DC
- Noise Suppression) 0.1 MFD 500 VAC-DC
- Noise Suppression) 0.1 MFD 500 VAC-DC
- Noise Suppression) 0.1 MFD 500 VAC-DC
- Breaker
- Water CB Circuit Breaker
- Breaker
- Breaker (Sergeant Special)
- Meter (Instrumentation)
- Meter (Instrumentation)
- Meter (Instrumentation)
- Meter (Voltage Droop)
- Lamp
- Water Lamp
- Ground Stud
- Receptacle Fuse
- General J14 Receptacle
- Receptacle J15
- J18 Receptacle
- 15 Amp Convenience Receptacle
- Special J25 Receptacle (Sergeant)
- 15 Amp J27 Receptacle (Sergeant)
- J28 Receptacle (Sergeant)
- Receptacle
- Relay
- Control Relay
- Relay
- Relay AC
- Relay
- Circuit Relay
- Pressure Sensing Relay
- Temperature Sensing Relay
- Motor

- M2 Exhaust Gas Temperature Gage
- M3 Oil Pressure Gage
- M4 Battery Charging Ammeter
- M5 Start Counter
- M6 Engine Hourmeter
- M7 AC Voltmeter
- M8 Frequency Meter
- M9 AC Ammeter
- M10 Kilowatt Meter
- M1 Frequency Transducer
- P1 Control Plug
- P2 Gas Turbine Plug
- P3 Control Plug
- P7 AC Generator Plug
- P8 Battery Heater Plug
- * P9 Load Anticipator Plug
- * P10 Load Anticipator Plug
- P11 Voltage Regulator Plug
- P12 Battery Charger Plug
- P13 Main Circuit Breaker Plug
- P14 Internally Wired Plug
- P17 Battery Electrolyte Temperature Sensor Plug
- P20 Fuel Boost Pump Plug
- P21 Battery Heater Fuel Pump Plug
- P24 Tachometer Indicator Plug
- P25 Internally Wired Plug (Sergeant)
- R1 Voltage Adj Rheostat 350 Ohms 12.5 Watt
- * R2 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
- * R3 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
- * R4 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
- * R5 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
- * R6 Frequency Droop Rheostat 3500 Ohms 12.5 Watt
- R7 Voltage Droop Rheostat 25 Ohms 25 Watt
- * R8 Frequency Adj Potentiometer 3500 Ohms 3 Watt
- R9 Resistor 1000 Ohms 1 Watt
- R10 Resistor 1000 Ohms 1 Watt
- R11 Resistor 1000 Ohms 1 Watt
- R12 Resistor 15 Ohms 10 Watt
- S1 Panel Lights Switch
- S2 Master Switch
- S3 Local Remote Control Selector Switch
- S4 Over Volt Reset Switch
- S5 Main CB Circuit Breaker Switch
- S6 Protection Bypass Switch
- S8 Winterization Heater Switch
- S10 Battery Electrolyte Temperature Sensor
- S11 Volt-Amp Selector Switch
- * S12 Unit-Parallel Selector Switch
- S13 Local Remote Sensing Voltage Selector Switch
- TB1 Terminal Board
- TB2 Terminal Board
- TB3 Terminal Board
- TB4 Terminal Board
- TB5 Voltage Change Panel
- TB7 AC Power Output Terminal Board
- TB8 Terminal Board
- TB9 Terminal Board
- TC1 Fire Detector
- TC2 Fire Detector
- TC3 Fire Detector
- TC4 Fire Detector
- VR1 Voltage Regulator

* NOTE : PARALLELING AND ELECTRICAL FREQUENCY ADJUSTMENT CAPABILITIES REMOVED BY MWO 5-6115-320-50/1

ME 6115-320-34/FO-1 ① C1

FO-2(2), FO-2(4), FO-2(5), and FO-2(6) are superseded as follows:

AM Converter	M2 Exhaust Gas Temperature Gage
Motor	M3 Oil Pressure Gage
Generator	M4 Battery Charging Ammeter
Motor	M5 Start Counter
Motor	M6 Engine Hourmeter
40 MFD 75 W VDC	M7 AC Voltmeter
100 8 MHY 2.5 AMPS.	M8 Frequency Meter
Motor	M9 AC Ammeter
Boost Pump	M10 Kilowatt Meter
Pump	M11 Frequency Transducer
	P1 Control Plug
	P2 Gas Turbine Plug
	P3 Control Plug
(Radio Noise Suppression) 0.1 MFD 500 VAC-DC	P7 AC Generator Plug
(Radio Noise Suppression) 0.1 MFD 500 VAC-DC	P8 Battery Heater Plug
(Radio Noise Suppression) 0.1 MFD 500 VAC-DC	* P9 Load Anticipator Plug
(Radio Noise Suppression) 0.1 MFD 500 VAC-DC	* P10 Load Anticipator Plug
Circuit Breaker	P11 Voltage Regulator Plug
On Heater CB Circuit Breaker	P12 Battery Charger Plug
Circuit Breaker	P13 Main Circuit Breaker Plug
Circuit Breaker (Sergeant Special)	P14 Internally Wired Plug
Transformer (Instrumentation)	P17 Battery Electrolyte Temperature Sensor Plug
Transformer (Instrumentation)	P20 Fuel Boost Pump Plug
Transformer (Instrumentation)	P21 Battery Heater Fuel Pump Plug
Transformer (Voltage Droop)	P24 Tachometer Indicator Plug
Lamp	P25 Internally Wired Plug (Sergeant)
Lamp	R1 Voltage Adj Rheostat 350 Ohms 12.5 Watt
Lamp	* R2 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
Pressure Lamp	* R3 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
On Heater Lamp	* R4 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
Lamp	* R5 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
Lamp	* R6 Frequency Droop Rheostat 3500 Ohms 12.5 Watt
Lamp	R7 Voltage Droop Rheostat 25 Ohms 25 Watt
Terminal Ground Stud	* R8 Frequency Adj Potentiometer 3500 Ohms 3 Watt
Ground Stud	R9 Resistor 1000 Ohms 1 Watt
Receptacle Fuse	R10 Resistor 1000 Ohms 1 Watt
Receptacle	R11 Resistor 1000 Ohms 1 Watt
Receptacle	R12 Resistor 15 Ohms 10 Watt
General J14 Receptacle	S1 Panel Lights Switch
Receptacle J15	S2 Master Switch
Power J18 Receptacle	S3 Local Remote Control Selector Switch
Cycle-15 Amp Convenience Receptacle	S4 Over Volt Reset Switch
Special J25 Receptacle (Sergeant)	S5 Main CB Circuit Breaker Switch
Fuel Pump J27 Receptacle (Sergeant)	S6 Protection Bypass Switch
Power J28 Receptacle (Sergeant)	S8 Winterization Heater Switch
Receptacle	S10 Battery Electrolyte Temperature Sensor
Receptacle	S11 Volt-Amp Selector Switch
Receptacle	* S12 Unit-Parallel Selector Switch
Receptacle	S13 Local Remote Sensing Voltage Selector Switch
Receptacle	TB1 Terminal Board
Receptacle	TB2 Terminal Board
Receptacle	TB3 Terminal Board
Receptacle	TB4 Terminal Board
Receptacle	TB5 Voltage Change Panel
Receptacle	TB7 AC Power Output Terminal Board
Receptacle	TB8 Terminal Board
Receptacle	TB9 Terminal Board
Receptacle	TC1 Fire Detector
Receptacle	TC2 Fire Detector
Receptacle	TC3 Fire Detector
Receptacle	TC4 Fire Detector
Receptacle	VR1 Voltage Regulator

RELLELING AND ELECTRICAL FREQUENCY ADJUSTMENT
CAPACITIES REMOVED BY MWO 5-6115-320-50/1

ME 6115-320-34/FO-2 ① C1

Converter
star Governor Control
rectifier
"

10 MFD 75 W VDC
10 8 MHY 2.5 AMPS

Pump

Pump

Radio Noise Suppression) 0.1 MFD 500 VAC-DC
Radio Noise Suppression) 0.1 MFD 500 VAC-DC
Radio Noise Suppression) 0.1 MFD 500 VAC-DC
Radio Noise Suppression) 0.1 MFD 500 VAC-DC

Circuit Breaker

Heater CB Circuit Breaker
Circuit Breaker

Circuit Breaker (Sergeant Special)

Transformer (Instrumentation)

Transformer (Instrumentation)

Transformer (Instrumentation)

Transformer (Voltage Droop)

Transformer

Transformer

Transformer

Transformer

Transformer Lamp

Transformer Lamp

Transformer

Transformer

Transformer Ground Stud

Transformer Stud

Transformer Receptacle Fuse

Transformer

Transformer

Transformer

Transformer General J14 Receptacle

Transformer Receptacle J15

Transformer J18 Receptacle

Transformer 15 Amp Convenience Receptacle

Transformer Special J25 Receptacle (Sergeant)

Transformer Pump J27 Receptacle (Sergeant)

Transformer J28 Receptacle (Sergeant)

Transformer Receptacle

Transformer No. 1

Transformer No. 2

Transformer Mold Relay

Transformer Relay

Transformer Loss Relay

Transformer Control Relay

Transformer Relay AC

Transformer Relay AC

Transformer Control Relay

Transformer Relay

Transformer Short Circuit) Relay

Transformer Nature Sensing Relay


Transformer Voltage Sensing Relay

Transformer Indicator

WIRING DIAGRAM USED ON UNITS
NUMBER P21468 AND SUBSEQUENT.

- M2 Exhaust Gas Temperature Gage
- M3 Oil Pressure Gage
- M4 Battery Charging Ammeter
- M5 Start Counter
- M6 Engine Hourmeter
- M7 AC Voltmeter
- M8 Frequency Meter
- M9 AC Ammeter
- M10 Kilowatt Meter
- MT Frequency Transducer
- P1 Control Plug
- P2 Gas Turbine Plug
- P3 Control Plug
- P7 AC Generator Plug
- P8 Battery Heater Plug
- P9 Load Anticipator Plug
- P10 Load Anticipator Plug
- P11 Voltage Regulator Plug
- P12 Transformer Rectifier Plug
- P13 Main Circuit Breaker Plug
- P14 Internally Wired Plug
- P17 Battery Electrolyte Temperature Sensor Plug
- P20 Fuel Boost Pump Plug
- P21 Battery Heater Fuel Pump Plug
- P24 Tachometer Indicator Plug
- P45 Internally Wired Plug (Fuel Tank Base Receptacle)
- P25 Internally Wired Plug (Sergeant)
- R1 Voltage Adj Rheostat 350 Ohms 12.5 Watt
- R2 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
- R3 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
- R4 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
- R5 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
- R6 Reactive Frequency Droop Rheostat 3500 Ohms 12.5 Watt
- R7 Voltage Droop Rheostat 25 Ohms 25 Watt
- R8 Frequency Adj Potentiometer 3500 Ohms 3 Watt
- R9 Resistor 1000 Ohms 1 Watt
- R10 Resistor 1000 Ohms 1 Watt
- R11 Resistor 1000 Ohms 1 Watt
- R12 Resistor 15 Ohms 10 Watt
- S1 Panel Lights Switch
- S2 Master Switch
- S3 Local Remote Control Selector Switch
- S4 Over Volt Reset Switch
- S5 Main CB Circuit Breaker Switch
- S6 Protection Bypass Switch
- S8 Winterization Heater Switch
- S10 Battery Electrolyte Temperature Sensor
- S11 Volt Amp Selector Switch
- S12 Unit-Parallel Selector Switch
- S13 Local Remote Sensing Voltage Selector Switch
- TB1 Terminal Board
- TB2 Terminal Board
- TB3 Terminal Board
- TB4 Terminal Board
- TB5 Voltage Change Panel
- TB8 Terminal Board
- TB9 Terminal Board
- TC1 Fire Detector
- TC2 Fire Detector
- TC3 Fire Detector
- TC4 Fire Detector
- VR1 Voltage Regulator

ME 6115-320-34/FO-2 (2) C1



MATE WITH J1 CUBICLE RECEPTACLE ON FIGURE 3 1

MATE WITH J3 CUBICLE RECEPTACLE ON FIGURE 3 1

THIS WIRING DIAGRAM USED ON UNITS SERIAL NUMBER P21448 AND SUBSEQUENT.

ME 6115-320-34/FO-2 (4) CI

VOLTAGE	OHMS	REMARKS				
		CIRCUIT BREAKER		GENERATOR	SWITCH	
		REF DES	POSITION	SET	REF DES	POSITION
0	0	CB-3	CLOSED		S2	OFF
0	INFINITY	CB-3	CLOSED		S12	UNIT
0	0	CB-3	CLOSED		S2	OFF
0	INFINITY	CB-3	CLOSED		S12	UNIT
0	1330	CB-3	CLOSED		S2	OFF
0	1220	CB-3	CLOSED		S2	OFF
0		CB-3	CLOSED		S12	UNIT
0	INFINITY	CB-3	CLOSED		S2	OFF
0	38	CB-3	CLOSED		S2	OFF
0	3.1	CB-3	CLOSED		S12	UNIT
0	3.1	CB-3	CLOSED		S2	OFF
0	9.1	CB-3	CLOSED		S12	UNIT
0	INFINITY	CB-3	CLOSED		S2	OFF
0	INFINITY	CB-3	CLOSED		S12	UNIT
0	0	CB-3	CLOSED		S2	OFF
0	INFINITY	CB-3	CLOSED		S12	UNIT
0	2.7K	CB-3	CLOSED		S2	OFF
0	INFINITY	CB-3	CLOSED		S12	UNIT
0	INFINITY	CB-3	CLOSED		S2	OFF
0	2600	CB-3	OPEN		S2	OFF
0	2600	CB-3	OPEN		* S12	PARALLEL
0	INFINITY	CB-3	OPEN		S2	OFF
0	2600	CB-3	OPEN		* S12	PARALLEL
0	2600	CB-3	OPEN		S2	OFF
0	2600	CB-3	OPEN		* S12	PARALLEL
0	INFINITY	CB-3	OPEN		S2	OFF
0	2600	CB-3	OPEN		* S12	PARALLEL
0	2600	CB-3	OPEN		S2	OFF
0	2600	CB-3	OPEN		* S12	PARALLEL

B. AC GENERATOR (G1)

0 0.0220 TO 0.0244
0 0.0220 TO 0.0244
0 0.0220 TO 0.0244
0 0.0220 TO 0.0244
0 0.0220 TO 0.0244


* SEE NOTE FIGURE FO-2 ①

ME 6115-320-34/FO-2 ⑤ C1

O A O	VOLTAGE	OHMS	REMARKS			
			CIRCUIT BREAKER		GENERATOR	SWITCH
			REF DES	POSITION	SET	REF DES POSITION
J1	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
J1	0	INFINITY				
	0	0				
IER	0	INFINITY				
IER	0	INFINITY				
IER	0	INFINITY				
IER	0	INFINITY				
IER	0	INFINITY				
	0	INFINITY				
	0	220				
A	0	INFINITY				
	0	260				
	0	220				
	0	40				
	0	INFINITY				
	0	70				
	0	70				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	70				
	0	INFINITY				
	0	200				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	37				
	0	INFINITY				
	0	INFINITY				
	0	200				
A	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	130				
	0	INFINITY				
	0	INFINITY				
	0	130				
	0	INFINITY				
IER	0	INFINITY				
IER	0	INFINITY				
IER	0	INFINITY				
IER	0	INFINITY				
I. CONTROL CUBICLE PLUGS						
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	INFINITY				
	0	2.1K				
	0	INFINITY				
	0	INFINITY				
	0	0				
			* WITH ALL CIRCUIT BREAKERS CLOSED AND ALL SWITCHES IN OFF OR NEUTRAL POSITION, "UNIT-PARALLEL" SWITCH IN "PARALLEL" POSITION, VOLT-AMP SELECTOR IN POSITION "C-A", BOTH P1 AND P3 REMOVED			
			* SEE NOTE FIGURE FO-2 ①			
			ME 6115-320-34/FO-2 ⑥ C1			

10
4

Page FO-3, figure FO-3 is superseded as follows :



ME 6115-320-34/FO-3 C1

Figure FO-3. Fuel and air flow diagram, turbine engine.
ME 6115-320-34/FO-3, C1

**DIRECT SUPPORT AND GENERAL SUPPORT
 MAINTENANCE MANUAL
 GENERATOR SET, GAS TURBINE ENGINE: 45 KW,
 AC, 120 / 208 240 / 416 V, 3 PHASE, 4 WIRE,
 SKID MOUNTED: WINTERIZED
 (AIRESEARCH MODEL GTGE 70-6-1)
 FSN 6115-075-1639**

		Paragraph	Page
CHAPTER Section	1. INTRODUCTION		
	I. General	1-1—1-3	1-1
	II. Description and data	1-4—1-6	1-1
CHAPTER Section	2. DIRECT SUPPORT GENERAL SUPPORT MAINTENANCE INSTRUCTIONS		
	I. Repair parts, special tools and equipment	2-1—2-3	2-1
	II. Troubleshooting	2-4, 2-5	2-7
	III. General maintenance	2-6, 2-7	2-12
	IV. Removal and installation of major components	2-8—2-10	2-13
CHAPTER Section	3. REPAIR OF GAS TURBINE ENGINE		
	I. Repair of engine electrical system	3-1—3-4	3-1
	II. Repair of fuel system	3-5—3-7	3-6
	III. Repair of lubricating system	3-8—3-10	3-10
	IV. Repair of combustion assembly	3-11, 3-12	3-20
	V. Repair of exhaust system	3-13 3-14	3-20
	VI. Repair of turbine assembly	3-15	3-21
	VII. Repair of compressor assembly	3-16	3-24
	VIII. Repair of accessory drive	3-17	3-26
	IX. Repair of safety controls	3-18—3-26	3-30
CHAPTER Section	4. REPAIR OF ELECTRICAL SYSTEM		
	I. Repair of electric generator	4-1	4-1
	II. Repair of electrical system components	4-2—4-7	4-4
	III. Repair of generator set wiring harness	4-8—4-9	4-12
CHAPTER Section	5. REPAIR OF WINTERIZATION EQUIPMENT		
	I. Repair of battery heater	5-1, 5-3	5-1
	II. Repair of enclosure assembly	5-4—5-7	5-4
APPENDIX	A. REFERENCES		A-1
INDEX			I-1

* This manual supersedes TM 5-6115-320-34, 20 August 1965, including all changes.

LIST OF ILLUSTRATIONS

<i>Number</i>	<i>Title</i>	<i>Page</i>
1-1	Oil flow diagram, turbine engine	1-3
2-1	Special tools and equipment (sheet 1 of 3)	2-2
2-1	Special tools and equipment (sheet 2 of 3)	2-3
2-1	Special tools and equipment (sheet 3 of 3)	2-4
2-2	Connecting gas turbine engine analyzer to generator set	2-5
2-3	Gas turbine engine analyzer controls and instruments panel	2-6
2-4	Engine and AC generator assembly removal and installation (sheet 1 of 2)	2-14
2-4	Engine and AC generator assembly removal and installation (sheet 2 of 2)	2-15
2-5	AC generator assembly removal and installation	2-16
3-1	Engine wiring harness identification	3-2
3-2	Engine wiring harness wire identification chart	3-3
3-3	Starter motor assembly, disassembly and reassembly	3-5
3-4	Turbine holding relays (K3 and K4) removal and installation	3-6
3-5	Fuel control unit removal and installation	3-7
3-6	Fuel boost pump, exploded view	3-9
3-7	Oil pump assembly removal and installation	3-11
3-8	Oil pump assembly, exploded view	3-12
3-9	Oil tank assembly, exploded view	3-13
3-10	Oil spray jet and breather tubes removal and installation	3-14
3-11	Oil spray jet and breather tubes, exploded view	3-15
3-12	Combustion system air flow	3-16
3-13	Combustion chamber assembly, exploded view	3-17
3-14	Turbine plenum removal and installation	3-18
3-15	Turbine plenum, exploded view	3-19
3-16	Turbine plenum alinement	3-20
3-17	Muffler assembly, exploded view	3-21
3-18	Turbine assembly, removal, disassembly, reassembly and installation	3-23
3-19	Nozzle and shroud assembly inspection	3-24
3-20	Compressor inlet plenum removal and installation	3-25
3-21	Compressor inlet plenum, exploded view	3-26
3-22	Accessory drive assembly, removal and installation	3-28
3-23	Accessory drive assembly, exploded view	3-29
3-24	Output shaft seal and bearing shim measurements	3-30
3-25	Centrifugal switch assembly, removal and installation	3-32
3-26	Centrifugal switch assembly, wiring diagram	3-33
3-27	Conversion of tachometer indication to turbine RPM	3-34
3-28	Centrifugal switch assembly adjusting screws	3-35
3-29	Centrifugal switch assembly, exploded view	3-36
3-30	(This figure is not used)	3-36
3-31	(This figure is not used)	3-36
3-32	Thermostatic switch removal and installation	3-38
3-33	Acceleration and overtemperature control thermostat removal and installation	3-39
3-34	Tachometer-generator removal and installation	3-40
3-35	Fire detectors removal and installation	3-41
3-36	Control panel assembly removal and installation	3-42
3-37	Frequency meter and transducer, wattmeter and thermal watt converter, voltage adjusting rheostat, voltage and frequency droop potentiometer, relays (K2 through K13, K15, and K16) and electrical equipment rack receptacles removal and installation	3-44
4-1	AC generator disassembly and reassembly	4-3
4-2	AC generator testing, schematic wiring diagram	4-4
4-3	Voltage regulator assembly, load anticipator, and terminal boards (TB4, TB7, and TB8) removal and installation	4-6
4-4	Current transformers, removal and installation	4-7
4-5	Battery charger and 24 VDC slave receptacle, removal and installation	4-9
4-6	Overcurrent relay (K14) and main circuit breaker (CB3), removal and installation	4-11
4-7	Voltage change panel assembly, removal and installation	4-12
4-8	Cubicle AC wiring harness	4-24
4-9	Cubicle DC wiring harness	4-29
5-1	Battery heater assembly, disassembly and reassembly	5-2
5-2	Battery heater ducting removal and installation	5-3
5-3	Power outlet receptacles (J18 and J26), removal and installation	5-4
5-4	Enclosure assembly components, removal and installation	5-5
5-5	Base plan for launching station installations	5-6
FO-1	Generator set schematic wiring diagram (sheet 1 of 2)	FO-1
FO-1	Generator set schematic wiring diagram (sheet 2 of 2)	FO-1

<i>Number</i>	<i>Title</i>	<i>Page</i>
FO-2	Generator set practical wiring diagram (sheet 1 of 7)	FO-2
FO-2	Generator set practical wiring diagram (sheet 2 of 7)	FO-2
FO-2	Generator set practical wiring diagram (sheet 3 of 7)	FO-2
FO-2	Generator set practical wiring diagram (sheet 4 of 7)	FO-2
FO-2	Generator set practical wiring diagram (sheet 5 of 7)	FO-2
FO-2	Generator set practical wiring diagram (sheet 6 of 7)	FO-2
FO-2	Generator set practical wiring diagram (sheet 7 of 7)	FO-2
FO-3	Fuel and air flow diagram, turbine engine	FO-3
FO-4	Engine wiring harness assembly and schematic diagram	FO-4
FO-5	Generator set wiring harness	FO-5

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

This manual contains instructions for the use of direct support and general support maintenance personnel maintaining of the generator set (Airesearch Model GTGE70-6-1) as allocated by the Maintenance Allocation Chart. It provides information on equipment maintenance which is beyond the scope of the tools, equipment, personnel or supplies normally available at organizational maintenance.

1-2. Forms and Records

Maintenance forms, records and reports which are

to be used by maintenance personnel at all maintenance levels are listed in, and prescribed by TM 38-750.

1-3. Reporting of Errors

Report of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028, Recommended Changes to Publications, and forwarded direct to Commanding General, U. S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Boulevard, St. Louis, Mo. 63120.

Section II. DESCRIPTION AND DATA

1-4. Description

A general description of the generator set is contained in TM 5-6115-320-12. A more detailed description of specific components and assemblies is contained in the applicable sections of this manual. Detailed description of components of the generator set are provided in the applicable maintenance paragraph of this manual.

1-5. Difference Between Models

This manual covers only Model GTGE70-6-1 generator set. A difference exists in the wiring covering serial numbers P21468 and up. See figure FO-2 (Located in back of manual) sheets 2 of 7 and 4 of 7.

1-6. Tabulated Data

a. Identification. The major identification plates of the generator set are located and described in TM 5-6115-320-12.

b. Tabulated Data. Tabulated data pertaining to direct and general support maintenance follows:

(1) Fuel control unit.

Manufacturer	Airesearch Manufacturing Company
Fuel inlet pressure	15.0 to 16.0 psi (pounds per square inch) (at 100 percent rpm (revolutions per minute))
Acceleration limiter	38 to 39 psi at 15 ± 1 psi cracking pressure

(2) Governor trim motor.

Manufacturer	Airesearch Manufacturing Company
--------------	----------------------------------

Operating voltage	5 VDC
Operating current	156 milliampere
Coil resistance	50 ohms/coil

(3) Oil pressure sequencing switch.

Manufacturer	Airesearch Manufacturing Company
Current capacity	4 amps at 30 VDC
Actuation	3.0 ± 0.5 psi
Reset	1.5 psi

(4) Low oil pressure switch.

Manufacturer	Airesearch Manufacturing Company
Actuation	65 ± 3 psi
Reset	55 ± 3 psi
Current capacity	4 amps at 14 to 29 VDC

(5) Oil temperature thermostatic switch.

Manufacturer	Fenwall Inc., Ashland, Massachusetts
Actuation	250° F (121° C) (Refer to tag on switch for tolerance).
Current capacity	1 amp at 32 VDC or 115 VAC

(6) Exhaust gas temperature thermostatic switch.

Manufacturer	Airesearch Manufacturing Company
Actuate (increasing)	$113.5^{\circ} \pm 2.5^{\circ}$ F ($62.5^{\circ} \pm 1.4^{\circ}$ C)
Current capacity	10 amps at 28 VDC and 500° F (260° C)

(7) Acceleration and overtemperature control thermostat.

Manufacturer	Airesearch Manufacturing Company
--------------	----------------------------------

(7) *Acceleration and overtemperature control thermostat—Continued*

Actuation temperature .. 1225° F + 10° F / 5° F
(663° C + 12.2° C /
6.1° C)

Normal position Closed

(8) *Exhaust gas temperature thermocouple.*

Manufacturer Airesearch Manufacturing
Company

Type Alumel chromel

Temperature range 400° F to 1400° F (204°C to
760° C)

(9) *Centrifugal switch assembly.*

Manufacturer Airesearch Manufacturing
Company

Centrifugal switch action:

Switch Switch Shaft RPM

Starter cutout 3,585 ± 50

Ready to load 9,542 ± 42 (increasing)
9,208 ± 122 RPM
(decreasing)

Overspeed 10,900 ± 20 RPM

(10) *Generator set relays.*

Close Open

Start (K1) 18 VDC .. 7+0 / -5.5 VDC

Master (K2) 18 VDC .. +0 / -5.5 DC typ

No. 1 holding (K3) 18 VDC .. +0 / -5.5 DC typ

No. 2 holding (K4) 18 VDC .. +0 / -5.5 DC typ

Overvoltage hold

(K5) 18 VDC .. 13 VDC

AC reset (K6) 18 VDC .. 13 VDC

AC voltage (K7) 90 VAC .. 30+0 / -25 VAC

Protection by-pass

(K8) 18 VDC .. 7±5 VDC

Temperature control

(K9) 18 VDC .. 13 VDC

Overvoltage (K10) 160 VAC .. 152 VAC

Undervoltage (K11) 105 ± 5 VAC .. 60 ± 84 VAC

Generator control

(K12) 18 VDC .. 7+0 / -5.5 DC

Fire sensing

(K13) 18 VDC .. 13 VDC

Overcurrent (K14) 375 ± 37.5a .. 50-2000

Battery temperature

sensor (K15) 2.8 ma .. 1.0 ma

Local-remote

voltage sensing

(K16) 18 VDC .. 7 ± 5 VDC

Main circuit

breaker (CB3)

(mechanically locked) 15 VDC .. 15 VDC

(11) *Tachometer generator.*

Specification MS28054-1

Pole type 2

(12) *Repair and replacement standards.* Table 1-1 lists manufacturers dimensions on tolerances in inches with required shimming instructions.

(13) *Adjustment data.*

Fuel control unit:

Input shaft

speed 0 to 5000 rpm

Fuel inlet

pressure 15.0 psi

Fuel discharge

pressure 0 to 430 psi

Low oil pressure

switch:

Actuate 65 ± 3 psi

Reset 55 ± 3 psi

Starter clutch:

Slip torque 130 to 145 inch-pounds

Oil pressure switch:

Actuate 3 ± 1 psi

Reset 1.5 ± 0.5 psi

Centrifugal switch assembly (actuation):


Switch Switch shaft rpm

Starter cutout 3,585 ± 50 rpm

Ready to load 9,542 ± 42 rpm (increasing)
9,208 ± 122 rpm (decreasing)

Overspeed shutdown 10,900 ± 20 rpm

(14) *Diagrams.* The wiring diagrams (FO-1 and FO-2) (Located in back of manual) show electrical connections for major components of the generator set. The fuel and air flow diagram (FO-3) and oil and gas flow diagram (fig. 1-1) show the fluid flow system of the turbine engine.



ME 6115-320-34/1-1

Figure 1-1. Oil flow diagram, turbine engine.

Table 1-1. Repair and replacement standards

Component	Manufacturers dimensions and tolerances in inches	
	Minimum	Maximum
Combustion assembly:		
Combustion chamber flange in turbine torus to plenum assembly (to be shimmed toward turbine) (shim with outer plenum gaskets)	0.00	0.006
Turbine exhaust flange to plenum flange (shim with turbine exhaust flange gaskets to obtain compression preload on plenum flange)	0.00	0.08
Accessory assembly:		
Output shaft bearing to seal retainer (shim for pinch)	0.000	0.003
Output shaft seal rotor to seal carbon face (shim for depression)	0.030	0.035

Table 1-2. Nut and bolt torque data.

Component	Torque (in-lb)
Engine:	
Compressor:	
Oil fitting bolts	20 to 25 in. lb
Turbine:	
Turbine plenum nuts (at turbine exhaust flange)	40 to 60 in. lb
Shroud bolts	45 to 50 in. lb.
Accessory Drive:	
Attaching bolts	50 to 70 in. lb.
Output shaft	145 to 155 in. lb.
Rotating fan lower nut	150 to 175 in. lb.
Rotating fan locknut	150 to 175 in. lb.
Generator:	
End shield attaching screws	25 to 30 in. lb.

CHAPTER 2

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS

Section I. REPAIR PARTS, SPECIAL TOOLS, AND EQUIPMENT

2-1. Tools and Equipment

Tools, equipment, and repair parts issued with or authorized for the generator set are listed in TM 5-6115-320-12.

2-2. Special Tools and Equipment

Special tools and equipment required to perform direct and general support maintenance of the generator set are listed in table 2-1, and illustrated in figure 2-1.

a. Gas Turbine Engine Analyzer. The Gas Turbine Engine Analyzer may be used for troubleshooting the generator set. The Gas Turbine Engine Analyzer is a portable unit that incorporates electrical, hydraulic, and pneumatic test systems and their associated controls and indicators. A portable multimeter and a portable fuel pressure gage are provided for use in performing troubleshooting checks at various components on the generator set. The Special Purpose Electrical Branched Cable Assembly and Analyzer Hose Kit are used to connect the test systems of the Analyzer to the generator set.

(1) The Special Purpose Electrical Branched Cable Assembly is used to electrically connect the analyzer to the generator set. A static test switch is provided with the Cable Assembly to permit individual component checks when the Analyzer is connected to the generator set.

(2) The Analyzer Hose Kit provides hoses and plumbing fittings for pneumatic and hydraulic connections between the generator set and the Analyzer.

b. Gas Turbine Engine Analyzer Connections. Connect the Gas Turbine Engine Analyzer to the generator set as shown in figure 2-2 and observing the following.

(1) Install thermocouple and thermocouple harness (22), provided with Analyzer, in place of engine thermocouple and connect thermocouple harness to THERMOCOUPLE receptacle on Analyzer.

(2) Install Special Electrical Branched Cable Assembly on MAIN receptacle on Analyzer and connect into generator set electrical harnesses as designated on Cable Assembly connectors. Install identification plate attached to Cable Assembly over Analyzer indicator lights to provide proper identification of indicator lights and switches.

(3) Use hoses and fittings from Analyzer Hose Kit to connect fuel and oil components as shown in figure 2-2. Connect fuel by-pass inlet hose (2) to AIR IN fitting on Analyzer and fuel by-pass discharge hose (15) to AIR OUT fitting. Insert discharge end of fuel by-pass discharge hose (15) in a suitable fuel container. Connect fuel pressure hose (4) to FUEL fitting on Analyzer. Connect oil pressure hose (11) to OIL fitting on Analyzer.

c. Gas Turbine Engine Analyzer Operation. Operate the Gas Turbine Engine Analyzer to check out generator set operation as follows, (fig. 2-3).

NOTE

These instructions apply only to Gas Turbine Engine Analyzer, AiResearch Part Number 281069-1 FSN 4920-778-6091. For additional information on the Analyzer, refer to TM 5-4920-200-15.

(1) Perform static checks of components by inserting the static check jumper lead in the appropriate electrical post on the Analyzer panel and actuating the individual component by energizing the static check switch on the Special Electrical Branched Cable Assembly.

(2) Perform operational check of the generator set by operating the generator set and observing the Analyzer for the following indications.

(a) MASTER Switch (on generator set) in RUN position.

MASTER RELAY light illuminated.

LOW OIL PRESS light illuminated.

(b) MASTER Switch (on generator set or analyzer) momentarily in START position.

AC RESET RELAY light illuminated.

STARTER light illuminated.

HOLD RELAY light illuminated.

TACH GENERATOR RPM indicator indicates rpm.

OIL pressure gage indicates pressure.

(c) Oil Pressure Reaches 2.5 to 3.5 PSIG.

FUEL light illuminates.

IGNITION light illuminates.

EXHAUST TEMP indicator indicates exhaust gas temperature.

(d) Generator set accelerates from 35 to 37 percent governed rpm starter cutout, switch in centrifugal switch assembly actuates.

STARTER light is extinguished.

(e) Oil pressure reaches 55 to 65 psig.

LOW OIL PRESS light is extinguished.

(f) Generator set acceleration reaches approximately 95 percent of governed speed, ready to load switch in centrifugal switch assembly actuates.

95 per cent RELAY light illuminates.

IGNITION light is extinguished.

(g) Place CKT BREAKER CLOSED switch in ON position.

CKT BREAKER CLOSED light illuminates.

(h) If oil temperature exceeds 250°F.

HI OIL TEMP light illuminates.

(i) If oil pressure drops below 55 psig.

LOW OIL PRESS light illuminates.

All lights except LOW OIL PRESS and

MASTER RELAY are extinguished (generator set shuts down).

(j) If exhaust gas temperature exceeds 1200°F.

HIGH TURB TEMP light illuminates.


(k) Protection BY-PASS Switch (on generator set) placed in ON position.

OVER TEMP SOL light illuminates.

(l) If enclosure temperature exceeds 450°F (fire inside enclosure).


(4) FIRE light illuminates.

(3) Special checks and observations of engine operating sequence may be performed by controlling engine rpm with the VALVE on the Analyzer to by-pass fuel as required to obtain the desired rpm.




ME 6115-320-34/2-1 (1)

Figure 2-1. Special tools and equipment (sheet 1 of 3).




ME 6115-320-34/2-1 (2)

Figure 2-1. Special tools and equipment (sheet 2 of 3).



ME 6115-320-34/2-1 (3)


Figure 2-1. Special tools and equipment (sheet 3 of 3).



ME 6115-320-34/2-2

Figure 2-2. Connecting gas turbine engine analyzer to generator set.

THERMOCOUPLE HARNESS ASSEMBLY



ME 6115-320-34/2-3

Figure 2-3. Gas turbine engine analyzer controls and instruments panel.

-3. Maintenance Repair Parts

Repair parts and equipment required to perform direct and general support maintenance of the

generator set are listed and illustrated in TM 5-6115-320-34P.

Table 2-1. Special tools and test equipment

Item	FSN or P / N	Reference			Use
		Fig.	Item	Para	
Spanner wrench	5120-778-6120	2-1	3	3-17	To replace the accessory output shaft nut.
Clutch torquing holder	5120-862-0050	2-1	5	3-3	To hold the starter clutch housing in a fixed position in an arbor press while assembling clutch parts and when checking clutch slip torque.
Mechanical fan puller	5120-778-6118	2-1	6	3-17	To remove the fan from the rotating assembly shaft of the accessory assembly.
Seal puller	5120-778-6115	2-1	1	3-17	To install the output shaft seal in the seal retainer of the accessory assembly.
Seal driver	5120-778-616	2-1	2	3-17	To install the oil pump seal located in the case assembly of the accessory assembly.
Mechanical seal puller	5120-608-8939	2-1	9	3-8	To replace the oil pump shaft seal.
Torque wrench adapter	5120-862-0049	2-1	7	3-3	To check the slip torque of the starter motor clutch assembly.
Wrench adapter	5120-608-6794	2-1	4	3-17	To hold output shaft stationary while the nut is being removed.
Seal installing holder	5120-778-6117	2-1	8	3-17	To replace the fan shaft seal within the accessory case.
Gas turbine engine analyzer	4920-778-6091	2-1	11	2-2	To monitor operating conditions of the gas turbine engine and as a bench setup for individual component troubleshooting.
Adjustable beam type sling	6115-731-0051	2-1	13	2-9	To hoist the gas turbine engine with the generator attached.
Chain	Commercial 2,000 lb test	2-1	14	2-9	To hoist the complete enclosure.
Analyzer hose kit	1450-799-8432	2-1	12	2-2	To supply hoses and fittings necessary to supplement the gas turbine engine analyzer.
Special purpose electrical branched cable assembly	(99193) 284044-1-1 FSN 6150-014-5556	2-1	10	2-2	To electrically interconnect the gas turbine engine analyzer DC circuitry with the gas turbine engine control system.

Section II. TROUBLESHOOTING

2-4. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the generator set and its components.

2-5. Troubleshooting

Malfunctions which may occur are listed in table 2-

2. Each malfunction stated is followed by a list of probable causes of the trouble. The corrective action recommended is described opposite the probable cause. Refer to TM 5-6115-320-12 for initial trouble-shooting information.

Table 2-2. Troubleshooting

Malfunction	Probable Cause	Corrective Action
1. Fuel boost pump and motor assembly fails to operate	a. Master switch defective b. Fuel boost pump and motor assembly defective	a. Refer to TM 5-6115-320-12. b. Perform test procedure (para 3-6). If test indicates a defective pump, repair pump (fig. 3-6). If fuel boost pump and motor assembly is defective beyond repair, replace fuel boost pump and motor assembly (para 3-6).

Table 2-2. Troubleshooting—continued

Malfunction	Probable Cause	Corrective Action
<p>2. No response when master switch placed in start position</p>	<p>a. Master switch defective b. Start motor defective</p> <p>c. Start relay defective d. Centrifugal switch assembly starter cutout switch defective</p> <p>e. Master relay (K2) defective f. No. 1 holding relay (K3) defective</p> <p>g. Centrifugal switch assembly defective</p>	<p>a. Refer to TM 5-6115-320-12. b. Replace start motor brushes (fig. 3-3). If starter motor is defective beyond repair, replace starter assembly (para 3-3). c. Refer to TM 5-6115-320-12 d. Perform continuity check between pins A and B of centrifugal switch assembly electrical receptacle. If continuity is not indicated, replace centrifugal switch assembly (para 3-18). e. Replace master relay (fig. 3-37). f. Perform test procedure (para 3-4). If malfunction is indicated, replace relay (fig. 3-4). g. Perform continuity check between pins in centrifugal switch assembly electrical receptacle. Pin A to B should indicate continuity. Pin C to D should indicate continuity. Pin D to E should indicate continuity. Pin D to F should indicate no continuity. If malfunction is indicated, replace centrifugal switch assembly (TM 5-6115-320-12).</p>
<p>3. Starter rotates but does not crank engine</p>	<p>h. Start relay defective a. Starter clutch defective</p> <p>b. Accessory drive assembly defective</p>	<p>h. Refer to TM 5-6115-320-12. a. Adjust clutch (para 3-3). If clutch is defective, replace starter assembly (para 3-3). b. Check for positive coupling through engine by manually turning turbine wheel. If defective, replace accessory drive assembly (fig. 3-23).</p>
<p>4. Engine fails to start</p>	<p>a. Centrifugal switch assembly overspeed shutdown switch defective</p> <p>b. Fuel boost pump defective</p> <p>c. Fuel control unit defective</p> <p>d. Oil pump assembly defective.</p> <p>e. Oil pressure sequencing switch defective</p> <p>f. Engine wiring harness defective</p> <p>g. Ignition unit defective</p>	<p>a. Perform continuity check between pins C to D in centrifugal switch assembly electrical receptacle. If continuity is not indicated, replace centrifugal switch assembly (para 3-18). b. Perform test procedure (para 3-6). If malfunction is indicated, repair fuel boost pump (fig. 3-6). c. Perform test procedure (para 3-5). If malfunction is indicated, replace fuel control unit (fig. 3-5). d. Repair defective oil pump assembly (para 3-8). If pump is defective beyond repair, replace oil pump assembly (fig. 3-7). e. Perform test procedure (TM 5-6115-320-12). If malfunction is indicated, adjust or replace oil pressure sequencing switch (TM 5-6115-320-12). f. Repair engine wiring harness (para 3-2). If wiring harness is defective beyond repair, replace engine harness (fig. 3-1). g. Refer to TM 5-6115-320-12.</p>

Table 2-2. Troubleshooting—continued

Malfunction	Probable Cause	Corrective Action
<p>Low fuel pressure</p>	<p>a. Fuel control unit defective b. Fuel boost pump defective</p>	<p>a. If malfunction is indicated, replace fuel control unit (fig. 3-5). b. Perform test procedure (para 3-6). If malfunction is indicated, repair fuel boost pump (fig. 3-6). If fuel boost pump is defective beyond repair, replace fuel boost pump and motor assembly (para 3-6). a. Refer to TM 5-6115-320-12.</p>
<p>Starter cranks engine but combustion does not occur. Normal fuel pressure and no pressure drop at 10 percent speed</p>	<p>a. Fuel shutoff solenoid valve defective b. Oil pressure sequencing switch defective</p>	<p>a. Refer to TM 5-6115-320-12. b. Perform test procedure (TM 5-6115-320-12). If malfunction is indicated, adjust or replace oil pressure sequencing switch (TM 5-6115-320-12).</p>
<p>Engine stops immediately after combustion occurs</p>	<p>c. Oil pump assembly defective d. Ignition unit defective a. Holding relays (K3 and K4) defective b. Oil pressure sequencing switch defective</p>	<p>c. Repair oil pump assembly (fig. 3-8). If pump is defective beyond repair, replace oil pump assembly (fig. 3-7). d. Refer to TM 5-6115-320-12. a. Perform test procedure (para 3-4). If malfunction is indicated, replace holding relays (fig. 3-4). b. Perform test procedure (TM 5-6115-320-12). If malfunction is indicated, adjust or replace oil pressure sequencing switch (TM 5-6115-320-12).</p>
<p>Engine starts, accelerates to governed speed or less, and shuts down</p>	<p>c. Fuel control unit defective d. Oil pump assembly defective</p>	<p>c. If malfunction is indicated, replace fuel control unit (fig. 3-5). d. Replace oil pump assembly (fig. 3-7).</p>
<p>Engine starts, accelerates to governed speed or less, and shuts down</p>	<p>a. Centrifugal switch assembly overspeed shutdown switch setting too low b. Low oil pressure switch defective</p>	<p>a. Record rpm on tachometer at cutoff point. Adjust overspeed shutdown switch setting (para 3-18). If centrifugal switch assembly is defective beyond adjustment replace centrifugal switch assembly (fig. 3-25). b. Perform test procedure, (TM 5-6115-320-12). If malfunction is indicated, adjust or replace low oil pressure switch (TM 5-6115-320-12).</p>
<p>Engine does not reach governed speed or rate of acceleration too slow.</p>	<p>c. Fire detector defective d. Fire detector relay (K13) defective</p>	<p>c. Perform test procedure (para 3-24). If malfunction is indicated, replace fire detector (fig. 3-35). d. If malfunction is indicated, replace fire detector relay (K13) (fig. 3-37).</p>
<p>Engine does not reach governed speed or rate of acceleration too slow.</p>	<p>a. Starter motor assembly defective b. Fuel control unit defective</p>	<p>a. Replace starter motor brushes (fig. 3-3). Adjust starter motor clutch (para 3-3). If starter motor assembly is defective beyond repair, replace starter motor assembly (para 3-3). b. If malfunction is indicated, replace fuel control unit (fig. 3-5).</p>
<p>Engine does not reach governed speed or rate of acceleration too slow.</p>	<p>c. Acceleration and overtemperature control thermostat defective</p>	<p>c. If malfunction is indicated, replace acceleration and overtemperature control thermostat (fig. 3-33).</p>
<p>10. Acceleration erratic</p>	<p>a. Acceleration and overtemperature control thermostat defective b. Fuel control unit defective</p>	<p>a. If malfunction is indicated, replace acceleration and overtemperature control thermostat (fig. 3-33). b. If malfunction is indicated, replace fuel control unit (fig. 3-5).</p>

Table 2-2. Troubleshooting—continued

Malfunction	Probable Cause	Corrective Action
11. Excessive exhaust gas temperature on start, or flaming start	<ul style="list-style-type: none"> a. Turbine plenum drain obstructed b. Acceleration and overtemperature control thermostat defective c. Fuel atomizer assembly defective d. Fuel control unit defective 	<ul style="list-style-type: none"> a. Remove obstruction from plenum drain. b. If malfunction is indicated, replace acceleration and overtemperature control thermostat (fig. 3-5). c. Refer to TM 5-6115-320-12. d. If malfunction is indicated, replace fuel control unit (fig. 3-5).
12. Excessive oil smoke from engine exhaust during operation	<ul style="list-style-type: none"> a. Packing in oil jet tube or oil breather tubes defective b. Defective air-oil seals in turbine or compressor assemblies 	<ul style="list-style-type: none"> a. Replace packing (fig. 3-11). b. Report condition to depot maintenance
13. Low oil pressure or loss of oil pressure	<ul style="list-style-type: none"> Oil pump assembly defective 	<ul style="list-style-type: none"> Repair oil pump assembly (fig. 3-8). If oil pump assembly is defective beyond repair, replace oil pump assembly (fig. 3-7).
14. Engine shuts down during operation	<ul style="list-style-type: none"> a. Fuel boost pump and motor assembly defective b. Fuel control unit defective c. Oil pump assembly defective d. Low oil pressure switch defective e. Fire detector defective f. Fire detector relay (K13) defective g. Oil pressure sequencing switch assembly defective h. Centrifugal switch assembly defective 	<ul style="list-style-type: none"> a. Perform test procedure (para 3-6). If malfunction is indicated, repair fuel boost pump motor assembly (fig. 3-6). If defective beyond repair, replace fuel boost pump and motor assembly (para 3-6). b. If malfunction is indicated, replace fuel control unit (fig. 3-5). c. Repair oil pump assembly (fig. 3-8). If defective beyond repair, replace oil pump assembly (fig. 3-7). d. Perform test procedure (TM 5-6115-320-12). If malfunction is indicated, adjust or replace low oil pressure switch (TM 5-6115-320-12). e. Perform test procedure (para 3-24). If malfunction is indicated, replace fire detector (fig. 3-35). f. If malfunction is indicated, replace fire detector relay (K13) (fig. 3-37). g. Perform test procedure (TM 5-6115-320-12). If malfunction is indicated, replace oil pressure sequencing switch (TM 5-6115-320-12). h. Perform continuity check between pins in centrifugal switch assembly electrical receptacle. Pin A to B should indicate continuity. Pin C to D should indicate continuity. Pin D to E should indicate continuity. Pin D to F should indicate no continuity. If malfunction is indicated, replace centrifugal switch assembly (fig. 3-25).
15. Excessive fuel leakage from fuel control unit drain	<ul style="list-style-type: none"> Fuel control unit defective 	<ul style="list-style-type: none"> Replace fuel control unit (fig. 3-5).
16. Oil leakage from fuel control unit drain	<ul style="list-style-type: none"> Oil pump drive shaft seal (25, fig. 3-23) 	<ul style="list-style-type: none"> Replace oil pump drive shaft seal (25, fig. 3-23) (para 3-17).

Table 2-2. Troubleshooting—continued

Malfunction	Probable Cause	Corrective Action
<p>17. Engine speed drops more than 1000 rpm when load is applied or exhaust gas temperature too high (above 1,200°F) (648°C)</p>	<p>a. Fuel control unit defective b. Acceleration and overtemperature control thermostat defective d. AC generator defective e. Thermocouple defective f. Exhaust gas temperature indicator defective</p>	<p>a. Replace fuel control unit (fig. 3-5). b. If malfunction is indicated, replace acceleration and overtemperature control thermostat (fig. 3-33). d. Perform test procedure (para 4-1). If malfunction is indicated, repair or replace AC generator (para 4-1). e. Perform test procedure (para 3-19). If malfunction is indicated, replace thermocouple (TM 5-6115-320-12). f. Perform test procedure (TM 5-6115-320-12) If malfunction is indicated, replace exhaust gas temperature indicator (TM 5-6115-320-12).</p>
<p>18. No AC generator output, overvoltage light is off</p>	<p>a. No. 2 holding relay (K4) defective b. AC generator permanent magnet generator (PMG) defective c. Voltage regulator (VRI) defective d. AC generator control relay (K12) defective e. AC generator rotor windings defective f. AC generator exciter rectifiers defective</p>	<p>a. If malfunction is indicated, replace relay (K4) (fig. 3-37). b. Perform test procedure (para 4-1). If PMG is defective, replace PMG rotor (fig. 4-1). If PMG winding is defective, replace AC generator (fig. 2-5). c. Perform test procedure (para 4-1). If PMG is defective, replace PMG rotor (fig. 4-1). If PMG winding is defective, replace ac generator (fig. 2-5). d. If malfunction is indicated, replace generator control relay (K12) (fig. 3-37). e. Perform test procedure (para 4-1). If malfunction is indicated, replace AC generator (fig. 2-5). f. Perform test procedure (para 4-1). If malfunction is indicated, replace rectifiers (fig. 4-1).</p>
<p>19. No AC generator output, overvoltage light is on</p>	<p>a. Voltage regulator (VR1) defective b. Overvoltage relay (K10) defective c. AC generator defective d. Circuit breaker (S5) defective e. Main circuit breaker (CB3) defective f. Overvoltage, underfrequency, or undervoltage condition in external load</p>	<p>a. If malfunction is indicated, replace voltage regulator (VR1) (fig. 4-3). b. If malfunction is indicated, replace overvoltage relay (K10) (fig. 3-37). c. Perform test procedure (para 4-1). If malfunction is indicated, repair generator (para 4-1). If generator is defective beyond repair, replace generator (fig. 2-5). d. Refer to TM 5-6115-320-12. e. Replace main circuit breaker (CB3) (fig. 4-6). f. Correct condition in external load</p>
<p>20. AC generator trips off and cycles when circuit breaker switch is held closed</p>	<p>a. Overvoltage relay (K5) defective b. Overcurrent relay (K14) defective c. Undervoltage relay (K11) defective</p>	<p>a. If malfunction is indicated, replace overvoltage relay (K5) (fig. 3-37). b. Perform test procedure (para 4-6). If malfunction is indicated, replace overcurrent relay (K14) (fig. 3-37). c. If malfunction is indicated, replace undervoltage relay (K11) (fig. 3-37).</p>

Table 2-2. Troubleshooting—continued

Malfunction	Probable Cause	Corrective Action
20. Continued	d. Overload from AC generator	d. Check for proper connection of phase leads. Perform test procedure (para 4-1). If malfunction is indicated repair generator (para 4-1). If generator is defective beyond repair, replace generator (fig. 2-5).
21. Voltage can not be adjusted	e. Centrifugal switch assembly defective a. Voltage adjusting rheostat defective b. Voltage regulator (VR1) defective c. AC generator exciter rectifier defective d. AC generator defective	e. Replace centrifugal switch assembly (fig. 3-25). a. Replace voltage adjusting rheostat (fig. 3-37). b. If malfunction is indicated, replace voltage regulator (VR1) (fig. 4-3). c. Perform test procedure (para 4-1). If malfunction is indicated, replace rectifiers (fig. 4-1). d. Perform test procedure (para 4-1). If malfunction is indicated, repair generator (para 4-1). If generator is defective beyond repair, replace generator (fig. 2-5).
22. Voltage droop cannot be adjusted	a. Frequency and voltage droop potentiometers defective b. Current transformer (CT4) defective c. Unit parallel switch in unit position	a. Replace frequency and voltage droop potentiometers (fig. 3-37). b. Perform test procedure (para 4-4). If malfunction is indicated, replace current transformer (CT4) (fig. 4-4). c. Place switch in parallel position.
23. Frequency droop, cannot be adjusted	a. Load anticipator defective b. Fuel control unit defective c. Current transformers (CT1 thru CT3) d. Frequency droop potentiometer defective	a. If malfunction is indicated, replace load anticipator (fig. 4-3). b. Replace fuel control unit (fig. 3-5). c. Perform test procedure (para 4-4). If malfunction is indicated, replace defective current transformers (fig. 4-4). d. Replace frequency droop potentiometer (fig. 3-37).
24. Battery heater does not operate	a. Battery temperature sensor (K15) defective b. Temperature control relay (K9) defective c. Heater circuit breaker defective d. Heater igniter defective	a. If malfunction is indicated, replace battery temperature sensor relay (K15) (fig. 3-37). b. If malfunction is indicated, replace temperature control relay (K9) (fig. 3-37). c. Refer to TM 5-6115-320-12. d. Replace heater igniter (fig. 5-11).
25. Battery heater fan operates but heater does not ignite		
26. Fan operates when switch is off	Note. Fan will normally operate for a short period after heater is shut off until flame switch cools and actuates Wiring defective	Replace defective wiring (para 4-8).

Section III. GENERAL MAINTENANCE

2-6. General

This section contains maintenance information that would otherwise have to be repeated throughout this manual.

2-7. Maintenance Requirements

a. *Hardware and Threaded Parts.* Inspect

hardware for damaged threads, rounded corners, and damaged slots. Threaded holes and parts should accept their mating parts without requiring excessive torque. Threads may be chased with a tap or die. Replace any threaded parts which cannot be repaired.

b. Gaskets. Replace all gaskets which are disturbed during repair operations or which show evidence of leakage. When installing gaskets, use grease or gasket cement to retain gasket in position during reassembly procedures.

c. Oil Seals and Packings. Thoroughly lubricate the sealing lip of spring loaded seals with grease or other suitable lubricant when installing. Apply non-hardening sealer to the outer circumference of encased seals or to the mating bores to prevent possible leakage. Immerse preformed packings in the liquid or lubricant with which they will be in contact.

d. Ball and Roller Bearings. After removing antifriction bearings, cover them immediately to keep out dirt and abrasives. Flush thoroughly with solvent, tap them against a wooden block to remove packed lubricant, and air dry. Coat cleaned bearings with oil, and wrap in clean paper. Replace any bearings that are scored, pitted, discolored from overheating, or otherwise damaged. When installing bearings against shoulders, be sure the chamfered side faces the shoulder. Lubricate the bearing and its mating surface when pressing a bearing into place. Press bearings only on the race

adjacent to the mating part. Use drivers which contact as much of the race as possible.

e. Repair of Damaged Machine and Polished Surfaces. Remove rough spots, scores, burrs, galling, gouges, and other surface damage from machined and polished surfaces. Use a suitable honing stone, crocus or emery cloth, file, or any other method that will permit the part to function efficiently. The finish of the part must approximate that of the original finish. Do not alter critical dimensions beyond acceptable limits. Build up shafts, rods, and other worn parts by metallizing, chrome plating, or welding. Grind built up parts to original size.

f. Welding Repair. Welding must be performed by a qualified welder. Welds must provide complete fusion and penetration and comply with governing specifications. Inspect all welds using a radiographic or magnetic particle process. Grind all new welds flat and smooth whenever possible.

g. Part Replacement. Replace parts which are worn or defective with new parts. Consider such factors as age, operating hours, usage, and parts availability to determine the necessity of part replacement.

Section IV. REMOVAL AND INSTALLATION OF MAJOR COMPONENTS

2-8. General

The major components of the generator set are the gas turbine engine and ac generator assembly, and the battery heater assembly. In order to facilitate repair of the gas turbine engine, and generator, they may be removed as a unit, with the mounting frame. This section covers direct and general support maintenance instructions for the removal, installation and where necessary the adjustment, of these components as authorized by the maintenance allocation chart.

2-9. Engine and Generator Assemblies

a. Removal. To remove the gas turbine engine and generator assembly, refer to figure 2-4 and proceed as follows:

- (1) Remove top panels (TM 5-6115-320-12).
- (2) Remove clamps (1, fig. 2-4) from cooling duct and remove cooling duct.
- (3) Remove fire detector from firewall by removing screws (2), washer (3), and nuts (4), from mounting bracket on firewall.
- (4) Remove screws (5) and washers (6) from upper firewall assembly (7).
- (5) Remove upper firewall assembly (7) by pushing back from engine compressor section, then pulling up until firewall assembly is clear of guides.
- (6) Disconnect generator electrical leads (8) and tag for identification.

(7) Disconnect starter motor electrical leads (9).

(8) Disconnect connector (10) and tag for identification.

(9) Disconnect connector (11) and tag for identification.

(10) Disconnect fuel control inlet line (12) and tag for identification.

(11) Disconnect fuel control drain line (13) at enclosure and tag for identification.

(12) Disconnect oil drain line (14) and tag for identification.

(13) Disconnect bleed air line (15) and tag for identification.

(14) Disconnect plenum drain line (16) and tag for identification.

(15) Remove clamp (17) and gasket (18) from exhaust pipe flange.

(16) Remove bolts (19) and washers (20) from frame.

(17) Secure a 2,000 pound test chain to lifting eyes (21 and 22). Support weight of engine ac generator assembly with adjustable beam type sling and a hoist.

CAUTION


Do not attach chains from the hoist assemblies to the lifting equipment in such a manner that the angle between

any of the chains and the top of the engine is less than 45°. Any angle less than 45° will cause an excessive strain, which could possibly bend or break the lifting eyes.

(18) While lifting gas turbine engine and ac


generator, push aside cable as necessary to prevent binding.

b. Installation. Install the gas turbine engine and ac generator in reverse order of removal using figure 2-4 as a guide.



ME 6115-320-34/2-4 ①

Figure 2-4. Engine and ac generator assembly removal and installation. (sheet 1 of 2).



- | | |
|--|--|
| <ul style="list-style-type: none"> 23. VOLTAGE DISTRIBUTION PANEL 24. FIRE DETECTOR PROBE 25. COOLING AIR FAN ASSEMBLY 26. OIL COOLER COOLING AIR DUCT 27. TUBULAR OIL COOLER 28. FUEL BOOST PUMP AND MOTOR ASSEMBLY 29. LOW OIL PRESSURE SWITCH 30. OIL PRESSURE SEQUENCING SWITCH 31. CENTRIFUGAL SWITCH ASSEMBLY 32. OIL PUMP ASSEMBLY 33. TACHOMETER GENERATOR 34. INTERNAL COMBUSTION BATTERY HEATER 35. BATTERY HEATER FUEL FILTER ASSEMBLY | <ul style="list-style-type: none"> 36. START RELAY 37. BATTERIES 38. BATTERY ELECTROLYTE TEMPERATURE SENSOR 39. BATTERY BOX ASSEMBLY 40. BATTERY HEATER ELECTRIC FUEL PUMP 41. OIL FILTER ASSEMBLY 42. BATTERY HEATER FUEL SHUTOFF VALVE 43. FUEL CONTROL UNIT 44. FUEL SOLENOID VALVE 45. OIL DRAIN VALVE 46. OIL TANK ASSEMBLY 47. FUEL FILTER ASSEMBLY 48. FIRE DETECTOR PROBE |
|--|--|


ME 6115-320-34/2-4 (2)

Figure 2-4. Engine and ac generator assembly removal and installation. (sheet 2 of 2).

2-10. AC Generator Assembly

a. *Removal.* Removal of the ac generator assembly may be accomplished by following a sequence of index numbers in figure 2-5.

b. *Installation.* Install the ac generator assembly in reverse order of removal using figure 2-5 as guide.



ME 6115-320-34/2-5

Figure 2-5. AC generator assembly removal and installation.

2-11. Battery Heater Assembly

Refer to TM 5-6115-320-12 for removal and installation procedures.

CHAPTER 3

REPAIR OF GAS TURBINE ENGINE

Section I. REPAIR OF ENGINE ELECTRICAL SYSTEM

3-1. General

This section contains information useful to direct and general support maintenance personnel in their performance of maintenance of the engine electrical system.

3-2. Engine Wiring Harness Assembly

a. General. The gas turbine engine wiring harness assembly connects to a receptacle attached on a bracket mounted to the accessory cooling duct on the right side of the engine. The gas turbine engine wiring harness assembly consists of wiring, attached terminals and connectors to interconnect all electrically operated engine components.

b. Removal. Refer to figure 3-1 for identification of engine wiring harness assembly. Remove harness assembly by disconnecting the electrical connectors and terminals from the various engine components and removing clamps securing harness assembly to

engine. Tag or otherwise identify connectors, leads, and location of clamps for aid at installation.

c. Repair. Refer to figure FO-4 and figure 3-2 for wire identification, routing and replacement, observing the following:

(1) Replace thermostat lead with lead per MIL-C-25038.

(2) All wire sizes are number 18 AWG.

(3) Identify all new leads with approved markers.

(4) Provide drip loops as applicable per MIL-W5088.

(5) Soldering of connections shall be per MIL-S-6872.

(6) Solder used shall be per QQ-3-571, composition SN50.

d. Installation. Install engine wiring harness assembly in reverse order of removal, using figure 3-1 as a guide.




Figure 3-1. Engine wiring harness identification.

AWG SIZE	LENGTH INCHES	WIRE NUMBER	LOCATION PIN NO.		LOCATION PIN NO.	
			FROM		TO	
18	89	E311A18	1	K	22	3
18	89	E312A18	1	R	22	1
18	18	E315A18	1	f	15	C
18	18	E316A18	1	g	15	D
18	19	K11B18	14	A	15	A
18	18	K111C18	14	A	17	D
18	57	K114B18	14	B	13	A
18	18½	E310A18	1	v	11	B
18	18½	E309A18	1	h	11	A
18	79	ALUMEL	1	T	39	—
18	79	CHROMEL	1	S	39	—
18	18½	E306A18	1	G	12	B
18	18½	E305A18	1	F	12	A
18	49½	K304A18	1	P	10	D
18	49½	K303A18	1	N	10	C
18	49½	K302A18	1	M	10	B
18	49½	K301A18	1	L	10	A
18	16½	K117A18	1	J	17	E
18	16½	K116A18	1	D	17	F
18	41½	K115A18	1	U	38	—
18	14	K114A18	1	e	14	B
18	18	K113A18	1	X	15	B
18	44	K112A18	1	H	16	A
18	18	K111A18	1	W	15	A
18	16½	K110A18	1	C	17	C
18	16½	K108A18	1	B	17	B
18	16½	K107A18	1	A	17	A
18	13½	K102D18N	36	—	40	—
18	13	K102C18N	13	B	36	—
18	13½	K102B18N	16	B	36	—
18	45	K102A18N	1	Z	36	—

ME 6115-320-34/3-2

Figure 3-2. Engine wiring harness, wire identification chart.

3-3. Starter Motor Assembly

a. *General.* The starter motor assembly is mounted at the top left side of the accessory assembly. Three pawls and a clutch mechanism, mounted on the starter shaft drive end engage with a ratchet on the end of the accessory drive shaft. The pawls are spring-loaded and are in retracted position until the starter motor is operated. When the starter motor is operated, the inertia of the

pawls and cage overcomes the spring load and force the pawl inward to engage with the ratchet. Torque, as a result of the starting operation, is absorbed by a clutch which is adjusted to slip at 130 to 145 inch-pounds. This arrangement absorbs shock at initial engagement, and allows the starter motor to engage with the ratchet at any time the engine is running, provided the speed of the engine is less than the cut-out speed of the starter motor

(35 to 55 percent of governed speed). The starter motor is series wound and has an output of one and one-half horsepower at 5,000 rpm.

b. Removal and Installation. Refer to TM 5-6115-320-12 for removal and installation of the starter.

c. Disassembly. Refer to figure 3-3 for disassembly procedures observing the following:

- (1) Remove clamp (1).
- (2) Remove insulator (2).
- (3) Remove screw (3) and washers (4 and 5).
- (4) Remove brush holder (6).
- (5) Remove brushes (7).
- (6) Replace brushes that are shorter than $\frac{1}{2}$ inch.
- (7) Record the position of pawls (10) and spider (11) to aid in reassembly.
- (8) Remove retainer (8).
- (9) Straighten end of spring (15) and remove spider (11), pins (9), and pawls (10).
- (10) Remove threaded ring (12) with spanner wrench.
- (11) Remove plates (13), clutch retainer (14), clutch spring (15), spring washer (16), and washer (17).
- (12) Drive out pin (18) and remove housing (19) from starter motor (20) if necessary.

NOTE

Do not remove pin (18) and housing (19) from starter motor (20) unless retainer housing or starter motor is defective.

d. Cleaning.

- (1) Remove all dust, dirt, and foreign matter from starter motor assembly by using clean, dry compressed air.

- (2) Clean all disassembled parts in cleaning solvent (Fed P-D-680).

e. Inspection. Inspect all disassembled parts for evidence of wear or damage. If defective, replace as necessary.

f. Repair. If the starter motor assembly is defective beyond repair outlined in this section, replace starter motor assembly and clutch assembly as a unit. If the clutch assembly requires repair, disassemble and replace parts only to the extent necessary to replace the defective part.

g. Reassembly. Refer to figure 3-3 as a guide and reassemble the starter motor observing the following:


- (1) Install housing (19) on starter motor (20) and secure with pin (18).
- (2) Install washers (17), spring washer (16), clutch plates (13), and clutch retainer (14).

NOTE

Coat clutch plates (13) with OE 10 and install with friction face of plates against flange of clutch retainer (14).

- (3) Install threaded ring (12) and clutch spring (15).
- (4) Assemble spider (11), pawls (10), and pins (9) and install into clutch retainer (14).
- (5) Install retainer (8).
- (6) Bend end of clutch spring (15) 35 to 55 degrees.

h. Adjustment. Mount clutch torquing holder on starter motor assembly. Use torque wrench adapter and torque wrench to check slip-torque. Slip-torque must be 130 to 145 inch-pounds. If slip-torque is not within the specified limits, adjust threaded ring (12) accordingly.



ME 6115-320-34/3-3

Figure 3-3. Starter motor assembly disassembly and reassembly.

-4. Turbine Holding Relays

a. **Removal.** Remove turbine holding relays (K3 and K4) according to sequence of index numbers assigned to figure 3-4.

b. **Cleaning and Inspection.**

(1) Remove all dust, dirt and foreign matter from turbine holding relays with clean, dry compressed air.

(2) Clean the turbine holding relays with a cloth moistened with solvent (FED P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage or stripping

of threads. If defective, replace turbine holding relay.

c. **Testing.** To test the turbine holding relays proceed as follows:

(1) Use a multimeter set at the lowest ohm scale to test the turbine holding relays.

(2) When the relay coils are not energized, continuity should be indicated between terminals A2 and A3, B2 and B3, C2 and C3, D2 and D3. The same shall apply to K4 and K5 except that D terminals are not used on K4 and A terminals are not used on K5.


(3) Connect the negative terminal of a 24 v dc power source to the X1 terminal of the relay and connect the positive terminal of the power source to terminal X2.

(4) With the relay coils energized as instructed in (3) above, continuity should be indicated be-

tween terminals A1 and A2, B1 and B2, C1 and C2, D1 and D2.

(5) Disconnect the multimeter and power source.

d. Installation. Install the turbine holding relays in the reverse order of removal procedure using figure 3-4 as a guide.



ME 6115-320-34/3-4

Figure 3-4. Turbine holding relays (K3 and K4) removal and installation.

Section II. REPAIR OF THE FUEL SYSTEM

3-5. Fuel Control Unit

a. General. The fuel control unit, mounted on the lower left side of the accessory assembly is the major component of the gas turbine engine fuel system, and is driven by the oil pump assembly

drive shaft. The fuel control unit meters fuel to the atomizer assembly to accelerate the engine to governed speed during starting and to maintain engine rpm at governed speed regardless of load changes.

b. *Removal.* Remove fuel control unit according to sequence of index numbers assigned to figure 3-5.

CAUTION

Carefully withdraw fuel control unit in a straight line to prevent damage to splines.

c. *Cleaning and Inspection.*

(1) Remove all dust, dirt and foreign matter from the fuel control unit with clean, dry, compressed air.

(2) Clean the fuel control unit (externally)


with cleaning solvent (FED P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage or wear. If defective, replace the fuel control unit.


d. *Installation.* Install the fuel control unit in reverse order to removal procedure using figure 3-5 as a guide and observing the following:

CAUTION

Carefully install fuel control unit in a straight line to prevent damage to splines. If necessary, rotate turbine wheel manually to aline splines.



- 1 Screw
- 2 Washer
- 3 Nut
- 4 Washer (3)
- 5 Bolt
- 6 Support
- 7 Nut (4)
- 8 Washer (4)
- 9 Fuel control unit
- 10 Gasket



ME 6115-320-34/3-5

Figure 3-5. Fuel control unit removal and installation.

3-6. Fuel Boost Pump

a. Fuel Boost Pump. The fuel boost pump is mounted on the right side of the enclosure base forward of the gas turbine engine firewall and is an electrically driven rotary-gear type pump. The fuel boost pump draws fuel from an external source and supplies it to the fuel control unit.

b. Removal. Refer to TM 5-6115-320-12 for removal procedures.

c. Cleaning and Inspection.

(1) Remove all dust, dirt and foreign matter from the fuel boost pump with clean, dry compressed air.

(2) Clean the fuel boost pump in an approved solvent (FED. P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage, corrosion, wear, or stripped threads.

d. Testing.

(1) Install a 0 to 30 psig pressure gage in the boost pump discharge line between the pump and fuel control unit.

(2) Apply 24v dc to terminal 1 (positive) and 11 (negative) of TB3 (fig. FO-1) to operate pump.

(3) Observe pressure gage for 15 psig minimum indication.

NOTE

Pressure in step c (3) above is valid only when fuel supply is within 25 feet of fuel boost pump.


(4) Pressure may be adjusted by removing cap nut on side of pump stator (12, fig. 3-6) and turning adjustment screw clockwise to increase or counterclockwise to decrease pressure.

e. Repair.

(1) Disassemble pump according to sequence of index numbers assigned to figure 3-6.

(2) Replace packing, seal, and gasket and assemble in reverse order of disassembly procedures.

f. Installation. Refer to TM 5-6115-320-12 for installation procedures.



ME 6115-320-34/3-6

Figure 3-6. Fuel boost pump, exploded view.

3-7. Fuel Atomizer Assembly

a. *Removal.* Refer to TM 5-6115-320-12 for removal procedures.

b. *Repair.*

(1) Inspect screen for breaks and clogged condition. Replace a defective screen. Discard packing and gasket.

(2) Repair parts having minor burrs on roughness by polishing with abrasive (Fed. Spec. P-P-101, 400 to 600 grit) paper.

CAUTION

Do not use abrasive paper or sandpaper to clean or repair head; alteration of fuel spray pattern may result.

(3) Replace all parts that do not pass inspection or are damaged beyond simple repair.

c. *Installation.* Refer to TM 5-6115-320-12 for installation procedures.

Section III. REPAIR OF LUBRICATING SYSTEM

3-8. Oil Pump Assembly

a. Oil Pump Assembly. The oil pump assembly is mounted on the lower left side of the accessory drive assembly case and is mechanically driven. The oil pump assembly consists of two major subassemblies; the oil pressure pump and the oil scavenge pump. The two subassemblies are bolted together and share a common drive shaft.

b. Removal. Remove tachometer-generator as described in paragraph 3-23. Remove thermostatic oil switch as described in TM 5-6115-320-12. Remove centrifugal switch assembly as described in paragraph 3-18. Remove oil pump assembly according to sequence of index numbers assigned to figure 3-7.

c. Cleaning and Inspection.

(1) Remove all dust, dirt and foreign matter from the oil pump assembly with clean, dry, compressed air.

(2) Clean the oil pump assembly in cleaning solvent (FED-P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage, corrosion, cracks, wear, or stripped threads. If defective, replace oil pump assembly.


d. Repair.

(1) Disassemble oil pump assembly according to sequence of index numbers assigned to figure 3-8.

(2) Replace preformed packings. Replace tachometer-generator seal using Mechanical Seal Puller.


(3) Assemble oil pump assembly in reverse order of disassembly procedures.

e. Installation. Install the oil pump assembly in reverse order of removal procedures using figure 3-7 as a guide.



ME 6115-320-34/3-7

Figure 3-7. Oil pump assembly removal and installation.



ME 6115-320-34/3-8

Figure 3-8. Oil pump assembly, exploded view.

3-9. Oil Tank Assembly

a. Oil Tank Assembly. The oil tank assembly is mounted on the left side of the compressor assembly plenum. The oil tank assembly supplies oil to the oil pressure pump and serves as an oil storage container for the gas turbine engine.

b. Removal. Refer to TM 5-6116-320-12 for removal procedures.

c. Cleaning and Inspection.

(1) Remove external dust, dirt and foreign matter from the oil tank assembly with clean, dry compressed air.

(2) Clean the oil tank assembly in cleaning solvent (FED P-D-680) and dry thoroughly.


(3) Inspect the oil tank assembly for evidence of damage, cracks, corrosion, excessive wear and stripped threads. If defective, replace the oil tank assembly.

d. Repair.

(1) Disassemble oil tank assembly according to sequence of index numbers assigned to figure 3-9.

(2) Replace preformed packings and assemble oil tank assembly in reverse order of disassembly procedures using figure 3-9 as a guide.

e. Installation. Refer to TM 5-6115-320-12 for installation procedures.



- | | |
|----------------------|----------------------|
| 1. Bolt | 15. Union |
| 2. Banjo seal | 16. Prefomed packing |
| 3. Elbow | 17. Bolt |
| 4. Union | 18. Banjo seal |
| 5. Prefomed packing | 19. Elbow |
| 6. Tee | 20. Lockwire |
| 7. Prefomed packing | 21. Bolt (4) |
| 8. Nut | 22. Washer (4) |
| 9. Oil drain valve | 23. Tube |
| 10. Prefomed packing | 24. Prefomed packing |
| 11. Nut | 25. Bolt |
| 12. Lockwire | 26. Banjo seal |
| 13. Reducer | 27. Elbow |
| 14. Prefomed packing | 28. Oil tank |

ME 6115-320-34/3-9

Figure 3-9. Oil tank assembly, exploded view.

3-10. Oil Spray Jet and Breather Tubes

a. Oil Spray Jet and Breather Tubes. The oil spray jet and breather tubes are two concentric tubes installed in a port on top of the compressor assembly case. An external fitting provides separate connections for the two tubes. The outer tube is a breather tube and allows oil vapor and air to be vented from the compressor-turbine bearing cavity

to the oil tank. The inner tube mates with a spray jet assembly in the compressor assembly which directs streams of oil to the compressor shaft bearing and the turbine assembly bearing.

b. Removal. Remove oil spray jet and breather tubes according to sequence of index numbers assigned to figure 3-10.

c. Cleaning and Inspection.

(1) Remove dust, dirt and foreign matter from the oil spray jet and breather tubes with clean, dry, compressed air.

(2) Clean the oil spray jet and breather tubes in cleaning solvent (Fed P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage or stripped threads. Replace defective parts.


d. Repair.

(1) Disassemble oil spray jet and breather

tubes according to sequence of index numbers assigned to figure 3-11.

(2) Replace all preformed packings and assembled oil spray jet and breather tubes in reverse order of disassembly using figure 3-11 as a guide.

e. Installation. Install the oil spray jet and breather tubes in the reverse order of removal procedures using figure 3-10 as a guide.




1. Oil pressure hose
2. Vent hose
3. Bolt (2)
4. Washer (2)
5. Oil spray jet and breather tubes

ME 6115-320-34/3-10

Figure 3-10. Oil spray jet and breather tubes removal and installation.

1. Preformed packing
2. Preformed packing
3. Preformed packing
4. Oil breather tube
5. Preformed packing (2)
6. Preformed packing
7. Oil jet tube
8. Union
9. Rider
10. Preformed packing
11. Preformed packing
12. Oil and breather fitting



ME 6115-320-34/3-11

Figure 3-11. Oil spray jet breather tubes, exploded view.

Section IV. REPAIR OF COMBUSTION ASSEMBLY

3-11. Combustion Chamber Assembly


a. Combustion Chamber Assembly. The combustion chamber assembly (5, fig. 3-12) is constructed of steel and is ceramic coated to withstand high temperatures. It is perforated to permit entry of air for combustion from the compressor. The lower end of the combustion chamber assembly is mated with the turbine torus, which directs the

products of combustion to the turbine nozzle and shroud assembly, and thence to the turbine wheel.

b. Removal. Refer to TM 5-6115-320-12 for removal procedures.


c. Repair. Repair cracks in the combustion chamber assembly as shown in figure 3-13.

d. Installation. Refer to TM 5-6115-320-12 for installation procedure.



ME 6115-320-34/3-12

Figure 3-12. Combustion system air flow.



ME 6115-320-34/3-13

Figure 3-13. Combustion chamber assembly, exploded view.

3-12. Turbine Plenum

a. Turbine Plenum. The turbine plenum is bolted to the rear of the compressor and surrounds the turbine. It directs the air to the combustion chamber assembly as shown in figure 3-11. The fuel atomizer assembly is mounted in the combustor cap and arranged to spray the fuel into the combustion chamber assembly. The igniter plug is also mounted in the combustor cap and protrudes into the combustion chamber assembly. The turbine plenum is an effective heat shield and enclosure for the combustion chamber assembly.

b. Removal. Remove the muffler, turbine exhaust flange, combustor cap assembly, and

combustion chamber assembly as described in TM 5-6115-320-12. Remove the turbine plenum according to sequence of index numbers assigned to figure 3-14.


c. Cleaning and Inspection.

(1) Clean the turbine plenum with cleaning solvent (FED. P-D-680) and dry thoroughly.

(2) Inspect for cracks, breaks, and other damage.

d. Repair. Repair the turbine plenum by welding as shown in figure 3-15.


e. Installation. Install the turbine plenum in reverse order of removal procedures, observing alignment requirements specified in figure 3-16.



- | | | |
|----------------|----------------|-----------------------------|
| 1. Nut (24) | 8. Bolt (4) | 16. Washer (12) |
| 2. Washer (AR) | 9. Washer (4) | 17. Support |
| 3. Flange | 10. Washer (4) | 18. Support |
| 4. Gasket | 11. Nut (4) | 19. Turbine plenum assembly |
| 5. Bolt (36) | 12. Gasket | 20. Gasket |
| 6. Washer (36) | 13. Gasket | 21. Gasket |
| 7. Bracket | 14. Gasket | 22. Gasket |
| | 15. Bolt (12) | 23. Turbine assembly |

ME 6115-320-34/3-14

Figure 3-14. Turbine plenum removal and installation.



- 1. CRACK IN WELDED SEAM
- 2. CRACK IN INTERSECTING WELDED SEAM
- 3. CRACK IN WELDED SEAM AND ADJOINING MATERIAL

1. CRACK IN WELDED SEAM

NOTES:


- A. WELD PER TM 9-237 AND MIL-W-8611.
- B. CLEAN AND REWELD ANY CRACK SHOWN IN ITEM 1.
- C. ITEMS 2 AND 3 WILL REQUIRE PATCHES.
- D. MINIMUM PATCH THICKNESS 0.035 INCH.
- E. DO NOT OVERLAP PATCHES.
- F. REMOVE ENOUGH MATERIAL SO AS TO ELIMINATE ALL TRACES OF CRACK.
- G. ITEMS 1, 2, AND 3 ARE ILLUSTRATIVE OF THE TYPES OF CRACKS AND DO NOT INDICATE LOCATION WHERE A CRACK MAY APPEAR.
- H. ALL PATCHES ARE TO BE WELDED ON THE OUTER SKIN OF THE PLENUM. NO NEGATIVE STEPS ARE ALLOWED INSIDE OF PLENUM.
- I. INSIDE FLOW SURFACE AND JOINTS TO BE FREE OF EXCESS WELD
- J. RESISTANCE SEAM WELD NOT PERMISSIBLE OTHER THAN TO HOLD PIECES FOR FUSION WELDING.
- K. PRESSURE TEST WELD AT 85 PSIG TO 90 PSIG. NO LEAKAGE PERMITTED
- L. MATERIAL 321 CRES PER SPECIFICATION MIL-S-6721 COMP. T1

ME 6115-320-34/3-15

Figure 3-15. Turbine plenum, exploded view.

USE EITHER 376322 & 376323 GASKETS TO OBTAIN ALINEMENT BETWEEN THE CENTERLINE OF THE COMBUSTION CHAMBER FLANGE IN TORUS AND PLENUM WITHIN 0.00 TO 0.60

NOTE. NO METAL TO METAL CONTACT SHALL EXIST BETWEEN GASKETS AND/OR MATING PARTS. USE 376322 GASKETS AS SEPARATORS.



USE 371959-1 & -2 GASKETS AS REQUIRED TO OBTAIN 0.00 TO 0.000 INCHES COMPRESSION PRELOAD ON PLENUM FLANGE

E = C + 0.060 INCHES (PLENUM OPENING CENTERLINE)
 C = E - 0.060 INCHES (TORUS OPENING CENTERLINE)
 A = 0.0 TO 0.000 INCHES CLEARANCE BEFORE INSTALLING EXHAUST FLANGE.

D = B - A

ME 6115-320-34/3-16

Figure 3-16. Turbine plenum alinement.

Section V. REPAIR OF EXHAUST SYSTEM

3-13. Exhaust Pipe and Ejector

a. *Removal.* Refer to TM 5-6115-320-12 for removal of exhaust pipe and ejector.


b. *Repair.* Repair cracks and breaks of the exhaust pipe and ejector by welding.

c. *Installation.* Refer to TM 5-6115-320-12 for installation procedure.

3-14. Muffler Assembly

a. *Removal.* Remove, clean and inspect as described in TM 5-6115-320-12.

b. *Repair.* Repair the muffler, as required, by welding as shown in figure 3-17.



NOTES:

- A. WELD PER TM 9-237 AND MIL-W-8611.
- B. CLEAN AND WELD ANY CRACKS SUCH AS SHOWN AT 1 ABOVE OR ANY SPOT WELDED SEAMS THAT HAVE PARTED.
- C. WELD PATCHES OVER CRACKS IN MATERIAL SUCH AS SHOWN AT 2 AND 3 ABOVE.
- D. MINIMUM PATCH THICKNESS 0.025 INCH.
- E. DO NOT OVERLAP PATCHES.
- F. REMOVE ENOUGH MATERIAL TO ELIMINATE ALL TRACES OF CRACK.
- G. ITEMS 1, 2, AND 3 ARE TYPICAL OF THE TYPES OF CRACKS THAT MAY BE FOUND, BUT DO NOT INDICATE LOCATIONS WHERE CRACKS ARE LIKELY TO APPEAR.
- H. RESISTANCE SEAM WELD PERMISSIBLE ONLY TO HOLD PIECES FOR FUSION WELDING.
- J. MATERIAL CRES 321 PER SPECIFICATION MIL-S-4721 COMPOSITION T1.

ME 6115-320-34/3-17

Figure 3-17. Muffler assembly, exploded view.

Section VI. REPAIR OF TURBINE ASSEMBLY

3-15. Turbine Assembly

a. General. The turbine assembly is comprised mainly of a turbine wheel and integral shaft, bearing housing, bearings, nozzle and shroud assembly, torus, and seal. The turbine wheel is a radial inward-flow type. The shaft is supported in the bearing housing by two pressure-lubricated ball bearings. A carbon seal, located between the turbine wheel and the adjacent bearing, prevents entrance of air around the turbine wheel to the oil cavity. The nozzle and shroud assembly forms a close fitting shroud at the back and sides of the turbine wheel, and contains nozzle vanes which receive the hot gases from the combustion chamber and direct the gases against the turbine wheel

blades. A heat shield mounted on the wheel end of the bearing housing prevents excessive heat from penetrating to the shaft bearings. The torus mates with the discharge end of the combustion chamber assembly and directs combustion gases into the nozzle vanes leading to the turbine wheel.

b. Removal. Remove the turbine assembly as follows:

(1) Refer to TM 5-6115-320-12 for removal of the muffler assembly, exhaust ejector assembly, fuel atomizer assembly, ignitor plug, combustor cap, and combustion chamber assembly.

(2) Refer to paragraph 3-12 for removal of the turbine plenum.

(3) Remove nuts (1, fig. 3-18), washers (2),

and assembled turbine assembly (index numbers 6 through 16) from compressor assembly (17).

(4) Remove quill shaft (3), spring (4), and packing (5).

c. Cleaning.

(1) Remove dust, dirt and foreign matter from the turbine assembly with clean, dry, compressed air.

(2) Clean the turbine assembly in cleaning solvent (FED. P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage, wear, cracks, and corrosion. Replace defective parts.

d. Inspection. Inspect the nozzle and shroud assembly as follows:

(1) Two shroud cracks less than one-quarter inch apart on the same side of vane which could intersect and break off a segment of material are not permissible (see example 1, fig. 3-19).

(2) Maximum permissible cracks on individual vanes are two cracks less than one-quarter inch long, separated by one-quarter inch minimum, or three cracks less than one-eighth inch long separated by one-eighth inch minimum (see example 2, fig. 3-19).

(3) Concentrations of small cracks are permissible on outer periphery of nozzle shroud (see example 3, fig. 3-19).

(4) Cracks from vane to shroud are permissible under one-quarter inch length (see example 4, fig. 3-19).

CAUTION

A vane to shroud crack may progress along the inside fillet until it joins a crack from an adjacent vane. Examine carefully for this possibility and replace nozzle and shroud assembly if this condition has occurred or is in progress.

(5) Damage from particles striking inner vane (trailing edges) is permissible if nicks, cracks, or dents do not exceed one-sixteenth inch in length; or one crack per vane, providing such damage is not at junction of shroud and vane (see example 5, fig. 3-19).

(6) Bolt hole cracks are permissible provided there are no more than four cracked bolt holes; cracked bolt holes must be separated by a minimum of six holes; cracks may extend to outer periphery but not into inner flange radius.

e. Repair. Repair turbine assembly as follows:

(1) Disassemble turbine assembly according to sequence of index numbers 6 through 16, figure 3-17. Note quantity and thickness of gaskets (9) and shims (14, 15) removed to facilitate assembly.

(2) Replace gaskets (9) with same quantity and thickness noted at disassembly.

(3) Replace torus assembly (8).

(4) Replace quill shaft (3).

(5) Replace preformed packing (5).

f. Installation. Install the turbine assembly in reverse order of disassembly and removal procedure observing the following: (refer to fig. 3-18).

(1) With nozzle and shroud assembly (13) placed on a bench in horizontal position, stand bolts (12) in upright position in slots of nozzle and shroud assembly.

(2) Secure bolts (12) in upright position with single loop of safety wire, and apply a small amount of approved high temperature thread compound to threads of each bolt.

(3) Install nozzle and shroud assembly (13) on turbine rotating assembly (16) using same number and thickness of shims (14, 15) noted at disassembly.

(4) Tighten nuts (11) to a torque of 24 to 28 inch-pounds.

(5) Install torus (8) to nozzle and shroud assembly (13) using same quantity and thickness of new gaskets (9) as noted at disassembly. Use additional gaskets (9) as required to aline holes for pins (7).

(6) Install spring (4) into compressor assembly (17).

(7) Coat spline ends of quill shaft (3) with compound (FSN 9150-664-0050), then install shaft in compressor section.

NOTE

End of shaft (3) with missing spline tooth must be installed against spring.

(8) Install new preformed packing (5), then install turbine assembly on compressor assembly (17).


CAUTION

Aline turbine assembly as straight as possible when installing it on compressor assembly to avoid damage to oil jet. Damage to oil jet may alter oil flow pattern with resulting bearing damage. Exercise care as shaft splines mesh.

(9) Coat nuts (1) and washers (2) with an approved high temperature thread compound and install to secure turbine assembly.


(10) Refer to paragraph 3-12 for installation of the turbine plenum.

(11) Refer to TM 5-6115-320-12 for installation of the combustion chamber assembly, combustor cap, igniter plug, atomizer assembly, exhaust ejector assembly, and muffler assembly.



ME 6115-320-34/3-18

Figure 3-18. Turbine assembly, removal, disassembly, reassembly and installation.



- 1 Shroud cracks
- 2 Vane cracks
- 3 Small crack concentration
- 4 Vane to shroud cracks
- 5 Nicks, cracks, or dents

ME 6115-320-34/3-19

Figure 3-19. Nozzle and shroud assembly inspection.

Section VII. REPAIR OF COMPRESSOR ASSEMBLY

3-16. Compressor Assembly and Inlet Plenum

a. General. The compressor is a two-stage, centrifugal type, with a compressor inlet plenum attached. The turbine assembly is mounted on the rear of the compressor assembly and the accessory drive assembly is mounted on the front end. Both the turbine assembly and the accessory drive assembly must be removed before the compressor assembly is accessible.

(1) *Compressor inlet plenum.* The compressor inlet plenum has a top opening, protected by a screen, for the air supply to the compressor. The compressor inlet plenum is fabricated from aluminum alloy sheets.

(2) *Compressor assembly.* Inlet air from the inlet plenum passes through the two stages of

compression and is discharged from the peripheral outlet into the turbine plenum. The compressor shaft is hollow with internal splines at the center. A splined quill shaft within the hollow shaft is used to connect the compressor to the turbine which drives it. The accessory drive is connected to the compressor by another splined quill shaft, mated to the hollow shaft.

b. Removal. Remove the compressor assembly and inlet plenum as follows:

(1) Remove the engine and generator assemblies as described in paragraph 2-9.

(2) Remove the accessory drive assembly as described in paragraph 3-17.

(3) Remove the compressor inlet plenum according to sequence of index numbers assigned to figure 3-20.

(4) If required for compressor assembly replacement, remove the turbine assembly as described in paragraph 3-15.


c. Cleaning and Inspection.

(1) Clean the compressor assembly and inlet plenum with cleaning solvent (FED. P-D-680) and dry thoroughly.

(2) Inspect for cracks, breaks, and other damage.

d. Repair. Repair the compressor inlet plenum by welding as shown in figure 3-21.

e. Installation. Install the compressor inlet plenum and compressor assembly in reverse order of removal procedure using figure 3-20 as a guide.




1. Lockwire
2. Bolt (4)
3. Washer (4)
4. Screw (24)
5. Washer (24)
6. Compressor inlet plenum assembly
7. Gasket
8. Preformed packing
9. Compressor assembly

NOTE: REPLACE PREFORMED PACKING (8) AND GASKET (7) WHENEVER PLENUM ASSEMBLY OR COMPRESSOR ASSEMBLY ARE REMOVED.

ME 6115-320-34/3-20

Figure 3-20. Compressor inlet plenum removal and installation.



1. Crack in welded seam
2. Crack in welded seam and adjoining material
3. Crack in material

NOTES:

- A. WELD PER TM 9-237.
- B. CLEAN AND REWELD ANY CRACK SUCH AS ITEM 1.
- C. CRACKS SUCH AS ITEM 2 AND 3 REQUIRE PATCHES.
- D. MINIMUM PATCH THICKNESS 0.023 INCH.
- E. DO NOT OVERLAP PATCHES.
- F. REMOVE ENOUGH MATERIAL TO ELIMINATE ALL TRACES OF CRACK.
- G. (ITEMS 1, 2, AND 3 ARE TYPICAL OF THE TYPES OF CRACKS, BUT DO NOT INDICATE LOCATIONS WHERE CRACKS MAY APPEAR.
- H. ALL PATCHES ARE TO BE WELDED ON OUTER SKIN.
- J. MATERIAL ALUMINUM ALLOY 6061-T4 PER SPECIFICATION QQ-A-327.

ME 6115-320-34/3-21

Figure 3-21. Compressor inlet plenum, exploded view.

Section VIII. REPAIR OF ACCESSORY DRIVE

3-17. Accessory Drive Assembly

a. General. The accessory drive assembly is mounted on the forward end of the compressor assembly and is designed as a separate assembly. The accessory drive assembly consists of an alloyed magnesium housing containing a gear reduction train to drive the fuel control unit, centrifugal switch assembly, cooling air fan assembly, oil pump assembly, tachometer-generator, and ac generator. The arrangement of the drive train is such that the starter motor assembly drives all accessories in

addition to driving the compressor, turbine and generator assemblies during the initial phase of starting.

b. Removal. To remove the accessory drive assembly, proceed as follows:

(1) Remove gas turbine engine and generator from enclosure (para 2-9).

(2) Remove ac generator from engine (para 10).

(3) Remove air inlet screen assembly (TM 6115-320-12).

(4) Remove and tag wiring harness, fuel lines, oil lines, and air lines as necessary.

(5) Remove starter motor assembly (TM 5-5115-320-12).

(6) Remove fuel control unit (para 3-5).

(7) Remove oil pump assembly (para 3-8).

(8) Remove oil cooler air duct (TM 5-6115-320-12).

(9) Remove accessory drive assembly according to sequence of index numbers assigned to figure 3-22.

c. Cleaning and Inspection.

(1) Remove all dust, dirt and foreign matter from the accessory drive assembly with clean, dry, compressed air.

(2) Clean the accessory drive assembly with cleaning solvent (FED. P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage, wear, stripped threads, or broken gear teeth. If defective, replace accessory drive assembly.

d. Repair. To repair the accessory assembly, refer to figure 3-23 and proceed as follows:

NOTE

Before performing the following step, check for an alignment scribe mark on nuts (1) and fan shaft. If necessary, rescribe mark for later assembly realignment.

(1) Remove nut (1) and washer (2).

(2) Attach Mechanical Fan Puller to fan assembly (3) with screws (10-24 x 1½ inch long) threaded into tapped holes in fan assembly. Tighten shaft of Mechanical Fan Puller to remove fan assembly.

(3) Remove bolts (4) and washers (5), then remove assembled parts (6 through 13).

(4) Remove bolts (6) and washers (7).

(5) Remove and replace housing (8) and plenum (9) as necessary.

(6) Remove retainer (10) and shim (11).

(7) Remove and replace preformed packing (12) and seal (13) using Seal Installing Holder.

(8) Remove lock key (14).

(9) Remove nut (15) using Wrench Adapter and Spanner Wrench.

(10) Remove lockwire (16).

(11) Remove screws (17) and washers (18).

(12) Remove retainer (19) and seal (20).

(13) Remove spacer (21), shims (22) and (23).

(14) Press seal (20) out of retainer (19) using Seal Driver and replace seal.

(15) Remove old cement from retainer (19) using methyl-ethyl-ketone (Federal Specification TT-M-261).

(16) Remove snap ring (24).

(17) Remove seal (25) by driving seal from oil pump side through fuel control unit side with Seal Driver. Replace seal as necessary.


(18) Assemble accessory drive assembly in reverse order of disassembly using figure 3-23 as a guide and observing the following:

(a) Cement seal (20) into retainer (19) using an approved clear cement (No. 1276 clear glyptal).

(b) Install shims (22) and (23) as required using figure 3-24 as a guide.


(c) Tighten nut (15) to a torque of 145-155 inch-pounds.

e. Installation. Install the accessory drive assembly in reverse order of removal procedure using figure 3-22 as a guide




ME 6115-320-34/3-22

Figure 3-22. Accessory drive assembly removal and installation.




ME 6115-320-34/3-23


Figure 3-23. Accessory drive assembly, exploded view.




1. INSPECT RETAINER TO BE SURE SEAL IS PROPERLY SEATED IN RETAINER.




2. MEASURE DISTANCE FROM FLANGE OF RETAINER TO TOP OF LIP OF RETAINER RECORD AS "A" DIMENSION (SEE STEP 6).




3. MEASURE DISTANCE FROM TOP OF LIP OF RETAINER TO FACE OF CARBON SEAL AND RECORD AS "B" DIMENSION. (SEE STEP 6) SUBTRACT "A" DIMENSION FROM "B" DIMENSION AND RECORD AS "C" DIMENSION.



4. MEASURE FROM SURFACE OF BEARING RETAINER AND RECORD AS "D" DIMENSION (SEE STEP 6) SUBTRACT "C" DIMENSION (STEP 5) FROM "D" DIMENSION. "D" DIMENSION MUST BE 0.030 TO 0.035 INCH GREATER THAN "C" DIMENSION (STEP 5). IF NECESSARY ADD SHIMS BETWEEN SEAL ROTOR AND BEARING TO OBTAIN THIS VALUE. INSTALL SHIMS IF REQUIRED.



5. MEASURE DISTANCE FROM OUTER FACE OF BEARING RETAINER TO BEARING RECORD AS DIMENSION "E". "A" DIMENSION OBTAINED IN STEP 2 MUST BE 0.000 TO 0.003 GREATER THAN "E" DIMENSION.



6. DIMENSIONS REQUIRED IN STEPS 2, 3, 4, 5.

ME 6115-320-34/3-24

Figure 3-24. Output shaft seal and bearing shim measurements.

Section IX. REPAIR OF SAFETY CONTROLS

3-18. Centrifugal Switch Assembly

a. *General.* The centrifugal switch assembly mounts on the right side of the accessory section housing adjacent to the oil pump assembly and is driven by the accessory section gear train. The self-

actuating and self-resetting centrifugal switch assembly is of the flyweight type and contains an input shaft, flyweights, fulcrum lever, actuator, push rods, bearings, springs, three micro switches, housing and cover. The function of the centrifugal

switch assembly is to control the sequence of operation of the electrical system components by movement of the flyweights in response to the speeds of the gas turbine engine. The flyweights cause a pushrod to exert force on a lever which contains two adjustable leaf springs and a button to operate each of the three switches. Three pushrods, each with an adjustment spring, oppose flyweight force against the lever to decrease the movement of the flyweights as necessary to actuate the switches in sequence. The switches actuate at approximately 35 percent, 95 percent and 110 percent speeds. The starter cutout (35 percent) switch controls the operation of the starter circuit to open the circuits when not required for operation of the power unit. The ready to load (95 percent) switch opens the ignition circuit to de-energize the igniter plug and allows closing of CB3. The overspeed shutdown (110 percent) switch functions to stop the gas turbine engine at overspeed conditions (refer to fig. 3-26).

b. Removal. To remove the centrifugal switch assembly, refer to figure 3-25 and proceed as follows:

- (1) Remove tachometer generator (para 3-22).
- (2) Remove electrical connector (1).
- (3) Remove screws (2, 3) and washers (4).
- (4) Separate upper half (5) of centrifugal switch assembly from lower half (10) of centrifugal switch assembly.

NOTE

Remove stud (6) and shims (7) from lower half of centrifugal switch assembly to prevent loss. Record quantity and thickness of shims (7) and exercise care to prevent loss of stud (6) or shims (7).

- (5) Remove screws (8) and washers (9).
- (6) Separate lower half of centrifugal switch assembly (10) from turbine engine.

NOTE

Do not replace either section of centrifugal switch assembly without replacing the other section.

c. Cleaning and Inspection.

(1) Remove all dust, dirt, and foreign matter from centrifugal switch assembly with clean, dry, compressed air.

(2) Clean the centrifugal switch assembly with a cloth moistened with cleaning solvent (FED. P-D-680), and dry thoroughly.

(3) Inspect for evidence of damage or excessive wear. If defective, replace centrifugal switch assembly.

d. Adjustment. The centrifugal switch assembly switch actuation points may be checked and adjusted without removal of the switch assembly from the gas turbine engine by connecting the Gas Turbine Engine Analyzer to the unit as described in

paragraph 2-2, and controlling engine operation as follows.

(1) Start the generator set (refer to TM 5-6115-320-12). Open the fuel by-pass valve (fig. 2-3) to by-pass fuel and control engine acceleration. Observe engine rpm on the Analyzer tachometer. Refer to figure 3-27 for Analyzer tachometer to engine rpm conversion data.

(2) Note that STARTER light (fig. 2-3) is extinguished at 1,465 to 1,545 rpm Analyzer tachometer indication indicating actuation of the starter cutout (35 percent) switch. If reading is outside these limits, remove cover plate (3, fig. 3-28) and rotate starter cutout switch adjustment screw (fig. 3-28) counterclockwise to decrease actuation point and clockwise to increase actuation point.

NOTE

Any change in the setting of the starter cutout switch will automatically change the settings of the ready-to-load (95 percent) and overspeed shutdown (110 percent) switches. The ready-to-load and overspeed shutdown switches must be readjusted whenever the starter cutout switch setting is changed.

(3) After satisfactory check or adjustment of starter cutout switch, increase engine rpm until 95 per cent RELAY light (fig. 2-3) illuminates. Note actuation rpm on Analyzer tachometer indicator and continue increasing engine rpm until Analyzer tachometer indicates approximately 4,100 rpm. Slowly open fuel by-pass valve (fig. 2-3) to decrease engine rpm, note Analyzer tachometer indication when 95 percent RELAY light is extinguished.

(4) Actuation point of ready-to-load (95 percent) switch on increasing rpm should be 4,030 rpm or less. Actuation point on decreasing rpm should be 3,818 to 3,918 rpm. If actuation point is outside these limits, turn ready-to-load switch adjustment screw (fig. 3-28) counterclockwise to decrease actuation point and clockwise to increase actuation point.

NOTE

Whenever the ready-to-load switch deceleration actuation point is set, the actuation point during acceleration is automatically set. Any change in the setting of the ready-to-load switch will change to setting of the overspeed shutdown switch but not the starter cutout switch. The overspeed shutdown switch must be adjusted if the ready-to-load switch is adjusted.

(5) After satisfactory check or adjustment of starter cutout and ready-to-load switches, gradually increase engine rpm to 4,580 rpm (Analyzer tachometer indicator) or the gas turbine engine shuts down automatically. Note analyzer tachometer indication at engine shutdown point.

CAUTION

Never allow the gas turbine engine to operate at an Analyzer tachometer reading above 4,592 rpm.

(6) Overspeed shutdown switch actuation should occur at 4,370 to 4,580 rpm. If switch actuation and engine shutdown does not occur within these limits, turn overspeed shutdown switch adjustment screw (fig. 3-28) counterclockwise to decrease actuation point and clockwise to increase actuation point.

NOTE


Changing the setting of the overspeed shutdown switch does not change the settings of the starter cutout or ready-to-load switches.

(7) After satisfactory check or adjustment of the centrifugal switch assembly, shutdown generator set and disconnect Gas Turbine Engine Analyzer.

d. *Repair.* Disassemble centrifugal switch assembly according to sequence of index numbers assigned to figure 3-29 to replace preformed packings. Assemble centrifugal switch assembly in reverse order of disassembly.

e. *Installation.* Install the centrifugal switch assembly in reverse order of removal procedure using figure 3-25 as a guide.

- | | |
|---|--|
| 1. Connector | 6. Stud |
| 2. Screw | 7. Shim |
| 3. Screw (2) | 8. Screw (4) |
| 4. Washer (3) | 9. Washer (3) |
| 5. Centrifugal switch assembly upper half | 10. Centrifugal switch assembly lower half |




NOTE: RECORD QUANTITY AND THICKNESS OF SHIMS (7) TO FACILITATE ASSEMBLY.

ME 6115-320-34/3-25


Figure 3-25. Centrifugal switch assembly removal and installation.

SWITCH ASSEMBLY SHAFT SPEED	CONDITION	STARTER CUTOUT SWITCH (35 PCT)	READY TO LOAD SWITCH (95 PCT)		OVERSPEED SHUTDOWN (110 PCT)
			A	B	
0 3,485 to 3,585 9,500 to 9,584 9,086 to 9,330 10,880 to 10,920	INCREASING INCREASING DECREASING INCREASING	CLOSED OPEN OPEN OPEN OPEN	OPEN OPEN CLOSED OPEN CLOSED	CLOSED CLOSED OPEN CLOSED OPEN	CLOSED CLOSED CLOSED CLOSED OPEN



ME 6115-320-34/3-26

Figure 3-26. Centrifugal switch assembly wiring diagram.



ME 6115-320-34/3-27

Figure 3-27. Conversion of tachometer indications to turbine rpm.





Figure 3-28. Centrifugal switch assembly adjusting screws.

CONNECTOR PREFORMED PACKING REPLACEMENT PROCEDURES

1. REMOVE FOUR SCREWS (1).
2. TAG AND UNSOLDER ELECTRICAL LEADS (3).
3. REMOVE RECEPTACLE (2).
4. REPLACE PREFORMED PACKING (4).
5. SOLDER ELECTRICAL LEADS.
6. REPLACE RECEPTACLE (2).
7. INSTALL AND TIGHTEN FOUR SCREWS (1).



CENTRIFUGAL SWITCH PREFORMED PACKING REPLACEMENT PROCEDURES

1. REMOVE THREE SCREWS (5) AND (6), AND WASHERS (7)
2. SEPARATE UPPER HALF (8) FROM LOWER HALF (12).
3. REMOVE STUD (9) AND SHIMS (10) TO PREVENT LOSS.
NOTE: RECORD QUANTITY AND THICKNESS OF SHIMS (10) FOR AID AT ASSEMBLY.
4. REPLACE PREFORMED PACKING (11).
5. INSTALL SAME QUANTITY AND THICKNESS OF SHIMS (10) AS REMOVED AND STUD (9).
6. REPLACE UPPER HALF (8) ON LOWER HALF (12).
7. INSTALL THREE WASHERS (7) AND SCREWS (5) AND (6) AND TIGHTEN.

ME 6115-320-34/3-29

Figure 3-29. Centrifugal switch assembly exploded view.

Figure 3-30. (This figure is not used).

Figure 3-31. (This figure is not used).

3-19. Thermocouple

a. *General.* The thermocouple is mounted on the left side of the turbine exhaust flange with a probe extending into the exhaust duct. The thermocouple senses exhaust gas temperatures and relays the reading electrically to the exhaust gas temperature

indicator. The thermocouple is a temperature sensing device consisting of two wires of dissimilar material fused together at one end and connected to separate terminals at the other end.

b. *Removal.* Refer to TM 5-6115-320-12 for thermocouple removal procedures.

c. Testing. Connect a multimeter to the two terminals of the thermocouple and check for continuity. If there is no continuity, replace the thermocouple. If there is continuity, test the thermocouple for an indication of $1,200^{\circ}\text{F} \pm 200^{\circ}\text{F}$ ($650^{\circ}\text{C} \pm 94^{\circ}\text{C}$) using a controlled heat source and a master gage. Replace a defective thermocouple.

d. Installation. Refer to TM 5-6115-320-12 for thermocouple installation.

3-20. Thermostatic Switch

a. General. The thermostatic switch is a temperature actuated electrical switch mounted on the bottom of the turbine exhaust flange with a probe extending into the exhaust duct. The thermostatic switch is provided for Sergeant Weapon System use only. When a temperature between $1,110^{\circ}\text{F}$ (599°C) and $1,160^{\circ}\text{F}$ (627°C) is reached the thermoswitch closes, which illuminates the TAIL TEMPERATURE lamp located on the remote control panel.

b. Removal. Remove thermostatic switch according to sequence of index numbers assigned to figure 3-32 observing the following:

(1) Remove muffler (TM 5-6115-320-12).

(2) Remove turbine access panel and tailpipe (TM 5-6115-320-12).

(3) Tag or otherwise identify all connectors to facilitate installation.

c. Cleaning and Inspection.


(1) Remove all dust, dirt, and foreign matter from thermostatic switch with clean dry compressed air.

(2) Clean thermostat switch with a cloth moistened with solvent (FED P-D-680) and dry thoroughly.


(3) Inspect for evidence of damage or excessive wear. If defective, replace thermostatic switch.

d. Testing. Test the thermostatic switch for continuity with a multimeter. Continuity should be indicated between terminals 1 and 2. No continuity should be indicated between terminals 1 and 3, and 2 and 3.

e. Installation. Install the thermostatic switch in reverse order of removal procedure using figure 3-32 as a guide. Use a new gasket (6) and coat threads of bolt (4) with approved high temperature compound.



- 1 Electrical connector
- 2 Nut (2)
- 3 Washer (2)
- 4 Bolt (2)
- 5 Thermostatic switch
- 6 Gasket
- 7 Mounting flange
- 8 Generator set enclosure (rear)



WIRING DIAGRAM

ME 6115-320-34/3-32

Figure 3-32. Thermostatic switch removal and installation.

3-21. Acceleration and Overtemperature Control Thermostat

a. Removal. Remove thermostat according to sequence of index numbers assigned to figure 3-33.

b. Cleaning and Inspection.

(1) Remove all dust, dirt and foreign matter from the thermostat with clean, dry, compressed air.


(2) Clean the thermostat in cleaning solvent (FED. P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage, corrosion, or stripped threads. If defective, replace thermostat.

c. Installation. Install the thermostat in reverse order of removal procedure using figure 3-33 as guide.

NOTE

Install the thermostat with one row of slots toward the rear of unit.



1. Lockwire
2. Control air tube assembly
3. Bolt (2)
4. Plate
5. Acceleration and overtemperature control thermostat

CAUTION: HOLD THERMOSTAT BY HEXAGON FITTING WHILE TIGHTENING OR LOOSENING "B" NUT ON TUBE ASSEMBLY.

ME 6115-320-34/3-33

Figure 3-33. Acceleration and overtemperature control and installation.

3-22. Engine Controls Instruments Panel Assembly

a. Removal. Remove engine controls instrument panel assembly as follows:

- (1) Tag and disconnect wiring harness electrical leads from panel assembly components.
- (2) Remove panel assembly by removing screws and washers attaching panel hinge to cabinet.

b. Cleaning and Inspection.

- (1) Clean the engine controls instrument panel assembly with a cloth moistened in solvent (FED P-D-680) and dry thoroughly.
- (2) Inspect for evidence of damage, loose terminals, stripped threads, corrosion or excessive wear of mating parts.

c. Repair. Refer to TM 5-6115-320-12 for individual component repair.

d. Installation. Install the engine controls in-

struments panel assembly in reversing order of removal.


3-23. Tachometer-Generator

a. Removal. Remove tachometer-generator according to sequence of index numbers assigned to figure 3-34.

b. Cleaning and Inspection.

- (1) Remove all dust, dirt and foreign matter from tachometer-generator with clean, dry compressed air.
- (2) Clean the tachometer-generator with a cloth moistened in cleaning solvent (FED. P-D-680) and dry thoroughly.
- (3) Inspect for evidence of damage of stripped threads. If defective, replace tachometer-generator.

c. Installation. Install tachometer-generator in reverse order of removal procedure using figure 3-34 as a guide.



ME 6115-320-34/3-34

Figure 3-34. Tachometer-generator removal and installation.

3-24. Fire Detectors

a. Removal. Remove fire detectors according to sequence of index numbers assigned to figure 3-35.

b. Cleaning and Inspection.

(1) Remove all dust and dirt from fire detectors with clean, dry compressed air.

(2) Clean the fire detector with a cloth moistened with cleaning solvent (FED P-D-680) and dry thoroughly.

(3) Inspect for evidence of damage or stripped threads. If defective, replace fire detector.

c. Testing. To test the fire detectors, proceed as follows:


(1) Remove the leads from the terminals of the fire detectors.

(2) Use a multimeter and test for continuity between the terminals of one of the fire detectors. If continuity is indicated, the fire detector is defective and must be replaced.

(3) Heat the fire detector to 450°F (232°C).

(4) If continuity is not indicated, the fire detector is defective and must be replaced.

d. Installation. Install the fire detectors in reverse order of removal procedure using figure 3-35 as a guide.



ME 6115-320-34/3-35

Figure 3-35. Fire detectors removal and installation.


3-25. Electrical Controls Instruments Panel Assembly

a. *Removal.* Remove electrical controls instruments panel assembly as follows:

- (1) Tag and disconnect wiring harness electrical leads from panel assembly components.
- (2) Remove panel assembly according to sequence of index numbers assigned to figure 3-36.

b. *Cleaning and Inspection.*

- (1) Clean the electrical controls instruments panel assembly with a cloth moistened in cleaning solvent (FED. P-D-680) and dry thoroughly.
- (2) Inspect for evidence of damage, loose terminals, stripped threads, corrosion or excessive wear of mating parts.



ME 6115-320-34/3-36

Figure 3-36. Control panel assembly removal and installation.

3-26. Electrical Controls and Instruments

a. Removal.

(1) To remove the wattmeter and thermal watt converter, refer to figure 3-37 and proceed as follows:

NOTE

Wattmeter and thermal watt converter must be replaced as a matched set.

- (a) Remove nuts (1) and washers (2).
- (b) Tag and disconnect electrical leads.
- (c) Remove nuts (3), screws (5), and washers (4).

(d) Remove wattmeter (6).

(e) Remove screws (7) and washers (8).

(f) Tag and disconnect electrical leads.

(g) Remove screws (9) and washers (10).

(h) Remove thermal watt converter (11).

(2) To remove the frequency meter and transducer, refer to figure 3-37 and proceed as follows:

NOTE

Frequency meter and transducer must be replaced as a matched set.

- (a) Remove nuts (12) and washers (13).

(b) Tag and disconnect electrical leads.
(c) Remove nuts (14), screws (16), and washers (15).

- (d) Remove frequency meter (17).
- (e) Remove screws (18) and washers (19).
- (f) Tag and disconnect electrical leads.
- (g) Remove screws (20) and washers (21).
- (h) Remove frequency transducer (22).

(3) To remove the voltage adjusting rheostat, refer to figure 3-37 and proceed as follows:

- (a) Remove screws (23).
- (b) Tag and disconnect electrical leads.
- (c) Remove nut (24) and washer (25).
- (d) Remove voltage adjusting rheostat (26).

(4) To remove the voltage droop potentiometer, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove nut (27) and washer (28).
- (c) Remove voltage droop potentiometer (29).

(5) To remove frequency droop potentiometer, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove nut (30) and washer (31).
- (c) Remove frequency droop potentiometer (32).

(6) To remove relays K2, K3, K4, K5, K8, K9, K12, K16, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect leads as necessary.
- (b) Remove applicable nuts (33), washers (34), and screws (35).
- (c) Remove relay K2 (36).
- (d) Remove relay K9 (37).
- (e) Remove relay K8 (38).
- (f) Remove relay K16 (39).
- (g) Remove relay K5 (40).
- (h) Remove relay K4 (41).
- (i) Remove relay K12 (42).
- (j) Remove relay K3 (43).

(7) To remove relays K6, K7 and K13, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove nuts (44) and washers (45).

(c) Remove relay K13 (46).

(d) Remove relay K6 (47).

(8) To remove relay K15, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove nuts (49), washers (50).
- (c) Remove relay K15 (51).

(9) To remove relay K11, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove screws (52) and washers (53).
- (c) Remove relay K11 (54).

(10) To remove relay K10, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove screws (55) and washers (56).
- (c) Remove relay K10 (57).

(11) To remove receptacle J1, refer to figure 3-37 and proceed as follows:

- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove nuts (58), washers (59), and screws (60).
- (c) Remove receptacle J1 (61).

(12) To remove receptacle J3, refer to figure 3-37 and proceed as follows:


- (a) Tag and disconnect electrical leads as necessary.
- (b) Remove nuts (62), washers (63), and screws (64).
- (c) Remove receptacle J3 (65).

b. Cleaning and Inspection.

(1) Clean all components with a cloth moistened in cleaning solvent (FED. P-D-680) and dry thoroughly.

(2) Inspect for evidence of damage, stripped threads, loose connections or pins, shorting, or cracks. Replace defective components.

c. Installation. Install the frequency meter and transducer, wattmeter and thermal watt converter, voltage adjusting rheostat, relays (K2 through K13, K15 and K16), and electrical equipment rack receptacle in reverse order of removal procedures using figure 3-37 as a guide.



ME 6115-320-34/3-37

Figure 3-37. Frequency meter and transducer, wattmeter and thermal watt converter, voltage adjusting rheostat, voltage and frequency droop potentiometer, relays (K2 through K13, K15, and K16) and electrical equipment rack receptacles removal and installation.

CHAPTER 4

REPAIR OF ELECTRICAL SYSTEM

Section I. REPAIR OF ELECTRIC GENERATOR

4-1. AC Generator

a. General. The ac generator is of brushless design in which the dc for the rotor is supplied through rectifying the ac in the exciter armature windings. The generator stator is wound for dual voltages of 120/208 and 240/416. As the generator is brought up to speed, the permanent magnet generator (PMG) begins to supply power to the voltage regulator. This power is then supplied to the exciter field windings. As the exciter armature conductors cut the magnetic field of the exciter stator, a voltage is induced in the armature. The ac output of this armature is then fed to the rectifiers which convert it to dc to feed the rotor windings of the alternator. The wound rotor of the alternator is essentially a rotating electro-magnet. As it rotates, the lines of force are cut by the coils in the alternator stator causing a voltage to build up. The regulator controls the excitation to the exciter field which controls the current feed to the rotor windings and the output of the generator.

b. On-Unit Test. To test the ac generator and components while they are in the unit, refer to figure 4-1 and proceed as follows:

- (1) Remove all connectors from generator.
- (2) Use an impedance bridge and check for 0.0220 to 0.0244 ohms between terminals T1 to T4, T2 to T5, T3 to T6, T7 to T10, T8 to T11, T9 to T12.
- (3) Use an impedance bridge to check for 13.2 to 14.7 ohms between terminals D and F.
- (4) Use an impedance bridge to check for 0.895 to 0.995 ohms between terminals A and B.
- (5) Reconnect leads to generator and install electrical connector.
- (6) Start generator set (refer to TM 5-6115-320-12), and run at governed speed.
- (7) Adjust generator for no load, 208 volts line-to-line (refer to TM 5-6115-320-12).
- (8) Use a multimeter set at the appropriate range to check for 0.75 ampere.
- (9) Disconnect V50A18 from TB4-4 and connect to the negative lead from the multimeter.
- (10) Connect the positive lead of multimeter to terminal 4 of TB4.
- (11) Current shall not exceed 0.750 ampere.
- (12) Adjust generator for full load, 208 volts line-to-line (refer to TM 5-6115-320-12).

(13) Use a multimeter set at the appropriate range to check for 1.3 amperes:

- (14) Connect multimeter as in step (9) and (10) above.
- (15) Current shall not exceed 1.3 amperes.
- (16) Shut down generator set (refer to TM 5-6115-320-12).

NOTE

The following test must be performed while the generator is at operating temperature, therefore perform steps (17 through 21) below immediately after shut down.

- (17) Disconnect all leads from generator.
- (18) Place one probe of an insulation tester on ground and the other to T1 of generator.
- (19) Set insulation tester for 500 v ac.
- (20) Energize insulation tester and observe indicator light on insulation tester for leakage indication.
- (21) Repeat test for T2, T3, T7 through T9, pins F and B of connector P7.

c. Removal. Remove ac generator as follows:

- (1) Remove engine and ac generator assemblies as described in paragraph 2-9.
- (2) Remove ac generator according to sequence of index numbers assigned to figure 2-5.

d. Cleaning and Inspection.

- (1) Clean the ac generator and components with a clean paint brush moistened in cleaning solvent (FED P-D-680). Dry the generator thoroughly.

CAUTION

Avoid harsh or brisk rubbing on varnished parts and do not soak components containing windings as solvents may tend to soften the varnish.

- (2) Visually inspect all parts for defects such as cracks, broken or loose connections, stripped threads, and excessive or abnormal wear.

e. Disassembly. Disassemble the ac generator according to sequence of index numbers assigned to figure 4-2.

NOTE


Disassemble the ac generator only to the extent required to replace a defective component.

f. Repair. To repair the ac generator, replace the

armature and rotor, stator, PMG rotor, and rectifiers if found defective when testing in paragraph *d* above. Replace defective exhaust air duct, bearings, shield pads, bearing supports, and inner shaft assembly if found defective in paragraph *b* above. For further instructions, refer to TM 5-764.


g. Reassembly. Reassemble the ac generator in reverse order of disassembly procedure using figure 4-1 as a guide.

h. Installation. Install ac generator in reverse order of removal procedure using figure 2-5 as a guide.



ME 6115-320-34/4-1

Figure 4-1. AC generator disassembly and reassembly.



ME 6115-320-34/4-2

Figure 4-2. AC generator testing, schematic wiring diagram.

Section II. REPAIR OF ELECTRICAL SYSTEM COMPONENTS

4-2. General

The electrical system components in this section consist of the voltage regulator assembly, load anticipator, terminal boards (TB4, TB7, and

TB8), current transformers, battery charger and wiring harness, voltage change panel generator set wiring harness, cubicle ac wiring harness, and cubicle dc wiring harness.

4-3. Voltage Regulator Assembly, Load Anticipator, and Terminal Boards (TB4, TB7, and TB8).

a. Removal.

(1) To remove the voltage regulator assembly, refer to figure 4-3 and proceed as follows:

- (a) Remove electrical connector (1).
- (b) Remove bolts (2) and washers (3).
- (c) Remove voltage regulator assembly (4).

(2) To remove the load anticipator, refer to figure 4-3 and proceed as follows:

- (a) Remove electrical connector (5).
- (b) Remove screws (6) and washers (7).
- (c) Remove load anticipator (8).

(3) To remove terminal board TB8, refer to figure 4-3 and proceed as follows:

- (a) Remove protective cover (9).
- (b) Tag and disconnect electrical leads to terminal posts.

- (c) Remove nuts (10) and washers (11).
- (d) Remove nuts (12) and screws (13).
- (e) Remove terminal board TB8 (14).

(4) To remove terminal board TB7, refer to figure 4-3 and proceed as follows:

- (a) Remove nuts (15) and washers (16).

(b) Tag and disconnect electrical leads to terminal posts.

(c) Remove screws (17), nuts (18), and washers (19).

(d) Remove terminal board TB7 (20).

(5) To remove terminal board TB4, refer to figure 4-3 and proceed as follows:

(a) Remove nuts (21) and washers (22).

(b) Tag and disconnect electrical leads to terminal posts.

(c) Remove bus bar (23) and washers (22).

(d) Remove nuts (24), washers (25), and screws (26).

(e) Remove terminal board TB4 (27).


b. Cleaning and Inspection.

(1) Clean the voltage regulator assembly, load anticipator, and terminal boards with a clean cloth moistened in cleaning solvent (Fed. Spec. O-T634B).

(2) Inspect for evidence of damage, stripped threads, loose connections or excessive wear.

(3) Replace a defective component.

c. Installation. Install the voltage regulator assembly, load anticipator, and terminal boards (TB4, TB7, and TB8) in reverse order of removal procedure using figure 4-3 as a guide.



- | | | | | | |
|---|--------------------------|----|--------------------|----|--------------------|
| 1 | Electrical connector | 10 | Nut (4) | 19 | Screw (5) |
| 2 | Screw (4) | 11 | Washer (8) | 20 | Terminal board TB7 |
| 3 | Washer (4) | 12 | Nut (2) | 21 | Nut (10) |
| 4 | Voltage regulator | 13 | Screw (2) | 22 | Washer (20) |
| 5 | Electrical connector (2) | 14 | Terminal board TB8 | 23 | Bus bar (2) |
| 6 | Screw (4) | 15 | Nut (4) | 24 | Nut (2) |
| 7 | Washer (4) | 16 | Washer (8) | 25 | Screw (2) |
| 8 | Load anticipator | 17 | Nut (5) | 26 | Washer (2) |
| 9 | Protective cover | 18 | Washer (5) | 27 | Terminal board TB4 |

ME 6115-320-34/4-3

Figure 4-3. Voltage regulator assembly, load anticipator, and terminal boards (TB4, TB7 and TB8) removal and installation.

4-4. Current Transformers

a. *Removal.* Remove current transformers according to sequence of index numbers assigned to figure 4-4.

b. *Cleaning and Inspection.*

(1) Clean the current transformers with a cloth moistened in cleaning solvent (Fed. Spec O-T634B) and dry thoroughly.

(2) Inspect for evidence of damage, shorting, loose connections, or excessive overheating. If defective, replace current transformer.

c. *Testing.*

(1) Connect an insulation tester to either terminal of transformer and mounting bracket, and apply 500 volts ac.

(2) Observe indicator lamp for indication of leakage.

(3) If insulation is defective, replace transformer.


(4) Connect a multimeter to terminals of transformer.

(5) Check transformer for continuity.

(6) If transformer is defective, replace transformer.

d. Installation.

(1) Install the current transformer in reverse order of removal procedure using figure 4-4 as a guide.



ME 6115-320-34/4-4

Figure 4-4. Current transformers removal and installation.

4-5. Battery Charger and 24 V DC Slave Receptacle

a. Removal. To remove the battery charger and 24v dc slave receptacle, refer to figure 4-5 and proceed as follows:

- (1) Remove electrical connector (1).
- (2) Remove screws (2) and washers (3).
- (3) Remove battery charger (4).
- (4) Remove nut (5), lock washer (6), and plain washer (7) from ground stud E2 (8).
- (5) Remove 24v dc slave receptacle electrical lead.
- (6) Remove nut (9), lockwasher (10), and plain washer (11) from terminal of start relay K1 (16).
- (7) Remove 24v dc slave receptacle electrical lead.
- (8) Remove screws (12).

(9) Remove 24v dc slave receptacle (13).

b. Cleaning and Inspection.

(1) Clean the battery charger and 24v dc slave receptacle with a cloth moistened in cleaning solvent (Fed Spec. O-T634B), and dry thoroughly.


(2) Inspect the electrical leads for evidence of damage, excessive wear, stripped threads or loose connector pins and terminals.

(3) Inspect the battery charger for evidence of damage, excessive wear, stripped threads or corrosion.

(4) Replace a defective 24v dc slave receptacle or battery charger.

c. Installation.

(1) Install the battery charger and 24v dc slave receptacle in reverse order of removal procedure using figure 4-5 as a guide.



ME 6115-320-34/4-5

Figure 4-5. Battery charger and 24 v dc slave receptacle removal and installation.

4-6. Overcurrent Relay (K14) and Main Circuit Breaker (CB3).

a. Removal. To remove overcurrent relay (K14) and main circuit breaker (CB3), refer to figure 4-6 and proceed as follows:

- (1) Remove electrical connector (1).
- (2) Remove nuts (2, 3, and 4).
- (3) Tag and remove electrical leads (5, 6, 7).

- (4) Remove nuts (8).
- (5) Remove bus bars (9).
- (6) Remove screws (10) and washers (11).
- (7) Remove main circuit breaker (12).
- (8) Remove screws (13) and washers (14).
- (9) Remove overcurrent relay (15).

b. Cleaning and Inspection.

- (1) Clean the overcurrent relay and main

circuit breaker with a cloth moistened in cleaning solvent (Fed. Spec O-T634B) and dry thoroughly.

(2) Inspect for evidence of damage, stripped threads, excessive wear or corrosion.

(3) Replace a defective overcurrent relay or main circuit breaker.

c. *Testing.* Overcurrent relay (K14) may be tested on unit by observing the following procedures.

WARNING

High voltages are present during the operation of the generator set. Death on contact may result if personnel fail to observe safety precautions. Be careful not to contact electrical connections when this equipment is operating. In case of accident from electrical shock, shut down the generator set at once. If the generator set cannot be shut down, free the victim from the live conductor with a board or any nonconductor. If the victim is unconscious, apply artificial respiration and get medical help.

(1) Connect a AN-2 size jumper wire from terminal L1 to terminal L2 of TB7, and secure firmly.

NOTE

Do not use a jumper wire larger than AN-2 size.

(2) Start generator set for multipurpose local operation in accordance with instructions outlined in TM 5-6115-320-12 and operate at governed speed.

CAUTION

While performing the next two steps be

ready to shut down the generator set as quickly as possible if MAIN CB CLOSURE lamp does not immediately extinguish. Extremely high current could cause extensive damage to the generator set electrical currents.

(3) Momentarily set MAIN CB circuit breaker switch in CLOSE position and observe that MAIN CB CLOSURE lamp illuminates, then immediately extinguishes.

NOTE

Since voltage to the filaments of MAIN CB CLOSURE lamp will be instantaneous (approximately two-tenths of one second) it will be necessary to observe MAIN CB CLOSURE lamp closely and while it is shaded from direct sun light.

(4) If MAIN CB CLOSURE lamp does not immediately extinguish, place MAIN CB circuit breaker switch in OPEN position.

NOTE


If MAIN CB CLOSURE lamp does not immediately extinguish after performing step four above, place MASTER switch in OFF position and allow generator set to come to a complete stop. Since the AN-2 size jumper wire will burn, it will act as a fuse when the current exceeds the tolerance of the overcurrent relay being tested.

(5) Remove jumper wire from terminals L1 and L2 of TB7.

(6) Replace a defective overcurrent relay.

d. *Installation.* Install overcurrent relay (K14) and main circuit (CB3) in reverse order of removal.

- | | |
|------------------------|-----------------------------|
| 1 Electrical connector | 9 Buss bar (3) |
| 2 Nut (3) | 10 Screw (4) |
| 3 Nut (3) | 11 Washer (4) |
| 4 Nut (3) | 12 Main circuit breaker CB3 |
| 5 Electrical leads (3) | 13 Screw (4) |
| 6 Electrical leads (3) | 14 Washer (4) |
| 7 Electrical leads (3) | 15 Overcurrent relay K14 |
| 8 Nut (3) | |



ME 6115-320-34/4-6

Figure 4-6. Overcurrent relay (K14) and main circuit breaker (CB3) removal and installation.

4-7. Voltage Change Panel Assembly

a. *Removal.* Remove voltage change panel assembly according to sequence of index numbers assigned to figure 4-7.


b. *Cleaning and Inspection.*

(1) Clean the voltage change panel assembly in

cleaning solvent (Fed. Spec. O-T634B) and dry thoroughly.

(2) Inspect for evidence of damage, cracks, corrosion or loose terminals.

(3) Replace a defective voltage change panel assembly in reverse order of removal procedure using figure 4-7 as a guide.



1. Nut (12)
2. Washer (12)
3. Voltage change panel assembly

ME 6115-320-34/4-7

Figure 4-7. Voltage change panel assembly removal and installation

Section III. REPAIR OF GENERATOR SET WIRING HARNESS

4-8. Generator Set Wiring Harness

a. *Removal.* To remove the generator set wiring harness, refer to figure FO-5 and proceed as follows:

- (1) Tag and disconnect all electrical leads.
- (2) Tag and disconnect all electrical connectors.

(3) Remove wiring harness noting location and position of attaching clamps and straps.

b. *Cleaning and Inspection.*

- (1) Clean the wiring harness with a clean cloth moistened in cleaning solvent (Fed. Spec. 0-T634B) and dry thoroughly.
- (2) Inspect for evidence of damage, excessive

wear, cracks, stripped threads or loose pins on connectors, or burned areas from shorting.

c. *Repair.* Refer to table 4-1 and replace defective wires.

Table 4-1. Generator set wiring harness wiring table

From	To	Wire no.	Wire size	Color	Length (in.)
B3-(minus)	TB3-11	Q2AM18N	18	Red	94
B5-(minus)	TB3-11	H2AL18N	18	Red	120
A8-1	J27-E	Q53A18	18	Red	
A8-2	A8-3	Q142A18	18	Red	
A8-3	A8-2	Q142A18	18	Red	
A8-4	CB4-1	Q131A18	18	Red	52
A8-5	TB3-11	Q2AN18N	18	Red	
C1-1	J19-1	X114B18C	18	White	
C2-1	K14-L1	X66E18A	18	White	30
C3-1	K14-L2	X67E18B	18	White	30
C4-1	K14-L3	X68F18C	18	White	30
CB1-1	TB9-4	P4B18	18	Red	
CB1-1	S2-B2	P4A18	18	Red	8
CB1-2	CB4-2	P31D12	12	Red	3
CB1-2	P3-s	P31B12	12	Red	
CB4-1	J27-D	Q131B18	18	Red	52
CB4-1	A8-4	Q131A18	18	Red	52
CB4-2	CB1-2	P31D12	12	Red	3
CB4-2	P12-I	P31C12	12	Red	49
CB4-2	M4+ (plus)	D31A12	12	Red	7
CT1-X1	P9-A	X79A18	18	White	36
CT1-X2	CT2-X2	X22N18N	18	White	6
CT2-X1	P9-E	X78A18	18	White	40
CT2-X2	CT3-X2	X22P18N	18	White	6
CT2-X2	CT1-X2	X22N18N	18	White	6
CT3-X1	P9-I	X77A18	18	White	44
CT3-X2	TB4-8	X22Q18N	18	White	34
CT3-X2	CT2-X2	X22P18N	18	White	6
CT4-X1	P1-Y	X52B18	18	White	45
CT4-X1	P11-H	X52A18	18	White	52
CT4-X2	P1-X	X51B18	18	White	45
CT4-X2	P11-R	X51A18	18	White	52
DX1-1	DS2-1	L3C18	18	Red	8
DX1-1	P3-T	L3B18	18	Red	45
DS1-2	DS2-2	L2R18N	18	Red	8
DS1-2	TB3-13	L2Q18N	18	Red	46
DS2-1	DS3-1	L3D18	18	Red	12
DS2-1	DS1-1	L3C18	18	Red	8
DS2-2	DS3-2	L2S18N	18	Red	12
DS2-2	DS1-2	L2R18N	18	Red	8
DS3-1	DS2-1	L3D18	18	Red	12
DS3-2	DS2-2	L2S18N	18	Red	12
E1	E2	P2AQ18N	8	Red	
E2	E1	P2AQ18N	8	Red	
E2	TB3-15	P2C8N	8	Red	68
F1-1	TB4-3	X39D12C	12	White	47
F1-2	J19-1	X114A12C	12	White	
J14-A	TB3-10	P105C18	18	Red	40
J14-B	TB3-9	P110E18	18	Red	39
J14-C	S2-A1	P7C18	18	Red	72
J14-D	TB3-4	P21E18	18	Red	34
J14-E	M6-1	P16G18	18	Red	68
J14-F	K14-A2	P10F18	18	Red	24
J14-G	P1-v	V101B18	18	White	58
J14-H	P1-H	V12B18	18	White	58
J14-J	TB4-2	V13D18	18	White	50
J14-K	TB3-6	P37D18	18	Red	36
J14-K	P1-L	V37B18	18	White	
J14-L	TB3-5	P36D18	18	Red	35
J14-L	TB4-9	V36C18	18	White	

Table 4-1. Generator set wiring harness wiring table—continued.

From	To	Wire no.	Wire size	Color	Length (in.)
J14-M	TB4-3	X39E18C	18	White	49
J14-N	P1-N	V95C18	18	White	58
J14-P	P1-D	X117B18	18	White	58
J14-R	P1-E	X116B18	18	White	58
J14-S	P1-F	X115B18	18	White	58
J14-T	P1-M	V58C18	18	White	58
J14-U	P10-L	X138A18	18	White	
J14-V	TB4-7	X22K18N	18	White	45
J19-1	C1-1	X114B18C	18	White	5
J19-1	F1-2	X114A12C	12	White	
J19-2	TB4-8	X22J12N	12	White	43
J25-E	TB3-7	P11C-8	18	Red	79
J25-F	TB3-9	L110D18	18	Red	86
J25-H	S2-A1	P7D18	18	Red	59
J25-J	TB3-10	P105D18	18	Red	87
J25-K	TB3-9	P110C18	18	Red	86
J25-L	P3-m	P121B18	18	Red	84
J25-M	P2-K	L124A18	18	Red	95
J25-N	P13-N	L125A18	18	Red	63
J25-P	P2-g	L123A18	18	Red	95
J25-R	P2-h	L122A18	18	Red	95
J25-S	J27-B	L126A18	18	Red	7
J25-T	TB9-1	L127G18			41
J25-X	TB3-12	P2L18N	18	Red	89
J27-A	TB3-2	Q9G18	18	Red	75
J27-B	J25-S	L126A18	18	Red	7
J27-C	TB3-12	Q2J18N	18	Red	85
J27-D	CB4-1	Q131B18	18	Red	52
J27-E	A8-1	Q43A18	18	Red	
J27-F	TB3-12	Q2K18N	18	Red	85
J27-G	P3-P	Q140A18	18	Red	
J27-H	P3-R	Q139A18	18	Red	
J29-A	K14-A1	Q9M18	18	Red	
J29-B	TB3-14	Q2AP18N	18	Red	
J29-C	TB9-4	L4C18	18	Red	
K1-A2	P13-L	K11B18	18	Red	19
K1-B2	M4—(minus)	D1C12	12	Red	57
K1-X1	M5-1	E8B18	18	Red	79
K1-X1	P2-B	K8A18	18	Red	51.5
K1-X2	TB3-14	P2G18N	18	Red	44
K1-11	P2-A	K7B18	18	Red	53.5
K1-11	S2-A1	P7A18	18	Red	76
K1-12	TB3-7	P11P18	18	Red	37.5
K14-A1	J29-A	Q9M18	18	Red	
K14-A1	TB3-1	P9A18	18	Red	48
K14-A2	J14-F	P10F18	18	Red	24
K14-A2	P13-B	P10E18	18	Red	21
K14-A2	P3-M	P10D18	18	Red	59
K14-L1	C2-1	X66E18A	18	White	30
K14-L2	C3-1	X67E19B	18	White	30
K14-L3	C4-1	X68F18C	18	White	30
K14-T1	P1-y	X32B18A	18	White	36
K14-T3	P1-K	X14B18C	18	White	38
M2-A1	P2-T	E83A-ALML			73
M4+ (plus)	CB4-2	D31A12	12	Red	7
M4— (minus)	K1-B2	D1C12	12	Red	57
M5-1	K1-X1	E8B18	18	Red	79
M6-1	J14-E	P16G18	18	Red	68
M6-1	TB3-3	E16E18	18	Red	87
M6-2	P24-C	E2V18N	18	Red	8
M6-2	TB3-13	E2T18N	18	Red	97
P1-A	P11-K	X120B18	18	White	23
P1-B	P11-L	X119B18	18	White	23
P1-B	P7-A	X55A18	18	White	34

Table 4-1. Generator set wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
P1-C	P11-S	X118B18	18	White	23
P1-D	J14-P	X117B18	18	White	58
P1-E	J14-R	X116B18	18	White	58
P1-F	J14-S	X115B18	18	White	58
P1-G	TB4-9	V36B18	18	White	
P1-H	J14-H	V12B18	18	White	58
P1-J	TB4-2	V13B18	18	White	29
P1-K	K14-T3	X14B18C	18	White	38
P1-L	J14-K	V37B18	18	White	
P1-M	J14-T	V58C18	18	White	58
P1-N	J14-N	V95C18	18	White	58
P1-O	TB5-7	X38C18A	18	White	52
P1-P	TB4-3	X39F18C	18	White	28
P1-Q	P11-D	V59B18	18	White	23
P1-R	P10-F	X107B18	18	White	52
P1-S	P10-C	X108B18	18	White	52
P1-T	P10-E	X109B18	18	White	52
P1-V	TB5-5	X48B18B	18	White	24
P1-W	P7-B	X57A18	18	White	34
P1-X	CT4-X2	X51B18	18	White	45
P1-Y	CT4-X1	X52B18	18	White	45
P1-Z	P11-B	X137A18	18	White	
P1-Z	P11-N	V53B18	18	White	23
P1-a	TB4-5	V54B18	18	White	26
P1-c	P11-A	X136A18	18	White	
P1-d	TB8-3	L63E18C	18	White	52
P1-e	TB8-1	L65E18A	18	White	49
P1-f	TB5-1	X66B18A	18	White	52.5
P1-g	TB5-2	X67B18B	18	White	49.5
P1-h	TB5-3	X68B18C	18	White	46.5
P1-j	P9-D	V72B18	18	White	46
P1-m	P9-J	V74B18	18	White	46
P1-n	P10-A	X91B18	18	White	52
P1-p	P10-B	X92B18	18	White	52
P1-q	P10-D	X93B18	18	White	52
P1-r	TB5-8	X47D18B	18	White	57
P1-u	TB4-6	X22L12N	12	White	25
P1-v	J14-G	V101B18	18	White	58
P1-w	P11-E	V60A18	18	White	23
P1-y	K14-T1	X32B18A	18	White	36
P1-z	P9-H	V73B18	18	White	46
P2-A	K1-11	K7B18	18	Red	53.5
P2-B	K1-X1	K8A18	18	Red	51.5
P2-C	P3-n	K102B18	18	Red	48
P2-D	TB3-3	K16F18	18	Red	35
P2-F	P24-A	E85A18	18	Red	75
P2-G	P24-B	E84A18	18	Red	75
P2-H	P3-J	K100B18	18	Red	48
P2-J	P3-K	K17E18	18	Red	48
P2-K	J25-M	L124A18	18	Red	95
P2-L	P10-H	X86A18	18	White	73
P2-M	P10-G	X89A18	18	White	73
P2-N	P10-J	X87A18	18	White	73
P2-P	P10-I	X88A18	18	White	73
P2-R	TB3-2	K9F18	18	Red	33
P2-S	R12-CR	E82A-CHROM			73
P2-T	M2-AL	E83A-ALML			73
P2-V	TB3-1	K9D18	18	Red	32
P2-W	TB3-7	K11A18	18	Red	38
P2-X	P3-S	K30A18	18	Red	48
P2-Z	TB3-13	P2N18N	18	Red	45
P2-a	P3-c	Q15C18	18	Red	48
P2-f	TB3-2	K9E18	18	Red	33

Table 4-1. Generator set wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
P2-g	J25-P	L123A18	18	Red	95
P2-h	J25-R	L122A18	18	Red	95
P2-v	93-h	K24B18	18	Red	48
P3-A	TB3-1	P9B18	18	Red	26.5
P3-C	S2-B1	P5A18	18	Red	98
P3-D	P8-F	H41D18	18	Red	49
P3-E	TB3-3	P16D18	18	Red	28.5
P3-G	S2-A2	P6D18	18	Red	98
P3-H	P8-E	L46A18	18	Red	49
P3-J	P2-H	K100B18	18	Red	48
P3-K	P2-J	K17E18	18	Red	48
P3-L	TB3-7	K11D18	18	Red	32.5
P3-M	K14-A2	P10D18	18	Red	59
P3-N	TB3-10	P105B18	18	Red	35.5
P3-P	J27-G	Q140A18	18	Red	
P3-R	J27-H	Q139A18	18	Red	
P3-S	P2-X	K30A18	18	Red	48
P3-T	DS1-1	L3B18	18	Red	45
P3-U	TB3-4	P21C18	18	Red	29.5
P3-V	TB3-12	P2H12N	12	Red	37.5
P3-W	P8-A	H42B12	12	Red	49
P3-X	P17-A	H111B18	18	Red	120
P3-Z	P17-C	H112B18	18	Red	120
P3-a	S2-B2	P4D18	18	Red	98
P3-b	P13-M	L26B18	18	Red	34
P3-c	P2-a	Q15C18	18	Red	48
P3-d	P13-T	P129B18	18	Red	34
P3-e	P13-U	P130B18	18	Red	34
P3-g	P17-D	H40D18	18	Red	120
P3-h	P2-v	K24B18	18	Red	48
P3-j	TB3-9	P110B18	18	Red	34.5
P3-m	J25-L	P121B18	18	Red	84
P3-n	P2-C	K102B18	18	Red	48
P3-p	P12-D	P106B18	18	Red	71
P3-r	TB9-1	W127B18			31
P3-s	CB1-2	P31B12	12	Red	
P7-A	P1-B	X55A18	18	White	34
P7-B	P1-W	X57A18	18	White	34
P7-C	P11-C	X56A18	18	White	34
P7-D	TB4-5	V54D18	18	White	22
P7-D	P11-M	V54A18	18	White	35
P7-F	TB4-4	V50A18	18	White	23
P8-A	P3-W	H42B12	12	Red	49
P8-B	P8-G	H44B18	18	Red	8.0
P8-B	P21-A	H44A18	18	Red	150
P8-D	TB3-11	H2D12N	12	Red	49
P8-E	P3-H	L46A18	18	Red	49
P8-F	P3-D	H41D18	18	Red	49
P8-G	P8-B	H44B18	18	Red	8.0
P9-A	CT1-X1	X79A18	18	White	36
P9-B	TB4-6	X22R18N	18	White	35
P9-C	TB5-7	X38B18A	18	White	59
P9-D	P1-j	V72B18	18	White	46
P9-E	CT2-X1	X78A18	18	White	40
P9-F	TB5-8	X47C18B	18	White	47
P9-G	TB5-9	X39B18C	18	White	44
P9-H	P1-z	V73B18	18	White	46
P9-I	CT3-X1	X77A18	18	White	44
P9-J	P1-m	V74B18	18	White	46
P10-A	P1-n	X91B18	18	White	52
P10-B	P1-p	X92B18	18	White	52
P10-C	P1-S	X108B18	18	White	52
P10-D	P1-q	X93B18	18	White	52
P10-E	P1-T	X109B18	18	White	52

Table 4-1. Generator set wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
P10-F	P1-R	X107B18	18	White	52
P10-G	P2-M	X89A18	18	White	73
P10-H	P2-L	X86A18	18	White	73
P10-I	P2-P	X88A18	18	White	73
P10-J	P2-N	X87A18	18	White	73
P10-K	TB4-6	X22AK18N	18	White	
P10-L	J14-U	X138A18	18	White	
P10-M	TB4-9	V36A18	18	White	
P11-A	P1-c	X136A18	18	White	
P11-B	P1-z	X137A18	18	White	
P11-C	P7-C	X56A18	18	White	34
P11-D	P1-Q	V59B18	18	White	23
P11-E	P1-w	V60A18	18	White	23
P11-F	TB4-2	V13C18	18	White	38
P11-G	TB4-4	V50B18	18	White	36
P11-H	CT4-X1	X52A18	18	White	52
P11-J	TB4-6	X22S18N	18	White	34
P11-K	P1-A	X120B18	18	White	23
P11-L	P1-B	X119B18	18	White	23
P11-M	P7-D	V54A18	18	White	35
P11-N	P1-Z	V53B18	18	White	23
P11-N	TB4-4	V50C18	18	White	27
P11-R	CT4-X2	X51A18	18	White	52
P11-S	P1-C	X118B18	18	White	23
P12-C	TB5-9	X39M18C	18	White	53
P12-D	P3-p	P106B18	18	Red	71
P12-E	TB4-7	X22AJ18N	18	White	
P12-H	TB3-14	P2F12N	12	Red	52
P12-I	CB4-2	P31C12	12	Red	49
P13-A	TB3-4	P21D18	18	Red	27
P13-B	K14-A2	P10E18	18	Red	21
P13-C	TB3-13	P2P18N	18	Red	36
P13-L	K1-A2	K11B18	18	Red	19
P13-M	P3-b	L26B18	18	Red	34
P13-N	J25-N	L125A18	18	Red	63
P13-R	TB3-2	P9H18	18	Red	25
P13-T	P3-d	P129B18	18	Red	34
P13-U	P3-e	P130B18	18	Red	34
P17-A	P3-X	H111B18	18	Red	120
P17-B	TB3-14	H2E18N	18	Red	96
P17-C	P3-Z	H112B18	18	Red	120
P17-D	P3-g	H40D18	18	Red	120
P20-A	TB3-1	Q9C18	18	Red	84
P21-A	P8-B	H44A18	18	Red	150
P24-A	P2-F	E85A18	18	Red	75
P24-B	P2-G	E84A18	18	Red	75
P24-C	M6-2	E2V18N	18	Red	8
R12-CR	P2-S	E82A-CHROM			73
S2-A1	J25-H	P7-D18	18	Red	59
S2-A1	J14-C	P7-C18	18	Red	72
S2-A1	K1-11	P7-A18	18	Red	76
S2-A2	P3-G	P6D18	18	Red	98
S2-B1	P3-C	P5A18	18	Red	98
S2-B2	P3-a	P4D18	18	Red	98
S2-B2	CB-1	P4A18	18	Red	8
TB3-1	P2V	K9D18	18	Red	32
TB3-1	P20-A	Q9C18	18	Red	84
TB3-1	P3-A	P9B18	18	Red	26.5
TB3-1	K14-A1	P9A18	18	Red	48
TB3-2	P13-R	P9H18	18	Red	25
TB3-2	J27-A	Q9G18	18	Red	75
TB3-2	P2-R	K9F18	18	Red	33
TB3-2	P2-f	K9E18	18	Red	33
TB3-3	P2-D	K16F18	18	Red	35

Table 4-1. Generator set wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
TB3-3	M6-1	E16E18	18	Red	87
TB3-3	P3-E	P16D18	18	Red	28.5
TB3-4	J14-D	P21E18	18	Red	34
TB3-4	P13-A	P21D18	18	Red	27
TB3-4	P3-U	P21C18	18	Red	29.5
TB3-5	J14-L	P36D18	18	Red	35
TB3-6	J14-K	P37D18	18	Red	36
TB3-7	K1-12	P11P19	18	Red	37.5
TB3-7	P3-L	K11D18	18	Red	32.5
TB3-7	J25-E	P11C18	18	Red	79
TB3-7	P2-W	K11A18	18	Red	
TB3-9	J14-B	P110E18	18	Red	39
TB3-9	J25-F	L110D18	18	Red	86
TB3-9	J25-K	P110C18	18	Red	86
TB3-9	P3-j	P110B18	18	Red	34.5
TB3-10	J25-J	P105D18	18	Red	87
TB3-10	J14-A	P105C18	18	Red	40
TB3-10	P3-N	P105B18	18	Red	35.5
TB3-11	A8-5	Q2AN18N	18	Red	
TB3-11	B3— (minus)	Q2AM18N	18	Red	94
TB3-11	B5— (minus)	H2AL18N	18	Red	120
TB3-11	P8-D	H2D12N	12	Red	49
TB3-12	J27-F	Q2K18N	18	Red	85
TB3-12	J25-X	P2L18N	18	Red	89
TB3-12	J27-C	Q2J18N	18	Red	85
TB3-12	P3-V	P2H12N	12	Red	37.5
TB3-13	M6-2	E2T18N	18	Red	97
TB3-13	DS1-2	L2Q18N	18	Red	46
TB3-13	P13-C	P2P18N	18	Red	36
TB3-13	P2-Z	P2N18N	18	Red	45
TB3-14	J29-B	Q2AP18N	18	Red	
TB3-14	K1-X2	P2G18N	18	Red	44
TB3-14	P12-H	P2F12N	12	Red	52
TB3-14	P17-B	H2E18N	18	Red	96
TB3-15	E2	P2C8N	8	Red	68
TB4-2	J14-J	V13D18	18	White	50
TB4-2	P11-F	V13C18	18	White	38
TB4-2	P1-J	V13B18	18	White	29
TB4-3	P1-P	X39F18C	18	White	28
TB4-3	J14-M	X39E18C	18	White	49
TB4-3	F1-1	X39D12C	12	White	47
TB4-3	TB5-9	X39C12C	12	White	37
TB4-4	P11-N	V50C18	18	White	27
TB4-4	P11-G	V50B18	18	White	36
TB4-4	P7-F	V50A18	18	White	23
TB4-5	P7-D	V54D18	18	White	22
TB4-5	P1-a	V54B18	18	White	26
TB4-6	P10-K	X22AK18N	18	White	
TB4-6	P11-J	X22S18N	18	White	34
TB4-6	P9-B	X22R18N	18	White	35
TB4-6	P1-u	X22L12N	12	White	25
TB4-7	P12-E	X22AJ18N	18	White	
TB4-7	TB4-12	X22M12N	12	White	36
TB4-7	J14-V	X22K18N	18	White	45
TB4-8	CT3-X2	X22Q18N	18	White	34
TB4-8	J19-2	X22J12N	12	White	43
TB4-9	J14-L	V36C18	18	White	
TB4-9	P1-G	V36B18	18	White	
TB4-9	P10-M	V36A18	18	White	
TB5-1	P1-f	X66B18A	18	White	52.5
TB5-2	P1-g	X67B18B	18	White	49.5
TB5-3	P1-h	X68B18C	18	White	46.5
TB5-5	P1-V	X48B18B	18	White	24
TB5-7	P1-O	X38C18A	18	White	52

Table 4-1. Generator set wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
TB5-7	P9-C	X38B18A	18	White	59
TB5-8	P1-r	X47D18B	18	White	57
TB5-8	P9-F	X47C18B	18	White	47
TB5-9	P12-C	X39M18C	18	White	53
TB5-9	TB4-3	X39C12C	12	White	37
TB5-9	P9-G	X39B18C	18	White	44
TB5-12	TB4-7	X22M12N	12	White	36
TB8-1	P1-e	L65E18A	18	White	49
TB8-3	P1-d	L63E18C	18	White	52
TB9-1	J25-T	L127G18			41
TB9-1	TC1-2	W127C18			26
TB9-1	P3-r	W127B18			31
TB9-2	TC4-2	W127F18			66
TB9-2	TC3-2	W127E18			58
TB9-2	TC2-2	W127D18			36
TB9-4	J29-C	L4C18	18	Red	
TB9-4	CB1-1	P4B18	18	Red	
TB9-4	TC2-1	W4P18			39
TB9-4	TC1-1	W4N18			23
TB9-5	TC4-1	W4R18			69
TB9-5	TC3-1	W4Q18			61
TC1-1	TB9-4	W4N18			23
TC1-2	TB9-1	W127C18			26
TC2-1	TB9-4	W4P18			39
TC2-2	TB9-2	W127D18			36
TC3-1	TB9-5	W4Q18			61
TC3-2	TB9-2	W127E18			58
TC4-1	TB9-5	W4R18			69
TC4-2	TB9-2	W127F18			66

d. *Installation.* Install the generator wiring harness in reverse order of removal procedure using figure FO-5 as a guide.

4-9. Cubicle AC Wiring Harness

a. *Removal.* To remove the cubicle ac wiring harness, refer to figure 4-8 and proceed as follows:

- (1) Tag and disconnect all electrical leads.
- (2) Tag and disconnect all electrical connectors.

(3) Remove wiring harness noting location and position of attaching clamps and straps.

b. *Cleaning and Inspection.*

(1) Clean the wiring harness with a clean cloth moistened in an approved cleaning solvent and dry thoroughly.

(2) Inspect for evidence of damage, excessive wear, cracks, stripped threads or loose pins on connectors, or burned areas from shorting.

c. *Repair.* Refer to table 4-2 and replace defective wires.

Table 4-2. Cubicle AC wiring harness wiring table

From	To	Wire no.	Wire size	Color	Length (in.)
A2+ (plus)	M10+ (plus)	D75A18	18	White	52
A2- (minus)	M10- (minus)	D76A18	18	White	52
A2-L1	S11-1	X71A18	18	White	51
A2-L2	S11-2	X69A18B	18	White	50
A2-L3	S11-8	S70A18	18	White	47
A2-N1	A2-N2	X22V18N	18	White	4
A2-N1	K11-N	X22X18N	18	White	16
A2-N2	A2-N3	X11W18N	18	White	4
A2-N2	A2-N1	X22V18N	18	White	4
A2-N3	A2-N2	X22W18N	18	White	4

Table 4-2. Cubicle AC wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
A2-S1	J1-j	V72A18	18	White	25
A2-S2	J1-z	V73A18	18	White	24
A2-S3	J1-m	V74A18	18	White	23
A2-V1	K10-L1	X38F18A	18	White	15
A2-V1	MT-1	X38E18A	18	White	31
A2-V2	K10-L2	X47F18B	18	White	15
A2-V2	J1-r	X47E18B	18	White	23
A2-V3	K10-L3	X39H18C	18	White	15
A2-V3	J1-P	X39G18C	18	White	36
DS7-1	R2-2	L62A18C	18	White	16
DS7-2	J1-d	L63F18C	18	White	44
DS8-1	R4-2	L96A18A	18	White	9
DS8-2	J1-e	L65F18A	18	White	33
J1-A	R9-1	X120A18	18	White	18
J1-B	E10-1	X119A18	18	White	18
J1-C	R11-1	X118A18	18	White	18
J1-D	K16-A1	X117A18	18	White	26
J1-E	K16-B1	X116A18	18	White	23
J1-F	K16-C1	X115A18	18	White	23
J1-G	R8-CCW	V36D18	18	White	
J1-H	S3-9	V12A18	18	White	35
J1-J	R1-CW	V13A18	18	White	38
J1-K	S12-1	X14C18C	18	White	45
J1-L	R8-S	V37A18	18	White	
J1-M	R1-CCW	V58B18	18	White	
J1-N	R1-S	V95B18	18	White	36
J1-O	MT-1	X38D18A	18	White	19
J1-P	A2-V3	X39G18C	18	White	36
J1-Q	S3-11	V59A18	18	White	33
J1-R	S12-12	X107A18	18	White	43
J1-S	S12-14	S108A18	18	White	44
J1-T	S12-13	X109A18	18	White	43
J1-V	K7-X1	X48C18B	18	White	21
J1-W	K12-A2	X57B18	18	White	
J1-X	S12-8	X51C18	18	White	45
J1-Y	S12-7	X52C18	18	White	45
J1-Z	K12-A3	X137B18	18	White	
J1-b	K12-C2	X55B18	18	White	
J1-c	K12-C3	X136B18	18	White	
J1-d	DS7-2	L63F18C	18	White	44
J1-e	DS8-2	L65F18A	18	White	33
J1-f	S11-A	X66C18A	18	White	34
J1-g	S11-B	X67C18B	18	White	34
J1-h	S11-C	X68C18C	18	White	39
J1-j	A2-S1	V72A18	18	White	25
J1-m	A2-S3	V74A18	18	White	23
J1-n	R6-CCW	X91A18	18	White	8
J1-p	R6-S	X92A18	18	White	8.5
J1-q	R6-CW	X93A18	18	White	9
J1-r	A2-V2	X47E18B	18	White	23
J1-u	TB1-6	X22T12N	12	White	18
J1-v	S3-12	V101A18	18	White	35
J1-w	S3-8	V60B18	18	White	33
J1-y	S12-6	X32C18A	18	White	43
J1-z	A2-S2	V73A18	18	White	24
K7-A2	S12-5	X94B18A	18	White	52
K7-A3	R5-2	X64B18A	18	White	43
K7-B2	S12-3	X90A18C	18	White	50
K7-B3	R3-2	X61B18C	18	White	40
K7-X1	J1-V	X48C18B	18	White	21
K7-X2	MT-2	X22Z18N	18	White	10
K10-L1	K11-L1	X38G18A	18	White	22
K10-L1	A2-V1	X38F18A	18	White	15
K10-L2	K11-L2	X47G18B	18	White	14

Table 4-2. Cubicle AC wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
K10-L2	A2-V2	X47F18B	18	White	15
K10-L3	K11-L3	X39J18C	18	White	14
K10-L3	A2-V3	X39H18C	18	White	15
K11-L1	K10-L1	X38G18A	18	White	22
K11-L1	R9-2	X38H18A	18	White	30
K11-L2	R10-2	X47H18B	18	White	30
K11-L2	K10-L2	X47G18B	18	White	14
K11-L3	R11-2	X39K18C	18	White	30
K11-L3	K10-L3	X39J18C	18	White	14
K11-N	A2-N1	X22X18N	18	White	16
K11-N	TB1-6	X22U18N	18	White	23
K12-A2	J1-W	X57B18	18	White	
K12-A3	J1-Z	X137B18	18	White	
K12-C2	J1-b	X55B18	18	White	
K12-C3	J1-c	X136B18	18	White	
K16-A1	J1-D	X117A18	18	White	23
K16-A2	R9-1	X120C18	18	White	8
K16-A3	R9-2	X38J18A	18	White	8
K16-B1	J1-E	X116A18	18	White	23
K16-B2	R10-1	X119C18	18	White	8
K16-B3	R10-2	X47B18B	18	White	8
K16-C1	J1-F	X115A18	18	White	23
K16-C2	R11-1	X118C18	18	White	8
K16-C3	R11-2	X39L18C	18	White	8
M7-1	S11-H	D98A18	18	White	7
M7-2	S11-D	D97A18	18	White	6
M8+ (plus)	MT+ (plus)	D81A18	18	White	44
M8- (minus)	MT- (minus)	D80A18	18	White	44
M9-1	S11-4	D103A18	18	White	8
M9-2	S11-N	D22AD18N	18	White	8
M9-2	S12-15	X22AC18N	18	White	21
M10+ (plus)	A2+ (plus)	D75A18	18	White	52
M10- (minus)	A2- (minus)	D76A18	18	White	52
MT+ (plus)	M8+ (plus)	D81A18	18	White	44
MT- (minus)	M8- (minus)	D80A18	18	White	44
MT-1	A2-V1	X38E18A	18	White	31
MT-1	J1-O	X38D18A	18	White	19
MT-2	K7-X2	X22Z18N	18	White	10
MT-2	TB1-6	X22Y18N	18	White	7
R1-S	J1-N	V95B18	18	White	36
R1-S	S3-7	V95A18	18	White	12
R1-CW	J1-J	V13A18	18	White	38
R1-CCW	J1-M	V58B18	18	White	36
R1-CCW	S3-10	V58A18	18	White	13
R2-1	R3-2	X61A18C	18	White	3
R2-2	DS7-1	L62A18C	18	White	16
R3-1	S12-3	X90B18C	18	White	12
R3-2	R2-1	X61A18C	18	White	3
R3-2	K7-B3	X61B18C	18	White	40
R4-1	R5-2	X64A18A	18	White	3
R4-2	DS8-1	L96A18A	18	White	9
R5-1	S12-5	S94A18A	18	White	14
R5-2	R4-1	X64A18A	18	White	3
R5-2	K7-A3	X64B18A	18	White	43
R6-S	J1-p	X92A18	18	White	8.5
R6-CW	J1-q	X93A18	18	White	9
R6-CCW	J1-n	X91A18	18	White	8
R7-S	R7-CCW	X52D18	18	White	3
R7-CW	S12-8	X51D18	18	White	45
R7-CCW	R7-S	X52D18	18	White	3
R7-CCW	S12-7	X52E18	18	White	45
R8-S	J1-L	V37A18	18	White	
R8-CW	TB1-6	X22AL18N	18	White	
R8-CCW	J1-G	V36D18	18	White	


Table 4-2. Cubicle AC wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
R9-1	K16-A2	X120C18	18	White	8
R9-1	J1-A	X120A18	18	White	18
R9-2	K16-A3	X38J18A	18	White	8
R9-2	K11-L1	X38H18A	18	White	30
R10-1	K16-B2	X119C18	18	White	8
R10-1	J1-B	X119A18	18	White	18
R10-2	K16-B3	X47B18B	18	White	8
R10-2	K11-L2	X47H18B	18	White	30
R11-1	K16-C2	X118C18	18	White	8
R11-1	J1-C	X118A18	18	White	18
R11-2	K16-3C	X39L18C	18	White	8
R11-2	K11-L3	X39K18C	18	White	30
S3-7	R1-S	V95A18	18	White	12
S3-8	J1-w	V60B18	18	White	33
S3-9	J1-H	V12A18	18	White	35
S3-10	R1-CCW	V58A18	18	White	13
S3-11	J1-Q	V59A18	18	White	33
S3-12	J1-v	V101A18	18	White	35
S11-A	S11-G	X66D18A	18	White	8
S11-A	J1-f	X66C18A	18	White	34
S11-B	S11-E	X67D18B	18	White	4
S11-B	J1-g	X67C18B	18	White	34
S11-C	S11-F	X68D18C	18	White	8
S11-C	J1-h	X68C18C	18	White	39
S11-D	M7-2	D97A18	18	White	6
S11-E	S11-B	X67D18B	18	White	4
S11-F	S11-C	X68D18C	18	White	8
S11-F	S11-K	X68E18C	18	White	6
S11-G	S11-A	X66D18A	18	White	8
S11-H	M7-1	D98A18	18	White	7
S11-K	S11-F	X68E18C	18	White	6
S11-N	S11-9	X22AE18N	18	White	6
S11-N	M9-2	D22AD18N	18	White	8
S11-1	S11-6	X71B18	18	White	4
S11-1	A2-L1	X71A18	18	White	51
S11-2	S11-7	X69B18B	18	White	3
S11-2	A2-L2	X69A18B	18	White	50
S11-3	S11-8	X70B18	18	White	3
S11-4	M9-1	D103A18	18	White	8
S11-5	S11-9	X22AF18N	18	White	3
S11-6	S11-1	X71B18	18	White	4
S11-7	S11-2	X69B18B	18	White	3
S11-8	S11-3	X70B18	18	White	3
S11-8	A2-L3	X70A18	18	White	47
S11-9	S11-N	X22AE18N	18	White	6
S11-9	S11-5	X22AF18N	18	White	3
S12-1	J1-K	X14C18C	18	White	45
S12-3	R3-1	X90B18C	18	White	12
S12-3	K7-B2	X90A18C	18	White	50
S12-5	K7-A2	C94B18A	18	White	52
S12-5	R5-1	X94A18A	18	White	14
S12-6	J1-y	X32C18A	18	White	43
S12-7	R7-CCW	X52E18	18	White	45
S12-7	J1-Y	X52C18	18	White	45
S12-8	R7-CW	X51D18	18	White	45
S12-8	J1-X	X51C18	18	White	45
S12-10	S12-15	X22AB18N	18	White	4
S12-10	TB1-6	X22AA18N	18	White	47
S12-12	J1-R	X107A18	18	White	43
S12-13	J1-T	X119A18	18	White	43
S12-14	J1-S	X108A18	18	White	44
S12-15	S12-10	X22AB18N	18	White	4
S12-15	M9-2	X22AC18N	18	White	21
TB1-6	R8-CW	X22AL18N	18	White	

Table 4-2. Cubicle AC wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
TB1-6	S12-10	X22AA18N	18	White	47
TB1-6	MT-2	X22Y18N	18	White	7
TB1-6	K11-N	X22U18N	18	White	23
TB1-6	J1-u	X22T12N	18	White	18

d. Installation. Install the cubicle ac wiring harness in reverse order of removal procedure using figure 4-8 as a guide.



ME 6115-320-34/4-8

Figure 4-8. Cubicle AC wiring harness.

4-10. Cubicle DC Wiring Harness

a. Removal. To remove the cubicle dc wiring harness, refer to figure 4-9 and proceed as follows:

- (1) Tag and disconnect all electrical leads.
- (2) Tag and disconnect all electrical connectors.
- (3) Remove wiring harness noting location and position of attaching clamps and straps.

b. Cleaning and Inspection.

(1) Clean the wiring harness with a clean cloth moistened in an approved cleaning solvent and dry thoroughly.

(2) Inspect for evidence of damage, excessive wear, cracks, stripped threads or loose pins on connectors or burned areas from shorting.

c. Repair. Refer to table 4-3 and replace defective wires.

Table 4-3. Cubicle DC Wiring Harness Wiring Table

From	To	Wire no.	Wire size	Color	Length (in.)
CB2-1	S8-2	H41A12	12	Red	4
CB2-1	J3-D	H41C18	18	Red	9.5
CB2-2	TB1-1	P31F12	12	Red	25
DS4-1	DS6-1	L2AK18N	18	Red	10
DS4-1	DS5-1	L2AJ18N	18	Red	11
DS4-2	J3-b	L26A18	18	Red	34
DS4-3	DS6-3	L4H18	18	Red	10
DS5-1	DS4-1	L2AJ18N	18	Red	11
DS5-1	TB2-3	L2AH18N	18	Red	27
DS5-2	J3-H	L46B18	18	Red	37
DS5-3	S8-2	L41B18	18	Red	6
DS6-1	DS4-1	L2AK18N	18	Red	10
DS6-2	K10-P	L34C18	18	Red	43
DS6-2	K6-B2	L34A18	18	Red	
DS6-3	DS4-3	L4H18	18	Red	10
DS6-3	S1-2	L4G18	18	Red	
J3-A	S13-2	K9J18	18	Red	
J3-C	S3-2	P5B18	18	Red	29
J3-D	CB2-1	H41C18	18	Red	9.5
J3-E	S5-2	P16C18	18	Red	33
J3-G	S3-1	P6A18	18	Red	29
J3-H	DS5-2	L46B18	18	Red	37
J3-J	K8-B1	K100A18	18	Red	18
J3-K	TB2-6	K17D18	18	Red	14
J3-L	TB2-5	P11E18	18	Red	14
J3-M	S5-4	P10C18	18	Red	32
J3-N	S3-3	P105A18	18	Red	
J3-P	S6-4	Q140B18	18	Red	
J3-R	S6-1	Q139B18	18	Red	
J3-S	K13-A2	K30B18	18	Red	17
J3-T	S1-3	L3A18	18	Red	31
J3-U	S5-3	P21B18	18	Red	33.5
J3-V	TB2-3	P2W12N	12	Red	16
J3-W	K9-4	H42A12	12	Red	16
J3-X	K15-5	H111A18	18	Red	15
J3-Z	K15-1	H112A18	18	Red	15
J3-a	TB2-4	P4E18	18	Red	15
J3-b	DS4-2	L26A18	18	Red	34
J3-c	K8-A1	Q15B18	18	Red	17
J3-d	S13-3	P129A18	18	Red	32.5
J3-e	K16-X1	P130A18	18	Red	15
J3-g	S8-3	H40C18	18	Red	37
J3-h	K4-B3	K24A18	18	Red	10
J3-j	S3-6	P110A18	18	Red	32
J3-m	K6-X1	P121A18	18	Red	
J3-n	K3-D1	K102A18	18	Red	9.5
K3-p	K3-A1	P106A18	18	Red	8
J3-r	K13-X1	W127A18	18	Red	19
J3-s	TB1-1	P31E12	12	Red	24
K2-1	S3-5	P6C18	18	Red	42
K2-2	K8-D2	P4L18	18	Red	6
K2-2	TB2-4	P4K18	18	Red	26
K2-4	K3-D2	K9L18	18	Red	14
K2-5	K9-5	P2Y18N	18	Red	6
K2-5	TB2-1	P2X18N	18	Red	29
K3-A1	J3-p	P106A18	18	Red	8
K3-A2	TB1-1	P31H18	18	Red	26
K3-B1	TB2-6	P17A18	18	Red	19
K3-B2	K8-C2	P25A18	18	Red	14
K3-C2	TB2-4	P4J18	18	Red	19
K3-C3	K8-C3	P10B18	18	Red	15
K3-D1	J3-n	K102A18	18	Red	9.5
K3-D2	K2-4	K9L18	18	Red	14
K3-D2	S13-2	K9K18	18	Red	

Table 4-3. Cubicle DC wiring harness wiring table—continued

From	To	Wire no.	Wire size	Color	Length (in.)
K3-X1	K13-A3	P132A18	18	Red	12
K3-X2	TB2-2	P2AE18N	18	Red	21
K4-A1	K4-X1	P16H18	18	Red	4
K4-A2	K4-B1	P11N18	18	Red	4
K4-A3	K8-A2	P132C18	18	Red	13
K4-B1	K4-A2	P11N18	18	Red	4
K4-B1	K5-B1	P11M18	18	Red	6
K4-B2	K8-A1	P15A18	18	Red	15
K4-B3	J3-h	K24A18	18	Red	10
K4-C2	K5-D1	P18B18	18	Red	6
K4-C3	K5-D2	P19B18	18	Red	6
K4-C3	K12-X1	P19A18	18	Red	13
K4-X1	K4-A1	P16H18	18	Red	4
K4-X1	K6-A2	P16B18	18	Red	
K4-X2	TB2-2	P2AC18N	18	Red	21
K5-B1	K5-C1	P11L18	18	Red	4
K5-B1	K4-B1	P11M18	18	Red	6
K5-B2	S4-2	P27A18	18	Red	40
K5-C1	K5-B1	P11L18	18	Red	4
K5-C1	TB2-5	P11K18	18	Red	20
K5-C2	K11-A3	P17C18	18	Red	19
K5-D1	K4-C2	P18B18	18	Red	6
K5-D1	K8-B3	P18A18	18	Red	15
K5-D2	K4-C3	P19B18	18	Red	6
K5-X1	K10-P	P34B18	18	Red	26
K5-X2	TB2-2	P2AB18N	18	Red	23
K6-A2	K4-X1	P16B18	18	Red	
K6-A2	S5-2	P16A18	18	Red	
K6-A3	S5-3	P21A18	18	Red	
K6-B1	S4-3	P23A18	18	Red	
K6-B2	DS6-2	L34A18	18	Red	
K6-X1	J3-m	P121A18	18	Red	
K6-X2	TB2-3	P2AG18N	18	Red	27
K8-A1	J3-c	Q15B18	18	Red	17
K8-A1	K4-B2	P15A18	18	Red	15
K8-A2	K4-A3	P132C18	18	Red	13
K8-A2	K13-A3	P132B18	18	Red	12
K8-B1	J3-J	K100A18	18	Red	18
K8-B2	TB2-5	P11F18	18	Red	26
K8-B3	K5-D1	P18A18	18	Red	15
K8-C2	K3-B2	P25A18	18	Red	14
K8-C3	K3-C3	P10B18	18	Red	15
K8-C3	S5-4	P10A18	18	Red	47
K8-D1	TB1-1	P31G18	18	Red	20
K8-D2	K2-2	P4L18	18	Red	6
K8-X1	S6-2	P35A18	18	Red	46
K8-X2	S6-5	P141A18	18	Red	
K9-1	K15-3	H43A18	18	Red	6.5
K9-2	S8-3	H40B12	12	Red	49
K9-2	K15-4	H40A18	18	Red	6.5
K9-4	J3-W	H42A12	12	Red	16
K9-5	K2-5	P2Y18N	18	Red	6
K10-P	DS6-2	L34C18	18	Red	43
K10-P	K5-X1	P34B18	18	Red	26
K10-T	K12-B2	P11J18	18	Red	
K10-T	TB2-5	P11H18	18	Red	
K11-A2	S4-6	P29A18	18	Red	37
K11-A3	K5-C2	P17C18	18	Red	19
K11-A3	TB2-6	P17B18	18	Red	18
K12-B2	K10-T	P11J18	18	Red	
K12-B3	S4-5	P28A18	18	Red	
K12-X1	K4-C3	P19A18	18	Red	13
K12-X2	TB2-2	P2AD18N	18	Red	23
K13-A2	J3-S	K30B18	18	Red	17


Table 4-3. Cubicle DC wiring harness wiring table—continued.

From	To	Wire no.	Wire size	Color	Length (in.)
K13-A3	K8-A2	P132B18	18	Red	12
K13-A3	K3-X1	P132A18	18	Red	12
K13-X1	J3-r	W127A18	18		19
K13-X2	TB2-1	P2AF18N	18		16
K15-1	J3-Z	H112A18	18	Red	15
K15-3	K9-1	H43A18	18	Red	6.5
K15-4	K9-2	H40A18	18	Red	6.5
K15-5	J3-X	H111A18	18	Red	15
K16-X1	J3-e	P130A18	18	Red	15
K16-X2	TB2-1	P2AA18N	18	Red	26
S1-2	S5-5	P4S18	18	Red	
S1-2	DS6-3	L4G18	18	Red	
S1-2	TB2-4	P4F18	18	Red	20
S1-3	J3-T	L3A18	18	Red	31
S3-1	S3-5	P6B18	18	Red	3
S3-1	J3-G	P6A18	18	Red	29
S3-2	J3-C	P5B18	18	Red	29
S3-3	J3-N	P105A18	18	Red	32
S3-5	S3-1	P6B18	18	Red	3
S3-5	K2-1	P6C18	18	Red	42
S3-6	J3-j	P110A18	18	Red	32
S4-2	K5-B2	P27A18	18	Red	40
S4-3	K6-B1	P23A18	18	Red	
S4-5	K12-B3	P28A18	18	Red	
S4-6	K11-A2	P29A18	18	Red	37
S5-2	J3-E	P16C18	18	Red	33
S5-2	K6-A2	P16A18	18	Red	
S5-3	J3-U	P21B18	18	Red	33.5
S5-3	K6-A3	P21A18	18	Red	
S5-4	J3-M	P10C18	18	Red	32
S5-4	K8-C3	P10A18	18	Red	47
S5-5	S1-2	P4S18	18	Red	
S6-1	J3-R	Q139B18	18	Red	
S6-2	K8-X1	P35A18	18	Red	46
S6-3	S13-2	P9N18	18	Red	
S6-4	J3-P	Q140B18	18	Red	
S6-5	K8-X2	P141A18	18	Red	
S6-6	TB2-1	P2Z18N	18	Red	
S8-2	CB2-1	H41A12	12	Red	4
S8-2	DS5-3	L41B18	18	Red	6
S8-3	J3-g	H40C18	18	Red	37
S8-3	K9-2	H40B12	12	Red	49
S13-2	S6-3	P9N18	18	Red	
S13-2	K3-D2	K9K18	18	Red	
S13-2	J3-A	K9J18	18	Red	
S13-3	J3-d	P129A18	18	Red	32.5
TB1-1	K3-A2	P31H18	18	Red	26
TB1-1	K8-D1	P31G18	18	Red	20
TB1-1	J3-a	P31E12	12	Red	24
TB1-1	CB2-2	P31F12	12	Red	25
TB2-1	K16X2	P2AA18N	18	Red	26
TB2-1	S6-6	P2Z18N	18	Red	
TB2-1	K2-5	P2X18N	18	Red	29
TB2-1	K13-X2	P2AF18N	18	Red	16
TB2-2	K3-X2	P2AE18N	18	Red	21
TB2-2	K12-X2	P2AD18N	18	Red	23
TB2-2	K4-X2	P2AC18N	18	Red	21
TB2-2	K5-X2	P2AB18N	18	Red	23
TB2-3	DS5-1	L2AH18N	18	Red	27
TB2-3	K6-X2	P2AG18N	18	Red	27
TB2-3	J3-V	P2W12N	12	Red	16
TB2-4	K2-2	P4K18	18	Red	26
TB2-4	K3-C2	P4J18	18	Red	19
TB2-4	S1-2	P4F18	18	Red	20

Table 4-3. Cubicle DC wiring harness wiring table—continued.

From	To	Wire no.	Wire size	Color	Length (in.)
TB2-4	J3-a	P4E18	18	Red	15
TB2-5	K5-C1	P11K18	18	Red	20
TB2-5	K10-T	P11H18	18	Red	
TB2-5	K8-B2	P11F18	18	Red	26
TB2-5	J3-L	P11E18	18	Red	14
TB2-6	J3-K	K17D18	18	Red	14
TB2-6	K11-A3	P17B18	18	Red	18
TB2-6	K3-B1	P17A18	18	Red	19

d. Installation. Install the cubicle dc wiring harness in reverse order of removal using figure 4-9 as a guide.



ME 6115-320-34/4-9

Figure 4-9. Cubicle DC wiring harness.

CHAPTER 5

REPAIR OF WINTERIZATION EQUIPMENT

Section I. REPAIR OF BATTERY HEATER

5-1. General

The battery heater is a light weight compact internal combustion, liquid fuel burning heater, used for heating the two-twelve volt batteries of the generator set. The battery heater is designed to operate on the same fuel used by the generator set at extreme low temperatures without modification or adjustment to the fuel system. The ducting provides the means for routing the heated air from the heater to the bottom of the battery box.

5-2. Battery Heater

a. Removal. Refer to TM 5-6115-320-12 for removal procedures.

b. Disassembly. Disassemble battery heater as required for parts replacement according to sequence of index numbers assigned to figure 5-1.

c. Cleaning and Inspection.

(1) Remove all excess dust and foreign matter from the battery heater with dry, compressed air.

(2) Clean the battery heater parts with a cloth moistened in cleaning solvent (Fed. Spec. O-T 634B).

(3) Inspect all battery heater parts for evidence of damage or excessive wear. Replace defective battery heater parts.

d. Repair. Refer to figure 5-1 and proceed as follows:

(1) Replace burner (31) if damaged.

(2) Replace burner assembly casing (35) if damaged.

(3) Replace combustion chamber (6) if damaged.

e. Assembly. Assemble the battery heater in reverse order of disassembly procedure using figure 5-1 as a guide.

f. Testing.

(1) Perform a bench test on the heater as follows:

(a) Operating test.

1. Install the heater assembly on a test stand equipped to operate the unit and measure voltage, amperage, and fuel flow.

2. Turn the test stand voltage selector switch to 24v dc.

3. Turn on the test stand fuel pump.

4. Place the test stand heater switch in the high heat position.

5. The blower should start immediately and the ammeter should indicate 15 amperes.

6. After an interval of 60 seconds, maximum, the flame switch should transfer, the blower should speed up, and the amperage should drop to 7 amperes. The indicator lamp will light when the flame switch transfers.

7. Place the test stand heater switch in the OFF position.

8. The burner should go off within 45 seconds, but the blower should continue to operate approximately 2 minutes to purge and cool the heater. The indicator light should continue to burn during this interval and should go out when the flame switch transfers and stops the blower.

9. If the heater fails to operate as described above, replace defective parts.

(b) Fuel control valve test.

1. With the heater connected as in (a)1 above, and with the test stand heater switch in the OFF position, turn on the test stand fuel pump.

2. Turn the test stand fuel flow meter control valve to ON position. When the fuel flow meter is full, set the flow meter control valve to OFF position.

3. Observe the level of gasoline in the fuel flow meter. If it is dropping, the heater fuel control valve is defective. Replace a defective heater fuel control valve.

4. Turn the fuel flow meter control valve to ON position.

5. Turn the test stand heater switch to high heat position.

6. After the heater is started and is operating normally, turn the fuel flow meter control valve to the off position.

7. With a stop watch, measure the time required for the fuel level in the fuel flow meter to drop from the FULL mark to the EMPTY mark.


8. From the table furnished with the test stand, compute the fuel consumption. It should be 22 to 28 cubic centimeters per minute.

9. With the test stand heater switch in the low heat position, repeat the steps in 6 through 8 above. The fuel consumption for low heat operation should be 14.5 to 19.5 cubic centimeters per minute.

10. Turn off the heater. Replace a defective fuel control valve as required.

(2) Remove the heater from the test stand.

g. Installation. Refer to TM 5-6115-320-12 for installation procedures.



ME 6115-320-34/5-1

Figure 5-1. Battery heater assembly disassembly and reassembly.

5-3. Battery Heater Ducting

a. *Removal.* To remove the battery heater ducting, refer to figure 5-2 and proceed as follows:

- (1) Remove electrical connector (1).
- (2) Remove clamp (2) and seal (3).
- (3) Remove bolts (4) and washers (5).
- (4) Remove clamp (6) and seal (7).

- (5) Remove battery heater (8).
- (6) Remove bolts (9) and washers (10).
- (7) Remove battery heater pipe assembly (11).
- (8) Remove screw (12) and washer (13).
- (9) Remove cap assembly (14).
- (10) Remove tube (15).
- (11) Remove screw (16) and washer (17).

(12) Remove cap assembly (18).

(13) Remove tube (19).

(14) Remove accumulator assembly (20).


b. Cleaning and Inspection.

(1) Remove all excess dust, dirt, and foreign matter from the battery heater ducting with dry, compressed air.

(2) Clean the battery heater ducting in cleaning solvent (FED-P-D-680).

(3) Inspect for evidence of damage, corrosion, stripped threads or excessive wear. Replace defective ducting.

c. Installation. Install the battery heater ducting in the reverse order of removal procedure using figure 5-2 as a guide.



ME 6115-320-34/5-2

Figure 5-2. Battery heater ducting removal and installation.

Section II. REPAIR OF ENCLOSURE ASSEMBLY

5-4. General

The enclosure consists of the necessary panels, skins, frame and supporting members to provide a weather tight housing for the turbine engine, generator, and components. The C.O.E. data plate provides the identifying data for the generator set. The power outlet receptacles (J18 and J26) provide the means for electrically connecting external cables to the generator set for ac power. The base plan provides a pictorial presentation for mounting SERGEANT Weapon System installations.

5-5. Power Outlet Receptacles (J18 and J26)

a. *Removal.* Remove power outlet receptacles (J18 and J26) according to sequence of index numbers assigned to figure 5-3.

b. Cleaning and Inspection.


(1) Remove all dust, dirt, and foreign matter from the power outlet receptacles with dry compressed air.

(2) Clean the receptacles with a cloth moistened in cleaning solvent (Fed. Spec. O-T 634B) and dry thoroughly.

(3) Inspect the receptacles for damage, excessive wear, cracks, loose pins, or stripped threads.

(4) Replace a defective receptacle.

c. *Installation.* Install the power outlet receptacles in reverse order of removal procedure using figure 5-3 as a guide.



- | | |
|----------------|----------------|
| 1 Nut (4) | 6 Nut (4) |
| 2 Washer (4) | 7 Washer (4) |
| 3 Screw (4) | 8 Screw (4) |
| 4 Cap assembly | 9 Cap assembly |
| 5 Receptacle | 10 Receptacle |

ME 6115-320-34/5-3

Figure 5-3. Power outlet receptacles (J18 and J26) removal and installation.

5-6. Enclosure Assembly Components and C.O.E. Data Plate

a. *Removal.* To remove the C.O.E. data plate, hoist assembly, right door retainer, access door clip, ac access door, and skid base, refer to figure 5-4 and proceed as follows:

- (1) Remove screws (3), washers (2), and nuts (1).
- (2) Remove C.O.E. data plate (4).
- (3) Remove cotter pin (5), washer (6), and straight pin (7).
- (4) Remove hoist assembly (8).

- (5) Remove screws (9) and washers (10).
- (6) Remove sound attenuation installation (11).
- (7) Remove rivets (12).
- (8) Remove clip (13).
- (9) Remove rivets (14).
- (10) Remove ac access door (15).
- (11) Remove skid base.

b. Cleaning and Inspection.

- (1) Remove all dirt, dust, and foreign matter from the enclosure assembly components and C.O.E. data plate with dry, compressed air.


- (2) Clean the enclosure assembly components in cleaning solvent (FED-P-D-680) and dry thoroughly.

- (3) Inspect for evidence of damage, excessive wear or stripped threads. Inspect the C.O.E. data plate for legibility.

- (4) Replace defective parts.

- c. Repair.** Weld all cracks or breaks per TM 9-237.

- d. Installation.** Install the C.O.E. data plate and enclosure assembly components in reverse order of removal procedure using figure 5-4 as a guide.




- 1. Nut (8)
- 2. Washer (16)
- 3. Screw (8)
- 4. C.O.E. data plate
- 5. Cotter pin (4)
- 6. Washer (4)
- 7. Pin (4)
- 8. Hoist assembly (4)
- 9. Screw (16)
- 10. Washer (16)
- 11. Sound attenuation installation
- 12. Rivet (2)
- 13. Clip
- 14. Rivet (8)
- 15. AC Power panel access door

ME 6115-320-34/5-4

Figure 5-4. Enclosure assembly components removal and installation.

5-7. Base Plan for Launching Station Installations

Refer to figure 5-5 for base plan of generator set for launching station installations.



ME 6115-320-34/5-5

Figure 5-5. Base plan for launching station installation.

APPENDIX A

REFERENCES

- A-1. Fire Protection**
TB 5-4200-200-10
Hand Portable Fire Extinguishers for Army Users.
- A-2. Lubrication**
C9100IL
LO 5-6115-230-12
Fuels, Lubricants, Oil.
Lubrication Order.
- A-3. Painting**
TM 9-213
Painting Instructions for Field Use.
- A-4. Maintenance**
TM 38-750
TM 5-6115-320-12
TM 5-6115-320-20P
TM 5-6115-320-34P
The Army Maintenance Management System (TAMMS).
Operator and Organizational Maintenance Manual
Organizational Maintenance Repair Parts and Special Tools Lists
Direct, General Support and Depot Maintenance Repair Parts
and Special Tools Lists.
TM 5-764
TM 9-6140-200-15
Electric Motor and Generator Repair.
Operator and Organizational Field and Depot Maintenance
Storage Batteries, Lead, Acid Type.
- A-5. Shipment and Storage**
TB 740-93-2
TM 740-90-1
Preservation of USAMEC Mechanical Equipment for Shipment
and Storage.
Administrative Storage of Equipment.
- A-6. Destruction of Army Materiel**
TM 750-244-3
Procedures for Destruction of Equipment to Prevent Enemy Use
(Mobility Equipment Command).

INDEX

	Paragraph	Page		Paragraph	Page
A			G		
AC Generator	4-1	4-1	Removal and installation of major components	2-8	2-13
AC Generator assembly	2-10	2-16	Repair of battery heater	5-1	5-1
Acceleration and overtemperature control thermostat	3-21	3-38	Repair of electrical system components	4-2	4-4
Accessory drive assembly	3-17	3-26	Repair of enclosure assembly	5-4	5-4
B			Repair of gas turbine engine	3-1	3-1
Base plan for launching station installation	5-7	5-6	Generator set wiring harness	4-8	4-12
Battery charger and 24V dc slave receptacle	4-5	4-8	M		
Battery heater	5-2	5-1	Maintenance repair parts	2-3	2-7
Battery heater assembly	2-11	2-16	Maintenance requirements	2-7	2-12
Battery heater ducting	5-3	5-2	Muffler assembly	3-14	3-20
C			O		
Centrifugal switch assembly	3-18	3-30	Oil pump assembly	3-8	3-10
Combustion chamber assembly	3-11	3-15	Oil spray jet and breather tubes	3-10	3-13
Compressor assembly and inlet plenum	3-16	3-24	Oil tank assembly	3-9	3-12
Cubicle ac wiring harness	4-9	4-13	Overcurrent relay (14) and main circuit breaker (CB3)	4-6	4-9
Cubicle dc wiring harness	4-10	4-24	P		
Current transformers	4-4	4-6	Power outlet receptacles (J18 and J26)	5-5	5-4
D			R		
Description	1-4	1-1	Reporting of errors	1-3	1-1
Difference between models	1-5	1-1	S		
E			Scope	1-1	1-1
Electric controls instruments	3-26	3-42	Special tools and equipment	2-2	2-1
Electric controls instruments panel assembly	3-25	3-41	Starter motor assembly	3-3	3-3
Enclosure assembly components and C.O.E. data plate	5-6	5-4	T		
Engine and generator assemblies	2-9	2-13	Tabulated data	1-6	1-1
Engine controls instruments panel assembly	3-22	3-39	Tachometer—generator	3-23	3-39
Engine wiring harness assembly	3-2	3-1	Thermocouple	3-19	3-36
Exhaust pipe and ejector	3-13	3-20	Thermostatic switch	3-20	3-37
F			Tools and equipment	2-1	2-1
Fire detectors	3-24	3-40	Troubleshooting	2-5	2-7
Forms and records	1-2	1-1	Turbine assembly	3-15	3-21
Fuel atomizer assembly	3-7	3-9	Turbine holding relays	3-4	3-5
Fuel boost pump	3-6	3-8	Turbine plenum	3-12	3-17
Fuel control unit	3-5	3-6	V		
G			Voltage change panel assembly	4-7	4-11
General			Voltage regulator assembly, load anticipator, and terminal boards (TB4, TB7, and TB8)	4-3	4-5
General maintenance	2-6	2-12			

By Order of the Secretary of the Army:

W. C. WESTMORELAND,
General, United States Army,
Chief of Staff.




Official:

VERNE L. BOWERS,
Major General, United States Army,
The Adjutant General.

Distribution:

To be distributed in accordance with DA Form 12-25, Section IV (qty rqr block no. 767) Direct and General Support Maintenance requirements for Motor Generators, 45 KW.

☆ U. S. GOVERNMENT PRINTING OFFICE : 1990 O - 277-860



ME 6115-320-34/FO-1 (2)

)-1. Generator set schematic wiring diagram. (sheet 2 of 2).

FO-1

Watt Converter
 icipator
 arger
 water
 er
 or 40 MFD 75 W VDC
 r 100 8 MHY 2.5 AMPS.

ator
Boost Pump
 et-Pump

(Radio Noise Suppression) 0.1 MFD 500 VAC-DC
 (Radio Noise Suppression) 0.1 MFD 500 VAC-DC
 (Radio Noise Suppression) 0.1 MFD 500 VAC-DC
 (Radio Noise Suppression) 0.1 MFD 500 VAC-DC
 Circuit Breaker
 tion Heater CB Circuit Breaker
 uit Breaker
 Circuit Breaker (Sergeant Special)
 ransformer (Instrumentation)
 ransformer (Instrumentation)
 ransformer (Instrumentation)
 ransformer (Voltage Droop)
 ts Lamp
 ts Lamp
 ts Lamp
 Closure Lamp
 tion Heater Lamp
 age Lamp
 Lamp
 Lamp
 ernal Ground Stud
 ound Stud
 ce Receptacle Fuse
 ator
 ceptacle
 ceptacle
 ceptacle
 entral General J14 Receptacle
 ave Receptacle J15
 Power J18 Receptacle
 Cycle-15 Amp Convenience Receptacle
 ntral Special J25 Receptacle (Sergeant)
 uel Pump J27 Receptacle (Sergeant)
 Power J28 Receptacle (Sergeant)
 Base Receptacle
 ay
 ay
 ay No. 1
 ay No. 2
 age Hold Relay
 elay
 e Relay
 .By-Pass Relay
 re Control Relay
 age Relay
 age Relay AC
 Control Relay
 g Relay
 st (Short Circuit) Relay
 mperature Sensing Relay
 ste Voltage Sensing Relay
 Indicator

.M2 Exhaust Gas Temperature Gage
 M3 Oil Pressure Gage
 M4 Battery Charging Ammeter
 M5 Start Counter
 M6 Engine Hourmeter
 M7 AC Voltmeter
 M8 Frequency Meter
 M9 AC Ammeter
 M10 Kilowatt Meter
 MT Frequency Transducer
 P1 Control Plug
 P2 Gas Turbine Plug
 P3 Control Plug
 P7 AC Generator Plug
 P8 Battery Heater Plug
 P9 Load Anticipator Plug
 P10 Load Anticipator Plug
 P11 Voltage Regulator Plug
 P12 Battery Charger Plug
 P13 Main Circuit Breaker Plug
 P14 Internally Wired Plug
 P17 Battery Electrolyte Temperature Sensor Plug
 P20 Fuel Boost Pump Plug
 P21 Battery Heater Fuel Pump Plug
 P24 Tachometer Indicator Plug
 P25 Internally Wired Plug (Sergeant)
 R1 Voltage Adj Rheostat 350 Ohms 12.5 Watt
 R2 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
 R3 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
 R4 Resistor (Synchronizing Light) 2500 Ohms 10 Watt
 R5 Resistor (Synchronizing Light) 5000 Ohms 10 Watt
 R6 Frequency Droop Rheostat 3500 Ohms 12.5 Watt
 R7 Voltage Droop Rheostat 25 Ohms 25 Watt
 R8 Frequency Adj Potentiometer 3500 Ohms 3 Watt
 R9 Resistor 1000 Ohms 1 Watt
 R10 Resistor 1000 Ohms 1 Watt
 R11 Resistor 1000 Ohms 1 Watt
 R12 Resistor 15 Ohms 10 Watt
 S1 Panel Lights Switch
 S2 Master Switch
 S3 Local Remote Control Selector Switch
 S4 Over Volt Reset Switch
 S5 Main CB Circuit Breaker Switch
 S6 Protection Bypass Switch
 S8 Winterization Heater Switch
 S10 Battery Electrolyte Temperature Sensor
 S11 Volt-Amp Selector Switch
 S12 Unit-Parallel Selector Switch
 S13 Local Remote Sensing Voltage Selector Switch
 TB1 Terminal Board
 TB2 Terminal Board
 TB3 Terminal Board
 TB4 Terminal Board
 TB5 Voltage Change Panel
 TB7 AC Power Output Terminal Board
 TB8 Terminal Board
 TB9 Terminal Board
 TC1 Fire Detector
 TC2 Fire Detector
 TC3 Fire Detector
 TC4 Fire Detector
 VR1 Voltage Regulator

ME 6115-320-34/FO-2 ①

Generator set practical wiring diagram. (sheet 1 of 7).

verter
Governor Control
by

FD 75 W VDC
MHY 2.5 AMPS.

ap

Noise Suppression) 0.1 MFD 500 VAC-DC

Noise Suppression) 0.1 MFD 500 VAC-DC

Noise Suppression) 0.1 MFD 500 VAC-DC

Noise Suppression) 0.1 MFD 500 VAC-DC

aker

er CB Circuit Breaker

er

aker (Sergeant Special)

er (Instrumentation)

er (Instrumentation)

er (Instrumentation)

er (Voltage Droop)

amp

er Lamp

ap

ound Stud

ud

tracle Fuse

eneral J14 Receptacle

receptacle J15

18 Receptacle

5 Amp Convenience Receptacle

pecial J25 Receptacle (Sergeant)

127 Receptacle (Sergeant)

128 Receptacle (Sergeant)

receptacle

1

2

3 Relay

Relay

ol Relay

by AC

ay AC

Relay

Circuit) Relay

re Sensing Relay

age Sensing Relay

er

M2 Exhaust Gas Temperature Gage

M3 Oil Pressure Gage

M4 Battery Charging Ammeter

M5 Start Counter

M6 Engine Hourmeter

M7 AC Voltmeter

M8 Frequency Meter

M9 AC Ammeter

M10 Kilowatt Meter

M11 Frequency Transducer

P1 Control Plug

P2 Gas Turbine Plug

P3 Control Plug

P7 AC Generator Plug

P8 Battery Heater Plug

P9 Load Anticipator Plug

P10 Load Anticipator Plug

P11 Voltage Regulator Plug

P12 Transformer Rectifier Plug

P13 Main Circuit Breaker Plug

P14 Internally Wired Plug

P17 Battery Electrolyte Temperature Sensor Plug

P20 Fuel Boost Pump Plug

P21 Battery Heater Fuel Pump Plug

P24 Tachometer Indicator Plug

P45 Internally Wired Plug (Fuel Tank Base Receptacle)

P25 Internally Wired Plug (Sergeant)

R1 Voltage Adj Rheostat 350 Ohms 12.5 Watt

R2 Resistor (Synchronizing Light) 2500 Ohms 10 Watt

R3 Resistor (Synchronizing Light) 5000 Ohms 10 Watt

R4 Resistor (Synchronizing Light) 2500 Ohms 10 Watt

R5 Resistor (Synchronizing Light) 5000 Ohms 10 Watt

R6 Reverse Frequency Droop Rheostat 3500 Ohms 12.5 Watt

R7 Voltage Droop Rheostat 25 Ohms 25 Watt

R8 Frequency Adj Potentiometer 3500 Ohms 3 Watt

R9 Resistor 1000 Ohms 1 Watt

R10 Resistor 1000 Ohms 1 Watt

R11 Resistor 1000 Ohms 1 Watt

R12 Resistor 15 Ohms 10 Watt

S1 Panel Lights Switch

S2 Master Switch

S3 Local Remote Central Selector Switch

S4 Over Volt Reset Switch

S5 Main CB Circuit Breaker Switch

S6 Protection Bypass Switch

S8 Winterization Heater Switch

S10 Battery Electrolyte Temperature Sensor

S11 Volt-Amp Selector Switch

S12 Unit-Parallel Selector Switch

S13 Local Remote Sensing Voltage Selector Switch

TB1 Terminal Board

TB2 Terminal Board

TB3 Terminal Board

TB4 Terminal Board

TB5 Voltage Change Panel

TB8 Terminal Board

TB9 Terminal Board

TC1 Fire Detector

TC2 Fire Detector

TC3 Fire Detector

TC4 Fire Detector

VR1 Voltage Regulator

DIAGRAM USED ON UNITS
SER P21468 AND SUBSEQUENT.

ME 6115-320-34/FO-2(2)

Generator set practical wiring diagram. (sheet 2 of 7).

FO-2

VOLTAGE	OHMS	REMARKS						
		CIRCUIT-BREAKER		GENERATOR	SWITCH			
		REF	DES	POSITION	SET	REF	DES	POSITION
0	0	CB-3		CLOSED		S2		OFF
0	INFINITY	CB-3		CLOSED		S12		UNIT
0	0	CB-3		CLOSED		S2		OFF
0	INFINITY	CB-3		CLOSED		S12		UNIT
0	1390	CB-3		CLOSED		S2		OFF
0	1220	CB-3		CLOSED		S12		UNIT
0		CB-3		CLOSED		S2		OFF
0	INFINITY	CB-3		CLOSED		S12		UNIT
0	38	CB-3		CLOSED		S2		OFF
0	3.1	CB-3		CLOSED		S12		UNIT
0	3.1	CB-3		CLOSED		S2		OFF
0	9.1	CB-3		CLOSED		S12		UNIT
0	INFINITY	CB-3		CLOSED		S2		OFF
0	INFINITY	CB-3		CLOSED		S12		UNIT
0	0	CB-3		CLOSED		S2		OFF
0	INFINITY	CB-3		CLOSED		S12		UNIT
0	2.7K	CB-3		CLOSED		S2		OFF
0	INFINITY	CB-3		CLOSED		S12		UNIT
0	INFINITY	CB-3		CLOSED		S2		OFF
0	2600	CB-3		OPEN		S12		PARALLEL
0	2600	CB-3		OPEN		S2		OFF
0	INFINITY	CB		OPEN		S12		PARALLEL
0	2600	CB-3		OPEN		S2		OFF
0	2600	CB-3		OPEN		S12		PARALLEL
0	INFINITY	CB-3		OPEN		S2		OFF
0	2600	CB-3		OPEN		S12		PARALLEL

B. AC GENERATOR (G1)

0	0.0220 TO 0.0244
0	0.0220 TO 0.0244
0	0.0220 TO 0.0244
0	0.0220 TO 0.0244
0	0.0220 TO 0.0244


ME 6115-320-34/FO-2 (5)

(1)-2. Generator set practical wiring diagram. (sheet 5 of 7).

FO-2

TOP
ALVE






ME 6115-320-34/FO-3

Figure FO-3. Fuel and air flow diagram, turbine engine.

2


-

1



ME 6115-320-34/FO-4 W-17A-122

Figure FO-1. Engine wiring harness assembly and schematic diagram.



F-17A-315

ME 6115-320-34/FO-5

Figure FO-5. Generator set wiring harness.

FO-5

