

SUPERSEDED BY TM 11-392, C2, 9 MAY 1963, TM 11-5850-201-20,
10 JUN 63 AND TM 11-5850-201-35P, *SIG 7 & 8 SE-11
11 JUN 1963

DEPARTMENT OF THE ARMY SUPPLY MANUAL

Portions of this manual are superseded by TM 11-392, C2, 9 May 1963
PORTIONS OF THIS MANUAL ARE SUPERSEDED BY TM 11-5850-201-20P, 10 JUN 63
Organizational Maintenance Allowances

and Field and Depot Maintenance Stockage Guide

for

SIGNAL LAMP EQUIPMENT SE-11

Ref: TM 11-392

Department of the Army, Washington 25, D. C.,

22 January 1957

1. A copy of SIG 1 and DA Pam 310-21 should be available to every user of the Signal portion of the Army supply manual.

a. SIG 1 explains the purpose and use of the Signal portion of the Army supply manual.

b. DA Pam 310-21 contains alphabetical and numerical indexes of available manuals in the Signal portion of the Army supply manual.

2. Items marked X under expendability note are expendable within the meaning of AR 735-4; nonexpendable items are marked NX.

3. Dry batteries shown are used with the equipment but are not considered part of the equipment. They will not be preshipped automatically but are to be requisitioned in quantities necessary for the particular organization, in accordance with SB 11-6.

4. A percent symbol (%) indicates the item is authorized for use in the category of maintenance indicated and may be requisitioned when required. Not authorized for stockage.

5. The Federal stock number column lists the 11-digit Federal stock number assigned by the Cataloging Division, OASD (S&L). The Federal stock number will be used for requisitioning purposes.

6. SIG 7 & 8 SE-11 comprises two parts as follows:

a. *Maintenance Items.* A list of parts for repair and supply facilities.

b. *Basic Issue Items.* A list of component parts showing the quantities of each that comprise a complete operating equipment, including running spares, that is, those spare parts shipped concurrently with the equipment, and accessories.

7. Comments relative to technical data discrepancies in this manual should be forwarded to—

CO, Signal Equipment Support Agency
Fort Monmouth, N. J.

ATTN: SIGFM/ES-PMA.

* This manual supersedes DA Supply Manuals SIG 7 SE-11, 14 August 1944, and SIG 8 SE-11, 1 July 1944.

Copy 1

PROPERTY OF THE ARMY
DO NOT REMOVE FROM BUILDING

By Order of Wilber M. Brucker, Secretary of the Army:

MAXWELL D. TAYLOR,
General, United States Army,
Chief of Staff.

Official:

HERBERT M. JONES,
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

CNGB
ASA
Tec Svc, DA
Tec Svc Bd
Hq CONARC
CONARC Bd
CONARC Bd Test Sec
Army AA Comd
OS Maj Comd
OS Base Comd
Log Comd
MDW
Armies
Corps
Div
US Army Tng Cen
Ft & Cp
Gen & Br Svc Sch
USMA (5)
Gen Depots
Sig Sec, Gen Depots
Depots
AH
ASMPA
AFIP
WRAMC
Sp Wpn Comd
POE (OS)
Trans Terminal Comd
Army Terminals
OS Sup Agencies
PG
Arsenals
Plants & Works

Active Army:—Con.

Sig Fld Maint Shops
ACS
Lab
Mil Dist
Trans Zones
JBUSMC

Units, org under fol TOE:

5-525R
5-526R
5-527R
11-7C
11-16C
11-57C
11-97R
11-116R
11-117R
11-127R
11-128C
11-500R
11-557C
11-587R
11-597R
20-45R
20-47R
20-300R
20-511R
20-512R
55-9C
55-68R
55-500R (AA-AE)
55-515R
55-516R
55-517R

NG: State AG; units—same as Active Army.

USAR: None.

For explanation of abbreviations used, see SR 320-50-1.

☆U.S. GOVERNMENT PRINTING OFFICE: 1957—400795/1053