

101.11:
-6115-449-20 P

TM 5-6115-449-20P

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS**

**GENERATOR SET, SELF-POWERED,
DIESEL ENGINE DRIVEN,
30 KW, AC, 3-PHASE, 120/208V, 240/416V,
60 HERTZ, CONVERTIBLE TO 25 KW,
50 HERTZ, SKID MOUNTED
(MILITARY DESIGN MODEL SF-30-MD/CIED)
NSN 6115-00-935-5111**

UNIVERSITY OF VIRGINIA LIBRARY
ALDERMAN LIBRARY
NOV 1 1990
GOVERNMENT DOCUMENTS

UNIVERSITY OF VIRGINIA LIBRARY



X004815969

This copy is a reprint which includes current
pages from Changes 1

HEADQUARTERS, DEPARTMENT OF THE ARMY

DECEMBER 1977

TECHNICAL MANUAL

NO. 5-6115-449-20P

HEADQUARTERS
 DEPARTMENT OF THE ARMY
Washington, DC, 16 December 1977

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

**GENERATOR SET, SELF-POWERED
DIESEL ENGINE DRIVEN,
30KW, AC, 3-PHASE, 120/208V, 240/416V, 60 HERTZ
CONVERTIBLE TO 25KW, 50 HERTZ, SKID MOUNTED
(MILITARY DESIGN MODEL SF-30-MD/CIED)
NSN 6115-00-935-5111**

Current as of 14 September 1977

REPORTING ERROR AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedure, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publication and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, U. S. Army Troop Support and Aviation Materiel Readiness Command, ATTN: DRSTS-MTPS, 4300 Goodfellow Blvd., St. Louis, MO 63120. A reply will be furnished to you.

TABLE OF CONTENTS

		Page	illus Figure
SECTION	I. INTRODUCTION	1	
Group	II. REPAIR PARTS LIST	5	
	01. Batteries and Related Items.....	5	
	Batteries, Cables, and Charging Receptacle.....	1	
	02. Muffler and Pipea.....	6	
	Muffler and Pipea.....	2	
	03. Convenience Receptacle.....	7	
Convenience Receptacle.....	3		
04. Paralleling Receptacle.....	8		
Paralleling Receptacle.....	4		
05. Generator Set Controls.....	9		
Remote Control Assembly.....	5		

*This manual supersedes TM 5-6115-449-20P, 11 May 1970, including all changes.

SECTION	Page	
	Title	
	Page	
	7	
	8	
	9	
	10	
06.	Housing Group..... Housing, Doors, and Panels..... Rear Panel.....	17 11 12
07.	Interconnecting Wiring Harnesses..... Interconnecting Wiring Harnesses.....	21 13
08.	Load Terminal Box..... Terminal Box Assembly.....	23 14
09.	Generator Controls..... Governor Control Unit Mounting Components..... Regulator and Exciter Assembly.....	25 16 23
10.	Air Cleaner Assembly..... Air Cleaner.....	28 27
11.	Generator Assembly..... Generator Assembly.....	29 28
12.	Day Tank and Fuel Filter Assembly..... Day Tank and Pump Assembly..... Fuel Filter Assembly.....	31 29 30
13.	Center Support..... Starting Aid Assembly..... Center Support and Related Components.....	35 31 32
14.	Cooling Group..... Shutter and Radiator.....	38 33
15.	Hydraulic Actuator..... Hydraulic Actuator and Throttle Linkage.....	40 34
16.	Hydraulic Tank and Filter..... Hydraulic Tank..... Hydraulic Filter.....	42 36 37
17.	Engine Assembly..... Alternator and Drive Belt..... Switches and Transmitters..... Oil Drain..... Manifolds..... Starter..... Oil Filter..... Fuel Injection Lines..... Water Pump and Fan..... Thermostat, Water Inlet and Outlet Covers..... Oil Pan..... Cylinder Head Cover..... Cylinder Block.....	45 38 40 41 43 45 46 47 51 52 53 57 63
18.	Base Group..... Fuel Tank..... Skid Base.....	62 64 65
19.	Accessory Items..... Accessory Items.....	66 66
20.	Winterization Equipment..... Heater Mounting Components, Lines and Fittings..... Heater Control Box.....	67 67 69
21.	Bulk Material.....	71
III.	SPECIAL TOOLS LIST (NOT APPLICABLE)	72
IV.	NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX	72

Section I. INTRODUCTION

1. Scope

This manual lists repair parts, special tools, test, measurement, and diagnostic equipment (TMDE), and other support equipment required for operation and performance of organizational maintenance of the Generator Set.

2. General

a. Section II - Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of assembly groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence, as the last group in Section II.

b. Section III - Special Tools List. (Not applicable)

c. Section IV - National Stock Number and Part Number Index. A list, in ascending numerical sequence, of all National stock numbers appearing in the listings, followed by a list, in alpha numeric sequence, of all part numbers appearing in the listings. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns.

The following provides an explanation of columns found in the tabular listings:

a. Illustration. This column is divided as follows:

(1) **Figure Number.** Indicates the figure number of the illustration in which the item is shown.

(2) **Item Number.** The number used to identify each item called out in the illustration.

b. Source, Maintenance, and Recoverability Codes (SMR).

(1) **Source Code.** Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
KD	An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at the direct support maintenance level.
MH	Item to be manufactured or fabricated at the general support maintenance level.
MD	Item to be manufactured or fabricated at the direct support maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.

Code	Definition (Cont)
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA or XD.

(2) **Maintenance Code.** Maintenance codes are assigned to indicate the levels of maintenance authorized to use and repair support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

a. The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance.

Code	Application/Explanation
C	Crew or operator maintenance performed within organizational maintenance.
O	Support item is removed, replaced, used at the organizational level.

b. The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
O	The lowest maintenance level capable of complete repair of the support item is the organizational level.

F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H	The lowest maintenance level capable of complete repair of the support item is the general support level.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
L	Repair restricted to designated specialized repair activity.
Z	Nonrepairable. No repair is authorized.
B	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) **Recoverability Code.** Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Codes	Definition
Z	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in position 3.
O	Reparable item. When uneconomically repairable, condemn and dispose at organizational level.
F	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.
H	Reparable item. When uneconomically repairable, condemn and dispose at the general support level.
D	Reparable item. When beyond lower repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L	Reparable item. Repair, condemnation, and disposal not authorized below/specialized repair activity level.
A	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. **National Stock Number.** Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. Part Number. Indicates the primary number used by the manufacturer which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. Federal Supply Code for Manufacturer(FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item. Items that are included in kits and sets are listed below the name of the kit or set with the quantity of each item in the kit or set indicated in the quantity incorporated in unit column. When the part to be used differs between serial numbers of the same model, the effective serial numbers are shown as the last line of the description. In the Special Tools List, the initial basis of issue (BOI) appears as the last line in the entry for each special tool, TMDE, and support equipment. When density of equipment supported exceeds density spread indicated in the basis of issue, the total authorization is increased accordingly.

g. Unit of Measure(U/M). Indicates the standard of the basic quantity of the listed items as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit.

Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e.g., shims, spacers, etc.).

4. Special Information

a. Repair parts kits and gasket sets appear as the last entries in the repair parts listing for the

figure in which its parts are listed as repair parts or are listed at the end of the repair parts listing for the last figure containing parts of the kit.

b. The following publications pertain to the Generator Set and its components.

TM 5-6115-449-15 Operator, Organizational, Direct and General Support and Depot Maintenance

c. The illustration in this manual are identical to those published in TM 5-6115-449-34P. Only those parts assigned the third position SMR maintenance code "C" or "O" are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

5. How to Locate Repair Parts

a. When National Stock Number or Part Number is Unknown:

(1) First. Using the table of contents, determine the functional group within which the repair part belongs. This is necessary since illustrations are prepared for functional groups, and listings are divided into the same groups.

(2) Second. Find the illustration covering the functional group to which the repair part belongs.

(3) Third. Identify the repair part on the illustration and note the illustration figure and item number of the repair part.

(4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National Stock Number or Part Number is Known:

(1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in ascending NSN sequence followed by a list of part numbers in ascending alphanumeric sequence, cross-referenced to the illustration figure number and item number.


(2) Second. After the finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

<i>Abbreviation</i>	<i>Explanation</i>
---------------------	--------------------

deg	degree (s)
ea	each
ft	feet (foot)
grp	group
id	insided diameter
in.	inch (es)
lg	long (length)
mtg	mounting (s)
No.	Number (s)
od	outside diameter


(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG. NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
SECTION II - REPAIR PARTS LIST							
GROUP 01 BATTERIES AND RELATED ITEMS							
1	1	XBOZZ		12310E3336-2	97403	CABLE ASSEMBLY,BATTERY NEGATIVE,6 FT 8 1/2 IN.O/A LG	EA 1
1	2	XBOZZ		12310E3337-2	97403	CABLE ASSEMBLY,BATTERY POSITIVE,7 FT 4 IN.O/A LG	EA 1
1	3	PAOZZ	5075-00-124-1505	12310E3333	97403	BUSHING,INSULATING BATTERY CABLE THRU FRAME	EA 2
1	4	XBOZZ		12310E3339	97403	CABLE,BATTERY JUMPER	EA 1
1	5	XBOZZ	5310-00-761-6882	MS51867-2	98806	NUT,PLAIN,HEXAGON RECEPTACLE ASSEMBLY MTG, 1/4-20 THD SIZE	EA 4
1	6	PAOZZ	5310-00-583-8865	MS98638-44	98806	WASHER,LOCK RECEPTACLE MTG,1/4 IN SCREW SIZE	EA 2
1	7	PAOZZ	5308-00-225-3830	MS906735-8	98806	SCREW,CAP,HEXAGON HEAD RECEPTACLE MTG,1/4-20 THD SIZE,1 IN.LG	EA 4
1	8	XBOZZ		12310E3334-2	97403	RECEPTACLE ASSEMBLY BATTERY CHARGING	EA 1
1	9	XBOZZ	5308-00-004-7121	12310E3306	97403	BOLT,SPECIAL BATTERY HOLD-DOWN,3/8-16 THD SIZE,9 3/4 IN. LG	EA 3
1	10	XBOZZ	5110-00-105-0736	12310E3312	97403	BAR,BATTERY HOLD-DOWN	EA 1
1	11	XBOZP	5140-00-067-3564	12310E3155	97403	BATTERY,STORAGE	EA 2
		XBOZZ		MS90663	98806	SULFURIC ACID,ELECTROLYTIC	EA 4



TS 6115-449-20P/1

Figure 1. Batteries, cables, and charging receptacle.


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
GROUP 02 MUFFLER AND PIPES							
2	1	PAOZZ	5310-00-913-8881	MS51971-3	98806 NUT,PLAIN,HEXAGON MUFFLER CLAMPING,3/8-16 THD SIZE	EA	2
2	2	XBOZZ		13216E00073	97403 SADDLE,EXHAUST CLAMPING	EA	1
2	3	XBOZZ		13216E00074	97403 BOLT,U MUFFLER,3 IN.,1/4-20 THD SIZE	EA	1
2	4	XBOZZ		MS35307-386	98806 SCREW,CAP,HEXAGON HEAD MUFFLER MTG,7/16-14 THD SIZE,1 1/4 IN. LG	EA	2
2	5	XBOZZ		MS35338-100	98806 WASHER,FLAT MUFFLER MTG,17/32 IN. ID,1 IN. OD,3/32 IN. THK	EA	2
2	6	PAOZZ	2990-00-136-1134	13216E00038	97403 MUFFLER,EXHAUST	EA	1
2	7	PAOZZ	5330-00-256-7003	40619A	28285 GASKET MUFFLER	EA	1
2	8	PAOZZ	5306-00-637-9675	MS35307-332	98806 BOLT,MACHINE EXHAUST TUBE MTG,5/16-18 THD SIZE,3/4 IN. LG	EA	2
2	9	PAOZZ	5310-00-974-8623	MS35338-140	98806 WASHER,LOCK EXHAUST TUBE MTG,5/16 IN. SCREW SIZE	EA	2
2	10	PAOZZ	5310-00-767-0445	MS51971-2	98806 NUT,PLAIN,HEXAGON EXHAUST TUBE MTG,5/16-18 THD SIZE	EA	2
2	11	XBOZZ		13216E00056	97403 TUBE,EXHAUST ENGINE	EA	1



TS 6115-449-20P/2

Figure 2. Muffler and pipes.


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	PSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
GROUP 03 CONVENIENCE RECEPTACLE							
8	1	XBOZZ	12314E2301-2	97403	NUT,PLAIN,HEXAGON HARNESS CLAMP MTG,NO. 6-32 THD SIZE	EA	2
3	2	PAOZZ	5310-00-045-4007	98006	WASHER,LOCK HARNESS CLAMP MTG,NO. 6 SCREW SIZE	EA	2
3	3	XBOZZ	MS34584-42	98006	SCREW,MACHINE HARNESS CLAMP MTG,NO. 6-32 THD SIZE,1/2 IN. LG	EA	2
3	4	PAOZZ	5310-00-003-0483	98006	WASHER,FLAT HARNESS CLAMP MTG,NO. 6 SCREW SIZE	EA	2
3	5	PAOZZ	5340-00-070-7637	98006	CLAMP,LOOP CONVENIENCE RECEPTACLE HARNESS MTG	EA	2
8	6	XBOZZ	MS34584-57	98006	SCREW,MACHINE CONVENIENCE RECEPTACLE MTG,NO. 6-32 THD SIZE, 5/8 IN. LG	EA	4
3	7	XBOZZ	12316E2304	97403	COVER,RECEPTACLE CONVENIENCE	EA	1
3	8	PAOZZ	5320-00-005-0583	97403	GASKET CONVENIENCE RECEPTACLE COVER	EA	1
3	9	XBOZZ	12316E7601	97403	HARNESS,WIRING CONVENIENCE RECEPTACLE	EA	1
3	10	XBOZZ	5300-00-004-1366	97403	RECEPTACLE,DUPLEX CONVENIENCE	EA	1
3	11	XBOZZ	5325-00-100-0327	97403	BUSHING,INSULATING CONVENIENCE RECEPTACLE LEAD	EA	1
3	12	XBOZZ	12316E2306	97403	BOX,CONDUIT CONVENIENCE RECEPTACLE	EA	1



TS 6115-449-20P/3

Figure 3. Convenience receptacle.


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT U/M
GROUP 04 PARALLELING RECEPTACLE							
4	1	XBOZZ	5310-00-761-6862	MS61967-2	98006 NUT,PLAIN,HEXAGON	EA	8
4	2	PAOZZ	5310-00-582-5065	MS35338-44	98006 WASHER,LOCK RECEPTACLE MTG	EA	8
4	3	PAOZZ	5305-00-088-0502	MS90725-6	98006 SCREW RECEPTACLE MTG	EA	8
4	4	PAOZZ		MS35043-18C	98006 CAP,DUST PARALLELING RECEPTACLE	EA	2
4	5	MOOOZ		1331GE7183	97403 HARNESS ASSEMBLY,WIRING PARALLELING RECEPTACLE TO RELAY CONTROL BOX MPD FROM AN 18 18 FT. REQUIRED	EA	1
4	6	XBOZZ		1331GE7151-1	97403 CONNECTOR,ELECTRICAL	EA	1
4	7	PAOZZ	5935-00-725-6630	MS9100R18-4P	98006 CONNECTOR,ELECTRICAL	EA	2



TS 6115-449-20P/4

Figure 4. Paralleling receptacle.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL			DESCRIPTION	QTY INC IN UNIT	
FIG. NO.	ITEM NO.	SMR CODE	STOCK NUMBER	PART NUMBER	PSCM	Usable On Code	U/M
GROUP 06 GENERATOR SET CONTROLS							
5	PAOZZ	6110-00-136-8750	13216E3195	97403	REMOTE CONTROL ASSEMBLY (REPLACES PLATE AND SLEEVE ASSEMBLY, FSN 6110-136-8756)	EA	1
5	1	XBOZZ	13214E3291-4	97403	NUT,ASSEMBLED WASHER SLEEVE MTG,NO. 10-24 THD SIZE	EA	4
5	2	XBOZZ	5305-00-084-0210	M836206-263	98006 SCREW,MACHINE SLEEVE MTG,NO. 10-24 THD SIZE,1/2 IN. LG	EA	4
5	3	XBOZZ	13216E3396-3	97403	BUSHING,SLEEVE RETAINING	EA	1
5	4	XBOZZ	13216E3199	97403	PLATE,RETAINER SLEEVE	EA	1
5	5	XBOZZ	5075-C3-421-0052	13216E3196	97403 SLEEVE,LEAD	EA	1
5	6	PAOZZ	5305-00-088-0503	M890725-4	98006 SCREW,CAP,HEXAGON HEAD REMOTE CONTROL BOX MTG, 1/4-20 THD SIZE,3/4 IN. LG	EA	2
5	7	PAOZZ	5310-00-200-0786	M836336-33	98006 WASHER,LOCK REMOTE CONTROL BOX MTG,1/4 IN. SCREW SIZE	EA	2
5	8	XBOZZ	13216E3399	97403 PLATE,MOUNTING REMOTE CONTROL BOX	EA	1	
5	9	XBOZZ	6110-00-089-5380	13216E3300	97403 REMOTE CONTROL BOX	EA	1



TS 6115-449-20P/5

Figure 5. Remote control assembly.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)				DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	U/M	
7	1	PAOZZ	5306-00-084-0310	MS35306-263	98906 SCREW,MACHINE FAULT INDICATOR PANEL MTG,NO. 10-24 THD SIZE, 1/2 IN. LG	EA	4
7	2	PAOZZ	5310-00-086-7891	MS35336-32	98906 WASHER,LOCK FAULT INDICATOR PANEL MTG, NO. 10 SCREW SIZE	EA	4
7	3	PAOZZ	6110-00-114-0000	13306E4770	97403 PANEL,FAULT INDICATOR	EA	1
7	8	XBOZZ		13314E4770-4	97403 FUSE FAULT INDICATOR PANEL,1 AMP,250V	EA	1
7	11	PAOZZ	6240-00-155-7836	MS35337-327	98906 LAMP,INCANDESCENT FAULT INDICATOR PANEL	EA	16





Figure 7. Fault indicator panel.

TS 6115-449-20P/7


(1) ILLUS		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
8	1	PAOZZ	5305-00-068-0500	MS90725-3	96906	SCREW,CAP,HEXAGON HEAD SIZE, 1/2 IN. LG	DC CONTROL MTG,1/4-20 THD	EA 2
8	2	PAOZZ	5310-00-582-5965	MS35338-44	96906	WASHER,LOCK	DC CONTROL MTG,1/4 IN. SCREW SIZE	EA 2
8		PAOZF	6115-00-857-0587	13214E3299	97403	CONTROL ASSEMBLY, DC		EA 1
8	9	PAOZZ	5920-00-243-3788	F03A250V15AS	81349	FUSE	DC CONTROL PANEL	EA 1



TS 6115-449-20P/8

Figure 8. DC control panel.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE				U/M	
9	1	PAOZZ	5310-00-052-3632	13214E3291-3	97403 NUT,ASSEMBLED WASHER CONTROL BOX DOOR HOLDER AND DOOR MTG, NO. 8-32 THD SIZE	EA	6
9	2	XBOZZ		MS24683-25	96906 SCREW,MACHINE DOOR HOLDER AND CLAMP TO DOOR,NO. 8-32 THD SIZE,7/16 IN. LG,FLATHEAD	EA	3
9	3	XBOZZ		13214E3276	97403 HOLDER ASSEMBLY DOOR	EA	2
9	4	XBOZZ		MS24584-42	96906 SCREW,MACHINE CONTROL PANEL COMPONENTS AND CLAMP MTG, NO. 8-32 THD SIZE,7/16 IN. LG	EA	15
9	5	XBOZZ		MS24584-47	96906 SCREW,MACHINE CLAMP MTG,NO. 8-32 THD SIZE,1/2 IN. LG	EA	2
9	8	XBOZZ		13214E3293-3	97403 JUMPER,WIRE SYNCHRONIZING LIGHTS	EA	3
9	10	PAOZZ	5315-00-449-2945	13213E9666	97403 PIN,GROOVED,HEADLESS DOOR FASTENER	EA	3
9	11	XBOZZ	5325-00-432-8902	13213E9655-6	97403 STUD,TURNLOCK FASTENER DOOR CLOSING	EA	3
9	12	XBOZZ	5325-00-437-8904	13214E3285	97403 GROMMET,METAL DOOR FASTENER	EA	3
9	14	PAOZZ	5930-00-668-1522	MS35058-30	96906 SWITCH,TOGGLE ENGINE PRIMER	EA	1
9	15	PAOZZ	6240-00-155-7878	13214E3273	97403 LAMP,INCANDESCENT PANEL LIGHT	EA	3
9	16	PAOZZ	6210-00-935-6919	13214E7704	97403 LIGHT,PANEL	EA	3
9	17	PAOZZ	6115-00-114-0663	13205E4793-2	97403 METER,KILOWATT	EA	1
9	18	PAOZZ	6625-00-869-3143	13205E4792	97403 METER,CURRENT	EA	1
9	19	PAOZZ	6625-00-869-3144	13205E4790	97403 VOLTMETER	EA	1
9	20	PAOZZ	6620-00-228-8442	13205E4787-1	97403 INDICATOR,PRESSURE OIL	EA	1
9	21	PAOZZ	6600-00-857-0656	13205E4798	97403 INDICATOR,LIQUID QUANTITY FUEL	EA	1
9	22	XBOZZ		MILM3971-1AMEND1	81349 METER,TIME TOTALIZING	EA	1
9	23	PAOZZ	6685-00-857-0662	13205E4799	97403 INDICATOR,TEMPERATURE ENGINE COOLANT	EA	1
9	24	PAOZZ	6625-00-869-3141	13205E4789	97403 AMMETER BATTERY CHARGING	EA	1
9	26	XAOZZ		13214E8648	97403 INDICATOR	EA	1
9	27	XAOZZ		13214E8647	97403 TRANSDUCER	EA	1
9	28	PAOZZ	6210-00-299-4104	MS25331-6	96906 LIGHT ASSEMBLY PROTECTION BY-PASS	EA	1
9	29	PAOZZ	6240-00-155-8714	MS25231-313	96906 LAMP,INCANDESCENT CIRCUIT BREAKER AND PROTECTION BY-PASS PRESS TO TEST	EA	2
9	30	PAOZZ	6240-00-143-3060	MS15567-1	96906 LAMP,INCANDESCENT SYNCHRONIZING LIGHT	EA	3
9	31	PAOZZ	6210-00-107-4121	13214E7706	97403 LIGHT,SYNCHRONIZING	EA	3
9	32	PAOZZ	5355-00-916-2060	MS91528-2P4B	96906 KNOB VOLTAGE AND FREQUENCY RHEOSTAT	EA	3
9	34	PAOZZ		MS25331-4-313	96906 LIGHT,INDICATOR CIRCUIT BREAKER TEST	EA	1
9	36	PAOZZ	5930-00-058-9692	13205E4786	97403 SWITCH,ELECTRICAL VOLT-AMP TRANSFER	EA	1
9	37	XBOZZ	5930-00-815-6731	MS25224-1	96906 GUARD,SWITCH PROTECTION BY-PASS	EA	1
9	38	PAOZZ	5930-00-655-1581	MS25068-23	96906 SWITCH,TOGGLE PROTECTION BY-PASS AND PARALLEL OPERATION	EA	2
9	39	PAOZZ	5930-00-655-1582	MS35059-23	96906 SWITCH,TOGGLE VOLTAGE SENSING	EA	1
9	40	I'AOZZ	5930-00-655-1514	MS35058-22	96906 SWITCH,TOGGLE PANEL LIGHT	EA	1
9	41	PAOZZ	5930-00-044-3518	MS25201-6	96906 SWITCH,TOGGLE CIRCUIT BREAKER	EA	1
9	42	PAOZZ	5930-00-782-8590	13205E4785	97403 SWITCH,ELECTRICAL START-STOP	EA	1



TS 6115-449-20P/9

Figure 9. Control cubicle panel.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
10	1	PAOZZ	5310-00-052-3632	13214E3291-3	97403 NUT,ASSEMBLED WASHER COMPONENT MTG,NO. 8-32 THD SIZE	EA	17
10	2	XBOZZ		MS36233-51	96906 SCREW,MACHINE FLASHER MTG,NO. 8-32 THD SIZE, 1/8 IN. LG	EA	2
10	3	PAOZZ	5945-00-782-0019	13214E3286	97403 FLASHER,LAMP	EA	1
10	5	XBOZZ		MS34584-42	96906 SCREW,MACHINE THERMINAL BOARD MTG,NO. 8-32 THD SIZE,3/4 IN. LG	EA	4
10	6	XBOZZ		06281	97520 BOARD,TERMINAL CONTROL BOX	EA	1





Figure 10. Control cubicle box.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
GROUP 06 HOUSING GROUP							
11	1	PAOZZ	5305-00-008-0503	M800725-6	98006 SCREW,CAP,HEXAGON HEAD 1/4-20 THD SIZE,3/4 IN. LG	EA	44
11	2	PAOZZ	5310-00-300-0700	M834335-33	98006 WASHER,LOCK TOP PANEL AND COMPARTMENT DOOR MTG,1/4 IN. SCREW SIZE	EA	70
11	3	XBOZZ		13316E0044	97403 PANEL,TOP GENERATOR END	EA	1
11	4	XBOZZ		13316E0006	97403 PANEL ASSEMBLY, TOP ENGINE END	EA	1
11	5	PAOZZ	5305-00-008-0503	13314E3200-50	97403 SCREW,ASSEMBLED WASHER RADIATOR FILLER DOOR MTG, NO. 10-34 THD SIZE,1/2 IN. LG	EA	3
11	6	PAOZZ	5330-00-036-0005	13314E7488	97403 SEAL,DOOR RADIATOR FILLER,30 IN. REQUIRED	EA	1
11	7	XBOZZ		13314E3333	97403 DOOR,RADIATOR FILLER	EA	1
11	8	XAOZZ		13316E0042	97403 PANEL	EA	1
11	9	PAOZZ	5305-00-300-0700	M835301-5	98006 SCREW,CAP,HEXAGON HEAD COMPARTMENT DOOR MTG, 1/4-20 THD SIZE,5/8 IN. LG	EA	20
11	10	XBOZZ		13316E0012	97403 DOOR ASSEMBLY GENERATOR END	EA	2
11	11	XBOZZ		13316E0006	97403 DOOR ASSEMBLY ENGINE END	EA	2
11	12	PAOZZ	5330-00-036-0005	13314E7488	97403 SEAL,DOOR ENGINE AND GENERATOR COMPARTMENT,35 FT REQUIRED FOR 4 DOORS	EA	4
11	13	PAOZZ	5310-00-003-0453	M827183-5	98006 WASHER,FLAT FUEL SYSTEM PLATE AND WIRING DIAGRAM MTG, NO. 6 SCREW SIZE	EA	16
11	14	XBOZZ		M830004B4T3	98006 RIVET,TUBULAR FUEL SYSTEM AND WIRING DIAGRAM PLATE MTG,0.125 IN. DIA,0.306 IN. LG	EA	16
11	15	XBOZZ		13316E0015-2	97403 PLATE,INFORMATION WIRING DIAGRAM	EA	1
11	16	XBOZZ		13316E0015-1	97403 PLATE,INFORMATION WIRING DIAGRAM	EA	1
11	17	XBOZZ		13316E3361	97403 PLATE,INSTRUCTION FUEL SYSTEM	EA	1
11	18	XBOZZ		13316E0006	97403 DOOR ASSEMBLY BATTERY COMPARTMENT	EA	1
11	19	PAOZZ	4030-00-700-0350	M867006-13	98006 HOOK,CHAIN BATTERY DOOR	EA	1
11	20	XBOZZ	5300-00-324-7579	13316E3336	97403 SPRING BATTERY DOOR RETAINING	EA	1
11	21	PAOZZ	5330-00-036-0005	13314E7488	97403 SEAL,DOOR BATTERY COMPARTMENT,9 FT REQUIRED	EA	1
11	22	PAOZZ	5310-00-003-0453	M827183-5	98006 WASHER,FLAT BATTERY ARRANGEMENT PLATE MTG,NO. 6 SCREW SIZE	EA	4
11	23	XBOZZ		M830004B4T3	98006 RIVET,TUBULAR BATTERY ARRANGEMENT PLATE MTG,0.125 IN. DIA,0.306 IN. LG	EA	4
11	24	XBOZZ		13316E3336	97403 PLATE,INSTRUCTION BATTERY ARRANGEMENT AND CONNECTIONS	EA	1
11	25	XBOZZ		13316E3361	97403 DOOR,BATTERY	EA	1



TS 6115-449-20P/11

Figure 11. Housing, doors, and panels.

(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
12	1	PAOZZ	5305-00-088-0602	MS800725-6	98806	SCREW,CAP,HEXAGON HEAD REAR PANEL ASSEMBLY MTG, 1/4-20 THD SIZE,3/4 IN. LG	EA 12
12	2	PAOZZ	5310-00-209-0786	MS35335-33	98806	WASHER,LOCK REAR PANEL ASSEMBLY MTG,1/4 IN. SCREW SIZE	EA 12
12		XBOZH		13316E20007	97403	PANEL ASSEMBLY,REAR HOUSING	EA 1
12	3	PAOZZ	5305-00-088-0600	MS800725-3	98806	SCREW,CAP,HEXAGON HEAD DOOR MTG,1/4-20 THD SIZE,1/2 IN. LG	EA 22
12	4	PAOZZ	5310-00-209-0786	MS35335-33	98806	WASHER,LOCK DOOR MTG,1/4 IN. SCREW SIZE	EA 20
12	5	PAOZZ	5330-00-088-0805	13314E7486	97403	SEAL,DOOR REAR PANEL,13 FT REQUIRED FOR 4 DOORS	EA 4
12	6	XBOZZ	6115-00-185-0682	13316E3300	97403	DOOR,CONTROL PANEL RH	EA 1
12	7	PAOZZ	5310-00-088-0483	MS27183-5	98806	WASHER,FLAT OPERATING INSTRUCTION PLATE MTG,NO. 6 SCREW SIZE	EA 6
12	8	XBOZZ		MS30004B4T3	98806	RIVET,TUBULAR OPERATING INSTRUCTION PLATE MTG,0.125 IN. DIA, 0.206 IN. LG	EA 6
12	9	XBOZZ		13316E0064	97403	PLATE,INSTRUCTION OPERATING	EA 1
12	10	XBOZZ	6115-00-483-2361	13316E3300	97403	DOOR,CONTROL PANEL LH	EA 1
12	11	XBOZZ	5310-00-761-0882	MS851007-3	98806	NUT,PLAIN,HEXAGON AIR INLET DOOR MTG,1/4-20 THD SIZE	EA 10
12	12	XBOZZ		13316E0020	97403	DOOR,AIR INLET RH	EA 1
12	13	XBOZZ		13316E0021	97403	DOOR,AIR INLET LH	EA 1
12	14	PAOZZ	5305-00-088-0602	13314E3300-50	97403	SCREW,ASSEMBLED WASHER LOUVER MTG,NO. 10-24 THD SIZE,1/2 IN. LG	EA 8
12	15	XBOZZ		13316E0042	97403	LOUVER,AIR INLET	EA 1
12	16	PAOZZ	5305-00-088-0600	MS800725-3	98806	SCREW,CAP,HEXAGON HEAD HEATER PLATE MTG, 1/4-20 THD SIZE, 1/2 IN. LG	EA 2
12	17	PAOZZ	5310-00-563-5005	MS35338-44	98806	WASHER,LOCK HEATER PLATE MTG,1/4 IN. SCREW SIZE	EA 2
12	18	XBOZZ		13314E7414	97403	PLATE,COVER HEATER CONTROL OPENING	EA 1
12	19	PAOZZ	5305-00-088-0600	MS800725-6	98806	SCREW,CAP,HEXAGON HEAD PLATE MTG,1/4-20 THD SIZE,3/4 IN. LG	EA 12
12	20	XBOZZ	5310-00-563-5005	MS35338-44	98806	WASHER,LOCK REAR PANEL PLATE MTG,1/4 IN. SCREW SIZE	EA 12
12	21	PAOZZ	6115-00-088-0682	13316E3300	97403	PLATE AND SLEEVE ASSEMBLY REAR PANEL	EA 1
12	22	XBOZZ		13316E3400	97403	PLATE,COVER	EA 1
12	23	XAOZZ		13316E0045	97403	PANEL	EA 1





Figure 12. Rear panel.

TS 6115-449-20P/12


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
GROUP 07 INTERCONNECTING WIRING HARNESSES							
13	1 MPOFF		13216E7177	97403	HARNESS ASSEMBLY,WIRING RELAY CONTROL BOX TO CB2 CONTRACTOR MFD FROM AN 16 15 FT. REQUIRED	EA	1
	PAOZZ	5340-00-809-1500	MS21333-107	96906	CLAMP,LOOP HARNESS TO RECONNECTION BOX	EA	2
13	2 MPOFF		13216E7181	97403	HARNESS ASSEMBLY,WIRE EXCITER REGULATOR TO CB2 CONTACTOR AND TB6 RECONNECTION BOARD MFD FROM AN16 10 FT. REQUIRED	EA	1
13	3 MPOFF		13216E7175	97403	HARNESS ASSEMBLY RELAY CONTROL BOX TO CONTROL CUBICLE AND EXCITER REGULATOR MFD FROM AN16 111 FT. REQUIRED	EA	1
13	4 PAOZZ	2920-00-135-6411	13216E7185	97403	HARNESS ASSEMBLY,WIRING RELAY CONTROL BOX TO FAULT INDICATOR PANEL	EA	1
13	5 MPOFF		13216E7184	97403	HARNESS ASSEMBLY,WIRING RELAY CONTROL BOX TO REMOTE CONTROL BOX MFD FROM AN16 24 FT REQUIRED	EA	1
13	6 MPOFF		13216E7180	97403	HARNESS ASSEMBLY,WIRING RELAY CONTROL BOX TO SPEED SWITCH MFD FROM AN16 20 FT. REQUIRED	EA	1
13	7 MPOFF		13216E7176	97403	HARNESS ASSEMBLY,WIRING RELAY CONTROL BOX TO LOAD MEASURING UNIT AND GOVERNOR CONTROL MFD FROM AN16 40 FT. REQUIRED	EA	1
13	8 XBOZZ		13216E3171	97403	HARNESS ASSEMBLY,WIRING FUEL PUMPS TO MAIN HARNESS	EA	1
13	9 XBOZZ		13216E7174	97403	HARNESS ASSEMBLY WIRING MAIN WIRING HARNESS	EA	1
13	10 MPOFF		13216E7179	97403	HARNESS ASSEMBLY,WIRING GOVERNOR CONTROL TO GOVERNOR ACTUATOR (P22 TO P24) MFD FROM AN16 19 FT. REQUIRED	EA	1
13	11 MPOFF		13216E7178	97403	HARNESS ASSEMBLY,WIRING GOVERNOR CONTROL TO GOVERNOR ACTUATOR (P23 TO P25) MFD FROM AN16 19 FT. REQUIRED	EA	1



TS 6115-449-20P/13

Figure 13. Interconnecting wiring harnesses.


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE				U/M	
GROUP 08 LOAD TERMINAL BOX							
14	5	XBOZZ	5305-00-004-0210	MS36336-263	98006 SCREW,MACHINE RECONNECT COVER MTG.NO. 10-24 THD SIZE, 1/2 IN. LG		EA
14	6	PAOZZ	5310-00-006-7601	MS36336-23	98006 WASHER,LOCK RECONNECT COVER MTG.NO. 10 SCREW SIZE		EA
14	7	XBOZZ		133160200778	97403 COVER ASSEMBLY RECONNECTION BOARD		EA
14	11	PAOZZ	5310-00-006-7431	MS17839-0C	98006 NUT,SELF-LOCKING,HEXAGON LOAD TERMINAL,1/2-13 THD SIZE		EA
14	12	PAOZZ	5310-00-006-0066	MS37163-16	98006 WASHER,FLAT LOAD TERMINAL,1/2 IN. SCREW SIZE		EA
14	18	PAOZZ	5305-00-322-3039	MS00735-6	98006 SCREW,CAP,HEXAGON HEAD TERMINAL AND LOAD BOARD MTG, 1/4-20 THD SIZE,1 IN. LG		EA
14	19	PAOZZ	5310-00-006-0706	MS36336-23	98006 WASHER,LOCK TERMINAL AND LOAD BOARD MTG, 1/4 IN. SCREW SIZE		EA
14	26	PAOZZ		MS361907-14	98006 NUT,PLAIN,HEXAGON LOAD TERMINAL,1/2-13 THD SIZE		EA
14	21	XBOZZ		1331301637-1	97403 TERMINAL,LOAD		EA
14	22	XBOZZ		1331602006	97403 TERMINAL BOARD,LOAD		EA



TS 6115-449-20P/14

Figure 14. Terminal box assembly.

(1) ILLUS (a)	(2) (b)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
GROUP 09 GENERATOR CONTROLS							
16	1	XBOZZ		13316E3300	97488	NUT,PLAIN,WING GOVERNOR UNIT MTG,1/4-20 THD SIZE	EA 2
16	2	XBOZZ	3840-00-324-0274	13314E3246	97403	STRAP,HOLD-DOWN GOVERNOR UNIT	EA 1
16	3	XBOZZ		13316E3300-2	97403	STUD,PLAIN GOVERNOR UNIT HOLD-DOWN,1/4-20 THD SIZE, 8 IN. LG	EA 2
16	4	PAOZZ	3808-00-325-0497	MS300725-32	98006	BOLT,MACHINE GOVERNOR BRACKET MTG,3/8-16 THD SIZE, 1/2 IN. LG	EA 3
16	5	PAOZZ		MS305328-46	98006	WASHER,LOCK GOVERNOR BRACKET MTG,3/8 IN. SCREW SIZE	EA 3
16	6	XBOZZ		13316E3023	97403	BRACKET GOVERNOR CONTROL UNIT MTG	EA 1
16	7	XBOZL		13316E3304-2	97403	CONTROL UNIT,GOVERNOR	EA 1



TS 6115-449-20P/16


Figure 16. Governor control unit mounting components.

1

;

D

D



TS 6115-449-20P/23

Figure 23. Regulator and exciter assembly.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	F9CM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
23	4	PAOZZ	5120-00-136-0757	13216E9068	97403 TOOL,BARRING LOAD TERMINAL	EA	1
23	11	XBOZZ		13214E3291-4	97403 NUT,ASSEMBLED WASHER WRENCH BRACKET MTG,NO. 10-24 THD SIZE	EA	2
23	12	XBOZZ	5305-00-004-0210	M835906-263	98006 SCREW,MACHINE WRENCH BRACKET MTG, NO. 10-24 THD SIZE, 1/2 IN. LG	EA	2
23	13	PAOZZ	5310-00-500-7001	M835336-32	98006 WASHER,LOCK WRENCH BRACKET MTG,NO. 10 SCREW SIZE	EA	2
23	14	XBOZZ		13216E7137	97403 BRACKET,WRENCH	EA	1

(1) ILLUS (a)	(2) (b)	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	Usable On Code	U/M	QTY INC IN UNIT
GROUP 10 AIR CLEANER ASSEMBLY								
27	1	XBOZZ	13216E3388	97403	NUT,PLAIN, WING AIR CLEANER RETAINER MTG, 1/4-20 THD SIZE	EA	2	
27	2	XBOZZ	13214E3205	97403	RETAINER AIR CLEANER ELEMENT	EA	1	
27	3	PAOZZ	5305-00-071-2235	MS90725-16	SCREW, CAP, HEXAGON HEAD AIR CLEANER RETAINER MTG	EA	2	
27	4	PAOZZ	4130-00-633-6392	13216E3375	ELEMENT,AIR CLEANER	EA	1	
27	5	PAOZZ	6685-00-179-8632	13216E3372	INDICATOR ASSEMBLY,SERVICE ENGINE AIR CLEANER	EA	1	
27	6	PAOZZ	4730-00-908-3184	MS35842-11	CLAMP,HOSE AIR CLEANER TO BREATHER HOSE	EA	2	
27	7	XBOZZ	4407-5-8	24161	HOSE,RUBBER AIR CLEANER TO BREATHER	EA	1	
27	8	XBOZZ	MS35890-822	98806	NUT,PLAIN,HEXAGON AIR CLEANER ADAPTER MTG, 1/2-20 THD SIZE	EA	2	
27	9	XBOZZ	MS35338-29	98806	WASHER,LOCK AIR CLEANER ADAPTER MTG, 1/2 IN. SCREW SIZE	EA	2	
27	10	XBOZZ	MS21306-2	98806	WASHER,FLAT AIR CLEANER ADAPTER MTG, 1/2 IN. SCREW SIZE	EA	2	
27	11	PAOZZ	2990-00-919-6564	13216E3167	FITTING,PRIMER FUEL ATOMIZER	EA	1	
27	12	XBOZZ	13216E3029	97403	ADAPTER,AIR CLEANER	EA	1	
27	13	XBOZZ	MILG12803TYPE3 GRADE2CLASS1	81349	GASKET AIR CLEANER ADAPTER MTG 4X6 IN. REQUIRED	EA	1	





Figure 27. Air cleaner.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE				U/M	
GROUP 11 GENERATOR ASSEMBLY							
28	3	PA0EZ	5300-00-225-0404	MS30725-30	90006 BOLT,MACHINE BRACKET COVER AND SCREEN MTG,5/16-18 THD SIZE, 1/2 IN. LG	EA	18
28	4	PA0EZ		MS36338-46	90006 WASHER,LOCK BEARING RETAINING BOLT,SCREEN AND BRACKET COVER MTG,5/16 IN. SCREW SIZE	EA	19
28	5	XBOZZ		13212E9461	97403 COVER,BRACKET	EA	2
28	6	XBOZZ	0615-00-220-0036	QQ9006	81348 PLATE,COVER END BRACKET	EA	1
28	10	PA0EZ		MS37183-13	90006 WASHER,FLAT BEARING RETAINING AND SCREEN MTG,5/16 IN. SCREW SIZE	EA	5
28	14	XBOZZ		13216E7002	97403 SCREEN,COVER FAN END	EA	2
28	15	XBOZZ		300016	53106 NUT,PLAIN,HEXAGON BRUSH HOLDER,1/4-20 THD SIZE	EA	4
28	16	XBOZZ		MS1230057	90006 WASHER,LOCK BRUSH HOLDER,1/4 IN. SCREW SIZE	EA	4
28	17	XBOZZ		MS31300-3	90006 WASHER,FLAT BRUSH HOLDER,1/4 IN. SCREW SIZE	EA	4
28	18	XBOZZ		MS00117-14	90006 SCREW,MACHINE BRUSH HOLDER,1/4-20 THD SIZE,1 1/2 IN. LG	EA	4
28	19	XBOZZ		MS0123-02	90006 SCREW,MACHINE BRUSH LEAD,NO. 10-32 THD SIZE,7/16 IN. LG	EA	4
28	20	XBOZZ		MS15735-000	90006 WASHER,FLAT BRUSH LEAD,1/4 IN. ID,0.563 IN. OD,0.151 IN. THK	EA	8
28	21	PA0EZ	0077-00-419-0734	13216E7002	97403 BRUSH,CARBON ELECTRICAL CONTACT	EA	4



TS 6115-449-20P/28

Plane motor assembly

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
(6)	(7)	(8)						
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
GROUP 12 DAY TANK AND FUEL FILTER ASSEMBLY								
28	1	PAOZZ	4710-00-135-6413	13216E0047	97403	TUBE ASSEMBLY DAY TANK TO FUEL FILLER NECK	EA	1
28	2	XBOZZ	4730-00-011-4637	M830176-3	96906	NUT,TUBE ADAPTER TO FILLER NECK,7/16-20 THD SIZE	EA	1
28	3	XBOZZ	5310-00-043-3656	57D6413H02	98726	WASHER,NONMETALLIC ADAPTER TO FILLER NECK	EA	1
28	4	XBOZZ		M821366-1	96906	WASHER,FLAT ADAPTER TO FILLER NECK,7/16 IN. ID	EA	1
28	5	XBOZZ	4730-00-267-0706	WWP400CLAS8A	81348	REDUCER,PIPE TEE TO FILLER NECK,ONE END MALE, 1/4 NPT, OTHER END FEMALE,1/8 NPT	EA	1
28	6	XBOZZ	4730-00-268-3896	550X4	79470	TEE,PIPE DAY TANK OVERFLOW TUBE TO FUEL FILLER NECK, FIRST END MALE,1/8 NPT,SECOND AND THIRD ENDS FEMALE, 1/4 IN. TUBE, 7/16-24 THD SIZE	EA	1
28	7	PAOZZ		M835336-46	96906	WASHER,LOCK DAY TANK MTG,3/8 IN. SCREW SIZE	EA	4
28	8	PAOZZ	5306-00-269-3310	M800726-30	96906	SCREW,CAP,HEXAGON HEAD DAY TANK MTG,3/8-16 THD SIZE,7/8 IN. LG	EA	4
28	9	XBOZZ		13216E0076	97403	DAY TANK AND PUMP ASSEMBLY	EA	1
28	10	PAOZZ	4730-00-477-0670	M832741-5-0314	96906	HOSE ASSEMBLY, RUBBER	EA	1
28	11	PAOZZ	4730-00-498-0556	M832741-5-0174	96906	HOSE ASSEMBLY,RUBBER FUEL PUMP TO DAY TANK	EA	1
28	12	PAOZZ	4730-00-194-1715	M832741-5-0340	96906	HOSE ASSEMBLY,RUBBER DAY TANK TO FILTERS	EA	1
28	13	PAOZZ	4730-00-251-5631	M832741-5-0344	96906	HOSE ASSEMBLY, RUBBER	EA	1
28	14	PAOZZ	4730-00-223-0719	M832741-5-0182	96906	HOSE ASSEMBLY,RUBBER FUEL PUMP INLET	EA	1
28	15	XBOZZ	4730-00-377-0167	M851613	96906	ELBOW,PIPE TO TUBE FUEL PUMP INLET AND OUTLET,ONE END MALE, 3/8 IN. TUBE, 5/8-18 THD SIZE,OTHER END FEMALE,1/4 NPT	EA	2
28	16	PAOZZ	5306-00-003-0603	M800726-3	96906	SCREW,CAP,HEXAGON HEAD TRANSFER PUMP AND CLIP MTG, 1/4-20 THD SIZE,3/4 IN. LG	EA	5
28	17	XBOZZ	5306-00-177-1783	13214E3106	96906	WASHER,LOCK TRANSFER PUMP AND CLIP MTG, 1/4 IN. SCREW SIZE	EA	5
28	18	PAOZZ	4710-00-133-6710	13214E3106	97403	CLIP TRANSFER PUMP LEAD MTG	EA	1
28	19	PAOZZ	4730-00-708-2206	9403902	97403	TUBE ASSEMBLY FUEL PUMP CONNECTING	EA	1
28	20	XBOZZ			00000	ELBOW,PIPE TO TUBE FUEL PUMP CONNECTING,BOTH ENDS FEMALE, ONE END 1/4-16 THD SIZE,OTHER END 5/16 IN. TUBE, 1/2-20 THD SIZE	EA	2
28	21	PAOZZ	5310-00-000-0007	M851231-3	96906	PUMP,FUEL,ELECTRICAL FUEL TRANSFER	EA	2
28	22	PAOZZ	5306-00-763-0033	470136	72860	GASKET,COVER	EA	2
28	23	PAOZZ	5310-00-003-0403	470135	72860	FILTER	EA	2
28	24	PAOZZ	4730-00-135-0345	13206E0192-3	97403	CAP,TUBE DAY TANK DRAIN	EA	1
28	25	PAOZZ	4820-00-595-3191	13214E3243	97403	COCK,DRAIN DAY TANK	EA	1
28	26	PAOZZ	5306-00-003-0503	M800726-3	96906	SCREW,CAP,HEXAGON HEAD DAY TANK AND SUPPORT MTG, 1/4-20 THD SIZE,1/2 IN. LG	EA	5
28	27	PAOZZ	5310-00-503-0006	M835336-44	96906	WASHER,LOCK DAY TANK TO BRACKET AND SOLENOID SUPPORT, 1/4 IN. SCREW SIZE	EA	5
28	28	XBOZZ		13216E0075	97403	BRACKET TANK MTG	EA	1
28	29	PAOZZ	4730-00-131-0136	C5465X5X4	72470	ELBOW,PIPE TO TUBE DAY TANK TOP AND LOWER SIDE, MALE, ONE END, 1/4 NPT, OTHER END, 5/16 IN. TUBE,1/2-20 THD SIZE,90 DEG	EA	2
28	30	XBOZZ		C5365X5X4	70470	ELBOW,PIPE TO TUBE HOSE TO DAY TANK,MALE,ONE END,1/4 NPT, OTHER END,5/16 IN. TUBE,1/2-20 THD SIZE,7/16-24 THD SIZE,45 THD SIZE, 45 DEG	EA	1
28	31	PAOZZ	4730-00-377-0043	13216E3222	97403	ELBOW,PIPE TO TUBE DAY TANK OVERFLOW ONE END MALE, 1/4-16 THD SIZE,OTHER END FEMALE,5/16 IN. TUBE	EA	1
28	32	XBOZZ		13214E3243	97403	SUPPORT,SOLENOID VALVE	EA	1
28	33	PAOZZ	4810-00-543-3656	13216E3227-1	97403	VALVE,SOLENOID	EA	1
28	34	PAOZZ	4730-00-499-4619	C3000X4	79470	NIPPLE,HEXAGON VALVE MTG,1/4 NPT	EA	1
28	35	PAOZZ	5310-00-007-0019	13214E2640	97403	SWITCH,LEVEL DAY TANK	EA	1
28	36	PAOZZ	5310-00-192-0126	13214E3100	97403	TANK,DAY	EA	1





Figure 29. Day tank and pump assembly

TS 6115-449-20P/29


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(9)	(10)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SER CODE				U/M	
26	1	PAOZZ	5305-00-200-3213	M530725-02	90006 SCREW,CAP,HEXAGON HEAD FILTER ASSEMBLY MTG, 3/8-16 THD SIZE, 1 1/4 IN. LG	EA	4
26	2	PAOZZ		M530533-46	90006 WASHER,LOCK FILTER ASSEMBLY MTG,3/8 IN. SCREW SIZE	EA	4
26	PAOZZ	2010-00-135-0413	12210E00013	97403 FILTER ASSEMBLY,FUEL	EA	1	
26	3	XBOZZ		MS30741-5-0104	90006 HOSE ASSEMBLY,RUBBER FILTER TO FUEL PUMP	EA	1
26	4	XBOZZ	5305-00-200-3200	M530725-20	90006 SCREW,CAP,HEXAGON HEAD FILTER MTG,3/8-16 THD SIZE, 0.750 IN. LG	EA	4
26	5	PAOZZ	5305-00-200-3200	M530725-20	90006 SCREW,CAP,HEXAGON HEAD FUEL FILTER AND STRAINER MTG, 3/8-16 THD SIZE,3/4 IN. LG	EA	4
26	6	PAOZZ		M530533-46	90006 WASHER,LOCK FUEL FILTER AND STRAINER MTG,3/8 IN. SCREW SIZE	EA	6
26	7	XBOZZ		12210E0003	97403 BRACKET FUEL FILTER AND STRAINER ASSEMBLY MTG	EA	1
26	8	PAOZZ	4730-00-121-0128	C5406X5X4	70470 ELBOW,PIPE TO TUBE FUEL HOSE TO FILTER, MALE ONE END, 1/4 NPT, OTHER END, 5/16 IN. TUBE,1/2-20 THD SIZE	EA	3
26	9	PAOZZ		3400X4	70470 ELBOW,PIPE SECONDARY FILTER,ONEONE END FEMALE, END MALE 1/4 NPT	EA	1
26	10	PAOZZ	4730-00-030-0304	C5306X5X4	70470 CONNECTOR,PIPE TO TUBE HOSE TO TEE,MALE ONE END, 1/4 NPT, OTHER END,5/16 IN. TUBE,1/2-20 THD SIZE	EA	2
26	11	XBOZZ	4630-00-505-3191	12214E2343	97403 COCK,SHUT-OFF,SCREW HEATER FUEL	EA	1
26	12	PAOZZ	4730-00-135-0345	12200E0192-2	97403 CAP ASSEMBLY HEATER FUEL LINE	EA	1
26	13	PAOZZ	4730-00-014-0763	2760X4	70470 TEE,STREET,BRANCHED HEATER COCK,1/4 NPT	EA	1
26	14	PAOZZ	4730-00-277-1000	2220X4	70470 BUSHING,PIPE TEE TO FILTER,1/3 NPT BY 1/4 NPT	EA	2
26	15	XBOZZ	2010-00-155-0220	12210E0003	97403 FILTER ASSEMBLY FUEL,SECONDARY	EA	1
26	16	PAOZZ	4730-00-207-1102	104018	73370 PLUG FILTER COVER	EA	1
26	17	XBOZZ		297222	73370 SCREW,CAP,SPECIAL FILTER HEAD	EA	1
26	18	PAOZZ	5310-00-043-3055	101407	73370 GASKET FILTER HEAD SCREW	EA	1
26	19	XBOZZ		101408	73370 HEAD,FILTER	EA	1
26	20	PAOZZ	5300-00-003-4773	101408	73370 GASKET FILTER HEAD	EA	1
26	21	PAOZZ	2010-00-007-1012	121001	73370 CARTRIDGE ASSEMBLY FUEL FILTER	EA	1
26	22	XBOZZ	4630-00-753-0040	100408	73370 COCK,DRAIN FILTER	EA	1
26	23	XBOZZ		297222	73370 BODY ASSEMBLY	EA	1
26	24	PAOZZ	2010-00-100-3331	12210E0331	97403 FILTER AND STRAINER ASSEMBLY	EA	1
26	25	XBOZZ	5310-00-221-0040	297004	73370 NUT,CROWN STRAINER RETAINING	EA	1
26	26	PAOZZ	5310-00-043-3055	151220	73370 GASKET CROWN NUT	EA	1
26	27	XBOZZ	4630-00-753-0040	100408	73370 COCK,DRAIN	EA	2
26	28	XBOZZ		297222	73370 BODY ASSEMBLY STRAINER	EA	1
26	29	PAOZZ	5300-00-003-4773	101408	73370 GASKET FILTER AND STRAINER	EA	2
26	30	XBOZZ	2010-00-008-0012	90006	73370 RETAINER ASSEMBLY	EA	1
26	31	PAOZZ	2010-00-222-2210	20070	73370 CARTRIDGE STRAINER	EA	1
26	32	XBOZZ		297222	73370 NUT,PLAIN,HEXAGON STUD LOCKING,5/16-18 THD SIZE	EA	1
26	33	XBOZZ		297222	73370 STUD,CENTER STRAINER	EA	1
26	34	XBOZZ	5305-00-200-2074	297222	73370 SCREW,CAP,HEXAGON HEAD FILTER,7/16-20 THD SIZE	EA	1
26	35	PAOZZ	5310-00-505-0300	101407	73370 GASKET FILTER SCREW	EA	1
26	36	PAOZZ	2010-00-007-1012	121001	73370 CARTRIDGE ASSEMBLY FILTER	EA	1
26	37	XBOZZ		297008	73370 BODY ASSEMBLY	EA	1
26	38	XBOZZ		297008	73370 HEAD,FILTER AND STRAINER	EA	1



TS 6115-449-20P/30

Figure 30. Fuel filter assembly


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	PSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SER CODE				U/M	
GROUP 13 CENTER SUPPORT							
31	1	XBOEZ	12314E3201-4	97403	NUT,ASSEMBLED WASHER SOLENOID VALVE,ETHER TANK BRACKET AND TUBE CLIP MTG,NO. 10-24 THD SIZE	EA	5
31	2	PAOEZ	MS30-00-004-0210	MS30300-263	SCREW,MACHINE SOLENOID VALVE,ETHER TANK BRACKET AND TUBE CLIP MTG,NO. 10-24 THD SIZE,1/2 IN. LG	EA	5
31	3	XBOEZ	12314E3100	97403	CLAMP AND BRACKET ETHER TANK	EA	1
31	4	PAOEZ	2810-00-040-0727	12314E3100	TANK,ETHER ENGINE PRIMER	EA	1
31	5	XBOEZ	MS30613-4P8	98006	RIVET,SOLID TUBE CLAMP MTG,1/8 IN. DIA,1/2 IN. LG	EA	2
31	6	XBOEZ	12314E3040	97403	CLAMP,TUBE PRIMER LINE RETAINING	EA	3
31	7	MOOEZ	LP2970-48	61112	TUBE ASSEMBLY PRIMER MFD FROM 538-84 52 IN REQUIRED	EA	1
		XBOEZ	MS30177-1	98006	SLEEVE	EA	2
		PAOEZ	4730-00-307-0001	MS30176-1	NUT,TUBE COUPLING	EA	2
31	8	XBOEZ	12314E3104	97403	ELBOW,PIPE TO TUBE PRIMER SOLENOID VALVE TO PRIMER TUBE	EA	1
31	9	PAOEZ	2800-00-071-5423	12314E3100	VALVE AND COIL ASSEMBLY PRIMER	EA	1



TS 6115-449-20P/31

Figure 31. Starting aid assembly.

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE				U/M	
32	1	PAOZZ	4730-00-908-6294	MS35842-16	96906 CLAMP,HOSE FUEL FILLER HOSE	EA	2
32	2	XBOZZ		4168	24161 HOSE,RUBBER FUEL FILLER 6 IN REQUIRED	EA	1
32	3	PAOZZ	5305-00-036-6906	13214E3290-50	97403 SCREW,ASSEMBLED WASHER FUEL FILLER MTG, NO. 10-34 THD SIZE,1/3 IN. LG	EA	4
32	4	XBOZZ		13214E3258	97403 FILLER ASSEMBLY,FUEL	EA	1
32	5	PAOZZ	2910-00-141-9758	MS35845-1	96906 CAP ASSEMBLY FILLER	EA	1
32	6	XBOZZ	2910-00-752-9138	MS90906-1	96906 SLEEVE,EXTENSION	EA	1
32	7	XBOZZ		AAL2274	78225 GUIDE,EXTENSION	EA	1
32	8	PAOZZ	5310-00-052-3632	13214E3291-3	97403 NUT,ASSEMBLED WASHER AUXILIARY FUEL LINE CAP CHAIN MTG, NO. 10-34 THD SIZE	EA	1
32	9	XBOZZ	5305-00-984-6210	MS35206-263	96906 SCREW,MACHINE AUXILIARY FUEL LINE CAP CHAIN MTG, NO. 10-34 THD SIZE,1/2 IN. LG	EA	1
32	10	PAOZZ	5310-00-167-0834	AN900-10L	88044 WASHER,FLAT AUXILIARY FUEL LINE CAP CHAIN MTG, NO. 10 SCREW SIZE	EA	1
32	11	PAOZZ	4730-00-135-6345	13208E9192-2	97403 CAP,TUBE AUXILIARY FUEL CONNECTION	EA	1
32	12	XBOZZ		C7924X5	79470 NUT,LOCK AUXILIARY FUEL HOSE CONNECTING ELBOW, 1/2-20 THD SIZE	EA	2
32	13	PAOZZ	4720-00-411-5621	MS28741-5-0070	96906 HOSE ASSEMBLY AUXILIARY FUEL CONTROL VALVE TO ELBOW,1/4 IN.	EA	1
32	14	PAOZZ	4730-00-620-6904	2021-4-5S	01276 CONNECTOR,PIPE TO TUBE AUXILIARY FUEL HOSE TO CONTROL, VALVE, ONE END MALE,1/4 NPTF,OTHER END MALE,5/16 IN. TUBE, 1/2-20 THD SIZE	EA	1
32	15	PAOZZ	4730-00-121-0138	C5405X5X4	79470 ELBOW,PIPE TO TUBE AUXILIARY FUEL CONTROL VALVE, ONE END MALE,1/4 NPT,OTHER END MALE,5/16 IN. TUBE, 1/2-20 THD SIZE	EA	2
32	16	XBOZZ	5310-00-761-6882	MS51967-2	96906 NUT,PLAIN,HEXAGON AUXILIARY FUEL CONTROL VALVE MTG, 1/4-20 THD SIZE	EA	2
32	17	PAOZZ	5310-00-582-5965	MS35338-44	96906 WASHER,LOCK AUXILIARY FUEL CONTROL VALVE MTG, 1/4 IN. SCREW SIZE	EA	4
32	18	PAOZZ	5305-00-068-0502	MS90725-6	96906 SCREW,CAP,HEXAGON HEAD AUXILIARY FUEL CONTROL VALVE MTG, 1/4-20 THD SIZE,3/4 IN. LG	EA	2
32	19	PAOZZ	4820-00-930-6624	13211E6750	97403 VALVE,PLUG AUXILIARY FUEL CONTROL,3WAY	EA	1
32	20	XBOZZ		C5525X5	79470 ELBOW,TUBE,AUXILIARY FUEL HOSE CONNECTING,FIREFALL TYPE 5/16 IN. TUBE,1/2-10 THD SIZE	EA	1
32	28	XBOZZ		MS20604B4T3	96906 RIVET,TUBULAR AUXILIARY FUEL VALVE INSTRUCTION PLATE MTG, 0.125 IN. DIA,0.396 IN. LG	EA	4
32	29	XBOZZ		13216E3357	97403 PLATE,INSTRUCTION AUXILIARY FUEL CONTROL VALVE	EA	1
32	30	XBOZZ	5340-00-171-2588	13216E3188	97403 CLEVIS,LIFTING GENERATOR SET	EA	1



TS 6115-449-20P/32

Figure 32. Center support and related components

(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY IN UNIT
GROUP 14 COOLING GROUP							
33	1	XBOZZ	4730-00-900-9037	MS35843-13	96006	CLAMP,HOSE RADIATOR WATER HOSE	EA 4
33	2	PAOZZ		13314E3242-2	97403	HOSE,RUBBER RADIATOR,UPPER	EA 1
33	3	PAOZZ	4720-00-412-5771	13314E3242-3	97403	HOSE, RUBBER RADIATOR, LOWER	EA 1
33	4	XBOZZ	5310-00-701-6883	MS361907-2	00000	NUT,PLAIN,HEXAGON FAN GUARD MTG,1/4-20 THD SIZE	EA 8
33	5	PAOZZ	5310-00-200-0786	MS36335-33	00000	WASHER,LOCK FRONT PANEL,FAN GUARD AND DOOR SUPPORT	EA 21
						MTG, 1/4 IN. SCREW SIZE	
33	6	PAOZZ	5306-00-066-0502	MS90725-6	96006	SCREW,CAP,HEXAGON HEAD FRONT PANEL AND FAN GUARD MTG, 1/4-20 THD SIZE,3/4 IN. LG	EA 26
33	7	PAOZZ	5310-00-900-4058	MS27183-10	00000	WASHER,FLAT FAN GUARD MTG,1/4 IN. SCREW SIZE	EA 4
33	8	PAOZZ	5310-00-582-5965	MS35338-44	96006	WASHER,LOCK FAN GUARD MTG,1/4 IN. SCREW SIZE	EA 4
33	9	XBOZZ		13316E0061	97403	GUARD,FAN,LEFT HAND	EA 1
33	10	XBOZZ		13316E0066	97403	GUARD,FAN,RIGHT HAND	EA 1
33	11	XBOZZ		13316E0010	97403	SUPPORT,PANEL ENGINE END,RH	EA 1
33	12	XBOZZ		13316E0016	97403	CAP ASSEMBLY,WEATHER EXHAUST TUBE	EA 1
33		XBOZZ		13316E0006	97403	FRONT PANEL AND RADIATOR ASSEMBLY	EA 1
33	13	PAOZZ	5306-00-225-8497	MS90725-32	96006	BOLT,MACHINE RADIATOR AND GRILLE MTG,5/16-18 THD SIZE,3/4 IN. LG	EA 14
33	14	PAOZZ	5310-00-514-8674	MS35338-34	96006	WASHER,LOCK RADIATOR AND GRILLE MTG,5/16 IN. SCREW SIZE	EA 14
33	15	XBOZZ		13316E0046	97403	GRILLE,FRONT RADIATOR	EA 1
33	16	XBOZZ		13316E0041	97403	PANEL,ENGINE END	EA 1
33	17	PAOZZ	4730-00-906-3194	MS35842-11	96006	CLAMP,HOSE RADIATOR DRAIN	EA 1
33	18	XBOZZ		4407-5-8X12	24161	HOSE,RUBBER RADIATOR DRAIN	EA 1
33	19	XBOZZ		13316E0079	97403	COCK,SHUT-OFF RADIATOR DRAIN	EA 1
33	20	PAOZZ		72-2055	30654	HOSE,RUBBER RADIATOR OVERFLOW	EA 1
33	21	PAOZZ	5305-00-269-3211	MS90725-60	96006	SCREW,CAP,HEXAGON HEAD POWER ELEMENT AND HOUSING TO RADIATOR,5/16 THD SIZE,1 IN. LG	EA 4
33	22	PAOZZ		MS35338-46	96006	WASHER,LOCK POWER ELEMENT AND HOUSING TO RADIATOR, 3/8 IN. SCREW SIZE	EA 4
33	23	XBOZZ	5330-00-251-4062	14803	96300	GASKET POWER CONTROL AND HOUSING MTG	EA 2
33	24	PAOZF	2930-00-118-1223	13316E0031	97403	RADIATOR, ENGINE COOLING	EA 1
33	25	XBOZZ	2930-00-720-2677	MS35840-1	96300	CAP,RADIATOR	EA 1
33	26	PAOZZ	5305-00-285-5275	453019	00000	SCREW,ASSEMBLED WASHER RADIATOR, 1/4-20 THD SIZE, 1/2 IN. LG	EA 12
33	27	XBOZZ	5310-00-582-5965	MS35338-44	96006	WASHER,FLAT RADIATOR,5/16 IN. ID,3/4 IN. OD,1/16 IN. THK	EA 12
33	28	XBOZZ		13316E0032	97403	SHUTTER AND CONTROL RADIATOR	EA 1
33	29	XAOZZ		14801-4	96300	HOUSING	EA 1
33	30	PAOZZ	5360-00-812-8893	1064	96300	SPRING,HELICAL,EXTENSION SHUTTER RETURN	EA 1
33	31	XBOZZ		1G17704	96300	ROD ASSEMBLY SHUTTER OPERATING	EA 1
33	32	XBOZZ		1G1770	96300	SHUTTER,RADIATOR	EA 1
33	33	XBOZZ		4461	96300	CONTROL ASSEMBLY,SHUTTER	EA 1
33	34	XBOZZ	2930-00-192-9266	1054-2	96300	LEVER,SHUTTER OPERATING	EA 1
33	35	XBOZZ		24904-2	96300	LEVER,HAND SHUTTER OPERATING	EA 1
33	36	XAOZZ		4465	96300	SHAFT,FSN 2930-065-1923	EA 1
33	37	PAOZZ	5360-00-343-3396	13616	96300	SPRING,HELICAL,COMPRESSION HAND LEVER TENSION	EA 1
33	38	XAOZZ		4462	96300	THERMOSTAT AND FLANGE,FSN 2930-004-1186	EA 1





Figure 22. Shutter and radiator

TS 6115-449-20P/33

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG. NO.	ITEM NO.	SMR CODE				U/M	
GROUP 15 HYDRAULIC ACTUATOR							
34	1	PAOZZ	4730-00-461-1731	MS28741-4-0244	98006 HOSE ASSEMBLY,RUBBER HYDRAULIC PUMP TO ACTUATOR	EA	1
34	2	XBOZZ		C6506X5	79470 ELBOW,SWIVEL HYDRAULIC TANK HOSE TO ACTUATOR, 1/4 IN. TUBE, 7/16-20 THD SIZE	EA	1
34	3	PAOZZ	4730-00-781-4997	C8406X4X4	79470 ELBOW,PIPE TO TUBE ACTUATOR LINE,MALE,ONE END, 1/4 IN. NPT, OTHER END,1/4 IN. TUBE,7/16-20 THD SIZE	EA	1
34	4	PAOZZ	4730-00-302-6491	3230X6X4	79470 BUSHING,PIPE ACTUATOR LINE,1/4 X 3/8 NPT	EA	1
34	5	XBOZZ		MS38321G4	98006 FITTING,FLARED ACTUATOR TO HOSE,MALE,ONE END,7/16-20 THD SIZE,OTHER END,1/4 IN. TUBE,7/16-20 THD SIZE	EA	1
34	6	PAOZZ	5330-00-348-3836	MS29513-012	98006 PACKING,PREFORMED CONNECTOR TO ACTUATOR	EA	1
34	7	PAOZZ	5310-00-807-1468	MS21042-4	98006 NUT,SELF-LOCKING,HEXAGON THROTTLE LINKAGE MTG, 1/4-28 THD SIZE	EA	3
34	8	XBOZZ	5310-00-080-8004	MS27183-14	98006 WASHER,FLAT THROTTLE LINKAGE TO FUEL PUMP, 13/32 IN. ID, 21/32 IN. OD	EA	1
34	9	XBOZZ		MS35276-79	98006 SCREW,MACHINE,FLATHEAD LINKAGE AND PULL CHAIN MTG, 1/4-28 THD SIZE,1/2 IN. LG	EA	1
34	10	PAOZZ	5340-00-157-9798	I3316E8864	97403 PIN,PULL THROTTLE STOP	EA	1
34	11	XBOZZ		I3316E8863	97403 THROTTLE LINKAGE	EA	1
34	12	PAOZZ	5306-00-590-7863	MS35306-306	98006 SCREW,CAP,HEXAGON HEAD THROTTLE LINKAGE MTG,1/4-28 THD SIZE 1 IN. LG	EA	1

TS 6115-449-20P/34

Figure 34. Hydraulic actuator and throttle linkage



(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
GROUP 16 HYDRAULIC TANK AND FILTER							
36	1	XBOZZ	13216E00065	97403	TUBE ASSEMBLY HYDRAULIC PUMP TO TANK	EA	1
36	2	XBOZZ	362X10	79470	ELBOW,PIPE TO TUBE ONE END MALE,1/2 NPT,OTHER END, FEMALE 5/8 IN. TUBE,7/8-16 THD SIZE	EA	1
36	3	XBOZZ	33006X6X5	79470	CONNECTOR,PIPE HYDRAULIC PUMP TO ELBOW,MALE END,3/8 NPT THD SIZE,FEMALE END,1/2 NPT	EA	1
36	4	PAOZZ	5306-00-200-3313	MS90725-63	SCREW,CAP,HEXAGON HEAD HYDRAULIC TANK MTG, 3/8-16 THD SIZE, 1 1/4 IN. LG	EA	1
36	5	PAOZZ		MS36398-46	WASHER,LOCK HYDRAULIC TANK AND BRACKET MTG,5/8 IN. SCREW SIZE	EA	7
36	6	XBOZZ	14896A	26306	SPACER HYDRAULIC TANK TO FILTER BRACKET,3/8 IN. ID,3/4 IN. OD, 3/16 IN. THK	EA	2
36	7	PAOZZ	5306-00-200-3312	MS90725-61	SCREW,CAP,HEXAGON HEAD HYDRAULIC TANK AND BRACKET MTG, 3/8-16 THD SIZE,3/4 IN. LG	EA	4
36	8	XBOZZ	13216E00067	97403	TANK ASSEMBLY,HYDRAULIC	EA	1
36	9	PAOZZ	4730-00-492-4235	MS27141-5-0124	HOSE ASSEMBLY,RUBBER HYDRAULIC TANK TO ACTUATOR	EA	1
36	10	XBOZZ	402X10	79470	ELBOW,PIPE TO TUBE HYDRAULIC SUPPLY TUBE,ONE END MALE, 1/2 NPT,OTHER END FEMALE,5/8 IN. TUBE,7/8-16 THD SIZE	EA	1
36	11	PAOZZ	4730-00-121-0138	C5406X5X4	ELBOW,PIPE TO TUBE MALE ONE END,1/4 NPT, OTHER END, 5/16 IN. TUBE,1/2-20 THD SIZE	EA	1
36	12	PAOZZ	4730-00-012-7951	3152X4	PLUG,PIPE HYDRAULIC TANK DRAIN,1/4 NPT,HEXAGON HEAD	EA	1
36	13	PAOZZ	0880-00-152-2180	13216E00069	CAP ASSEMBLY HYDRAULIC TANK	EA	1
36	14	XBOZZ	MS20365-1032	98006	NUT,SELF-LOCKING,HEXAGON CHAIN MTG,NO. 10-32 THD SIZE	EA	1
36	15	PAOZZ	5310-00-800-8546	MS27183-8	WASHER,FLAT CHAIN,NO. 10 SCREW SIZE	EA	1
36	16	PAOZZ	4030-00-270-5436	MS87006-3	HOOK,CHAIN	EA	1
36	17	XBOZZ	MS17311-1	98006	CHAIN	FT	V
36	18	XBOZZ	13216E00069	97403	CAP,FILLER	EA	1
36	19	XBOZZ	13216E00063	97403	STICK,DIP	EA	1
36	20	PAOZZ	2910-00-152-2180	13216E00063	TANK,HYDRAULIC	EA	1
36	21	XBOZZ	MS36398-622	98006	NUT,PLAIN,HEXAGON HYDRAULIC TANK BRACKET MTG, 3/8-24 THD SIZE	EA	2
36	22	XBOZZ	13216E00069	97403	BRACKET HYDRAULIC TANK MTG	EA	1
36	23	XBOZZ	265561A	26626	GASKET HYDRAULIC TANK BRACKET MOUNTING	EA	1
36	24	XBOZZ	MS15066	98006	STUD,PLAIN HYDRAULIC TANK BRACKET MTG,ONE END,3/8-16 THD SIZE,OTHER END,3/8-24 THD SIZE,1 1/4 IN. O/A LG	EA	2
36	25	XBOZZ	C5625X5	79470	ELBOW 5/16 IN. TUBE,1/2-20 THD SIZE	EA	1
36	26	PAOZZ	5300-00-248-3838	MS36398-013	PACKING, PREFORMED	EA	1
36	27	XBOZZ	MS39331G4	98006	ADAPTER,PIPE TO TUBE HYDRAULIC ELBOW TO ACTUATOR, MALE ONE END,1/2-20,OTHER END, 5/16 IN. TUBE, 1/2-20 THD SIZE	EA	1

TS 6115-449-20P/36





Figure 36. Hydraulic tank

(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN U/M UNIT
37	1	PAOZZ	4730-00-894-6349	MS38741-4-0164	98806	HOSE ASSEMBLY HYDRAULIC FILTER	EA 1
37	2	XBOZZ	4730-00-815-0271	6C80X3	45881	ELBOW	EA 2
37	3	PAOZZ	5305-00-071-2237	MS90725-14	98806	SCREW,CAP,HEXAGON HEAD FILTER MTG	EA 2
37	4	PAOZZ	5319-00-582-5965	MS35338-44	98806	WASHER,LOCK FILTER MTG	EA 2
37	5	PAOZZ	1650-00-288-0806	MS26730-6	98806	FILTER,HYDRAULIC	EA 1
37	6	PAOZZ	4330-00-543-2060	AN6335-2A	88044	ELEMENT,FILTER	EA 1
37	7	PAOZZ	5330-00-171-6649	MS26775-223	98806	PACKING,PREFORMED	EA 1



TS 6115-449-20P/37

Figure 37. Hydraulic filter

(1) ITEM NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION	(8) Usable On Code	(9) U/M	(10) QTY INC IN UNIT
(1) ITEM NO.	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)
GROUP 17 ENGINE ASSEMBLY									
28	1	XBOE2		6861	26472	BELT,V ALTERNATOR AND FAN DRIVE,1/2 IN. W,56 1/4 IN. LG	EA	1	
28	2	PAOE2	8310-00-880-7744	M8851987-5	98888	NUT,PLAIN,HEXAGON ALTERNATOR ADJUSTING STRAP, THD SIZE	EA	1	
28	3	XBOE2		13810E20000	97403	L.T,MACHINE ALTERNATOR ADJUSTING STRAP,5/16-18 THD SIZE, 1 1/4 IN. LG	EA	1	
28	4	PAOE2	8310-00-874-0023	M8853238-140	98888	WASHER,LOCK ALTERNATOR ADJUSTING STRAP, 5/16 IN. SCREW SIZE	EA	1	
28	5	PAOE2	8310-00-881-4210	M8857188-12	98888	WASHER,FLAT ALTERNATOR ADJUSTING STRAP, 5/16 IN. SCREW SIZE	EA	1	
28	6	XBOE2		13810E20000	97403	BRACKET ALTERNATOR ADJUSTING	EA	1	
28	7	PAOE2	8308-00-728-4187	M8860728-114	98888	SCREW,CAP,HEXAGON HEAD ALTERNATOR MTG,1/2-20 THD SIZE, 1 3/4 IN. LG	EA	1	
28	8	PAOE2		M886328-48	98888	WASHER,LOCK ALTERNATOR MTG,1/2 IN. SCREW SIZE	EA	1	
28	9	PAOE2	8308-00-880-3314	M8860728-44	98888	SCREW,CAP,HEXAGON HEAD ALTERNATOR BRACKET MTG, 3/8-16 THD SIZE,1 1/2 IN. LG	EA	1	
28	10	PAOE2		M886328-48	98888	WASHER,LOCK ALTERNATOR BRACKET MTG,3/8 IN. SCREW SIZE	EA	2	
28	11	PAOE2	8308-00-728-0480	M8860728-08	98888	SCREW,CAP,HEXAGON HEAD ALTERNATOR BRACKET MTG, 3/8-16 THD SIZE,2 IN. LG	EA	1	
28	12	XBOE2		13810E20004	97403	BRACKET ALTERNATOR MTG	EA	1	
28	13	PAOEF	2080-00-110-1222	13810E3175-2	97403	ALTERNATOR BATTERY CHARGING	EA	1	
28	14	PAOE2	2080-00-131-0007	68861987	94713	FUSE ALTERNATOR,40 AMP,35V	EA	1	





Figure 38. Alternator and drive belt

TS 6115-449-20P/38


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(9)	(10)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG. NO.	ITEM NO.	SMR CODE				U/M	
40	1	PA00Z	5310-00-733-0656	M561967-6	96006 NUT,PLAIN,HEXAGON OVERSPEED SWITCH CLAMP, 3/8-16 THD SIZE	EA	1
40	2	PA00Z		M563330-48	96006 WASHER,LOCK OVERSPEED SWITCH CLAMP,3/8 IN. SCREW SIZE	EA	1
40	3	PA00Z	5305-00-507-0036	122104	12204 SCREW,CAP,HEXAGON HEAD OVERSPEED SWITCH CLAMP, 3/8-16 THD SIZE,5/8 IN. LG	EA	1
40	4	XBO0Z		1221020017	97403 CLAMP OVERSPEED SWITCH	EA	1
40	5	PA00Z	5300-00-157-0026	1221020000	97403 SWITCH,OVERSPEED	EA	1
40	6	XBO0Z		1221020007	97403 BRACKET, OVERSPEED SWITCH	EA	1
40	7	PA00Z	5305-00-119-0033	1221020177	97403 TRANSMITTER,ENGINE TEMPERATURE	EA	1
40	8	PA00Z	5300-00-503-0044	1221420106	97403 SWITCH,PRESSURE OIL	EA	1
40	9	XBO0Z		3995X3	79470 NIPPLE,PIPE,HEXAGON OIL PRESSURE SWITCH MTG,1/8-27 THD SIZE, MALE,BRASS	EA	1
40	10	XBO0Z		1221020072	97403 TRANSMITTER,PRESSURE OIL	EA	1
40	11	PA00Z	5300-00-179-0003	1221420105-3	97403 ENGINE SWITCH,TEMPERATURE	EA	1



TS 6115-449-20P/40

Figure 40. Switches and transmitters


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER			PART NUMBER	FSCM	QTY INC IN UNIT
41	1	XBOZZ		MS28741-16-0100	97403	HOSE ASSEMBLY OIL DRAIN	EA 1
41	2	PAOZZ	4730-00-133-3356	13316E33384	97403	ADAPTER, STRAIGHT, PIPE TO TUBE OIL DRAIN, MALE ONE END, 3/4-14 THD SIZE, OTHER END, 3/4 IN. TUBE, 1 5/16-12 THD SIZE	EA 2
41	3	XBOZZ	4830-00-482-3614	13316E33390-2	97403	VALVE, SHUT-OFF OIL DRAIN	EA 1
41	4	XBOZZ		3-4FFB	36327	NIPPLE, PIPE, HEXAGON OIL DRAIN, 3/4-14 THD SIZE, MALE, BRASS	EA 1
41	5	PAOZZ	4730-00-951-1928	13316E33395	97403	ELBOW, PIPE, STREET OIL DRAIN, 3/4 NPT	EA 1
41	6	XBOZZ	5310-00-913-0681	MS61971-3	90006	NUT, PLAIN, HEXAGON GROUND LUG, 3/8-16 THD SIZE	EA 1
41	7	PAOZZ	5310-00-973-8786	MS35338-142	90006	WASHER, LOCK GROUND LUG, 7/16 IN. SCREW SIZE	EA 1
41	8	PAOZZ	5305-00-269-3211	MS90725-00	90006	SCREW, CAP, HEXAGON HEAD GROUND LUG, 3/8-16 THD SIZE, 1 IN. LG	EA 1
41	9	XBOZZ	5075-00-230-0696	13316E33392	97403	LUG, GROUND	EA 1



TS 6115-449-20P/41

Figure 41. Oil drain

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
43	1	XBOZZ		MS35000-022	90006	NUT,PLAIN,HEXAGON INTAKE MANIFOLD MTG,3/8-24 THD SIZE	EA 8
43	2	PAOZZ	5310-00-543-5101	MS35338-27	90006	WASHER,LOCK MANIFOLD MTG,3/8 IN. SCREW SIZE	EA 8
43	3	XBOZZ		200079D	28265	MANIFOLD AIR INTAKE	EA 1
43	4	PAOZZ		97A	28265	GASKET PART OF KIT P/N 201968AS	EA 1
43	5	XBOZZ	5307-00-005-8227	13114A	28265	STUD,PLAIN AIR CLEANER MTG,ONE END,1/2-18 THD SIZE,OTHER END,1/2-20 THD SIZE,2 1/16 IN. LG	EA 2
43	6	XBOZZ		11083A	28265	STUD MANIFOLD MTG	EA 8
43	7	XBOZZ		13123A	28265	NUT,PLAIN,HEXAGON MANIFOLD MTG,7/16-20 THD SIZE	EA 12
43	8	XBOZZ		2306A	28265	WASHER,SPECIAL EXHAUST MANIFOLD,1 IN. OD,15/32 IN. ID,5/32 IN. THICK	EA 12
43	9	XBOZZ		200339D	28265	MANIFOLD,EXHAUST	EA 1
43	10	PAOZZ	5305-00-171-7034	70036A	28265	GASKET,MANIFOLD EXHAUST PART OF KIT P/N 201968AS	EA 6
43	11	PAOZZ	5307-00-005-8227	13114A	28265	STUD,PLAIN MANIFOLD MTG,7/16-14 THD SIZE,1 5/8 IN. LG	EA 12



TS 6115-449-20P/43

Figure 43. Manifolds

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
(a)	(b)	NATIONAL STOCK NUMBER			PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE					Usable On Code U/M	
46	1	XBOZZ	5310-00-064-0751	MS36000-032	90006	NUT,PLAIN,HEXAGON	SWITCH LEAD MTG,NO. 8-32 THD SIZE	EA 1
46	2	XBOZZ		MS36330-32	90006	WASHER,LOCK	SWITCH LEAD MTG,NO. 8 SCREW SIZE	EA 1
46	3	PAOZZ		MS36330-031	90006	NUT, PLAIN, HEXAGON		EA 3
46	4	PAOZZ	5310-00-073-0373	9421426	10764	WASHER,LOCK	LEAD ATTACHING, 5/16 IN. SCREW SIZE	EA 2
46	5	XBOZZ	5306-01-014-4250	201752A	20206	SCREW,CAP,HEXAGON HEAD	STARTER MTG, 5/16-11 THD SIZE, 1 3/8 IN. LG	EA 3
46	6	PAOZZ		201800A	20206	WASHER,LOCK	STARTER MTG, 5/8 IN. SCREW SIZE	EA 3
46	PAOZZ		5306-00-073-0043	1112106	10764	STARTER,ENGINE,ELECTRIC		EA 1
46	10	PAOZZ	5306-00-036-4276	1917034	10764	BOLT,EXTERNALLY RELIEVED BODY	SWITCH MTG, 1/4-20 THD SIZE, 1/2 IN. LG	EA 4
46	20	PAOZZ	5306-00-064-0046	1115006	10764	RELAY SOLENOID,ENGINE STARTER		EA 1




Figure 45. Starter

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER			PART NUMBER	F9CM	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE				DESCRIPTION	Usable On Code U/M
46	1	XBOZZ		MS28741-8-143	98806	HOSE ASSEMBLY,RUBBER OIL FILTER INLET	EA 1
46	2	PAOZZ	4730-00-802-8156	MS28741-8-0170	98806	HOSE ASSEMBLY,RUBBER OIL FILTER OUTLET,11 1/4 IN. LG	EA 1
46	3	PAOZZ	5308-00-724-5906	MS20725-156	98806	SCREW,CAP,HEXAGON HEAD OIL FILTER BRACKET MTG, 5/8-18 THD SIZE,3/4 IN. LG	EA 2
46	4	XBOZZ		MS36338-31	98806	WASHER,LOCK OIL FILTER BRACKET MTG,5/8 IN. SCREW SIZE	EA 2
46	5	XBOZZ		MS36090-502	98806	NUT,PLAIN,HEXAGON OIL FILTER MTG,5/16-18 THD SIZE	EA 4
46	6	PAOZZ	5310-00-012-0214	MS35338-36	98806	WASHER,LOCK OIL FILTER MTG,5/16 IN. SCREW SIZE	EA 4
46	7	PAOZZ	5308-00-225-8497	MS20725-32	98806	BOLT,MACHINE OIL FILTER MTG,5/16-18 THD SIZE,3/4 IN. LG	EA 4
46	8	PAOZZ	5310-00-061-4219	MS27183-12	98806	WASHER,FLAT OIL FILTER MTG,5/16 IN. SCREW SIZE	EA 4
46	9	XBOZZ		290777C	28265	BRACKET,FILTER,OIL	EA 1
46	10	PAOZZ	4730-00-555-1764	5822X8	79470	ELBOW,PIPE TO TUBE	EA 4
46	11	PAOZZ	4730-00-013-7409	200X8	79470	ADAPTER,STRAIGHT,PIPE OIL FILTER LINES	EA 2
46	12	XBOZZ	2940-00-720-4969	2468	73370	FILTER,OIL ENGINE LUBRICATION	EA 1
46	13	XBOZZ		13446	73370	NUT,PLAIN,SQUARE FILTER STRAP,1/4-20 THD SIZE	EA 1
46	14	XBOZZ		10092	73370	BOLT,MACHINE STRAP TO FILTER	EA 1
46	15	PAOZZ	5310-00-274-8715	10124	73370	WASHER,LOCK STRAP TO FILTER	EA 1
46	16	XBOZZ	2910-00-368-1909	10768	73370	STRAP OIL FILTER MTG	EA 1
46	17	XBOZZ		2563	73370	BOLT AND VALVE ASSEMBLY COVER	EA 1
46	18	PAOZZ	5310-00-297-2275	101979	73370	WASHER,NONMETALLIC COVER BOLT	EA 1
46	19	XBOZZ	2520-00-771-5276	103326	73370	COVER,FILTER	EA 1
46	20	XBOZZ	4330-00-724-1463	118940	73370	SPRING ASSEMBLY,FILTER	EA 1
46	21	PAOZZ	5330-00-171-7032	MS35347-1	98806	GASKET OIL FILTER COVER	EA 1
46	22	XBOZZ	2940-00-560-6304	MS35802-2	98806	FILTER ELEMENT,FLUID PRESSURE	EA 1
46	23	PAOZZ	4730-00-287-3281	10428	73370	PLUG,PIPE FILTER DRAIN	EA 1
46	24	XAOZZ		8715	73370	BODY	EA 1





Figure 46. Oil filter

TS 6115-449-20P/43

(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG. NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY IN UNIT
47	1	PAOZZ	5305-00-068-0502	M830725-6	98806	SCREW,CAP,HEXAGON HEAD FUEL LINE BRACKET,1/4-20 THD SIZE, 3/4 IN. LG	EA 4
47	2	PAOZZ	5310-00-582-5965	M835338-26	98806	WASHER,LOCK FUEL LINE BRACKET AND CLAMP, 1/4 IN. SCREW SIZE	EA 8
47	3	XBOZZ		203997A	28265	BRACKET,CLAMP FUEL LINE	EA 1
47	4	XBOZZ	5340-00-364-1485	88133A	28265	STRAP,RETAINING FUEL LINE,REAR	EA 1
47	5	XBOZZ		660A	28265	SCREW,CAP,HEXAGON HEAD FUEL LINE CLAMP,1/4-20 THD SIZE, 5/8 IN. LG	EA 4
47	7Z			28266A	28265	CLAMP,LINE FUEL	EA 2
47	7Z		20-00-061-540	283536AS	28265	LINE ASSEMBLY,FUEL INJECTOR,NO. 3	EA 1
47	7Z		20-00-061-540	283535AS	28265	LINE ASSEMBLY,FUEL INJECTOR,NO. 2	EA 1
47	9	XAO7Z	20-00-061-540	283534AS	28265	LINE ASSEMBLY,FUEL INJECTOR,NO. 1	EA 1
47	10	XBOZZ		283533AS	28265	TUBE ASSEMBLY,METAL LEAKOFF,NO. 1,CYLINDER TO FUEL PUMP	EA 1
47	11	PAOZZ	53-65-00-973-7803	203896A	28265	GROMMET,TUBE LEAKOFF TUBE	EA 1
47	12	PAOZZ	2910-00-061-5397	283537AS	28265	LINE ASSEMBLY,FUEL INJECTOR,NO. 4	EA 1
47	13	PAOZZ	4-10-00-061-5416	283538AS	28265	TUBE ASSEMBLY,METAL INJECTOR,NO. 5	EA 1
47	14	PAOZZ	4710-00-061-5418	283539AS	28265	TUBE ASSEMBLY,METAL INJECTOR,NO. 6	EA 1
47	15	PAOZZ	4710-00-061-5057	290577AS	28265	TUBE ASSEMBLY,METAL LEAKOFF,NO. 6 AND NO. 3	EA 2
47	16	XBOZZ		290516AS	28265	TUBE ASSEMBLY,METAL LEAKOFF,NO. 4	EA 1
47	17	XBOZZ		290515AS	28265	TUBE ASSEMBLY,METAL BLEED OFF,NO. 6 AND NO. 2	EA 2
47	18	PAOZZ	4730-00-063-0672	51X3	78470	TEE,PIPE TO TUBE LEAKOFF LINES,MALE,FIRST END 1/8 NPT, SECOND AND THIRD ENDS,3/16 IN. TUBE,3/8-24 THD SIZE	EA 8
47	19	PAOZZ	47-00-061-972-1630	49X3	78470	ELBOW,PIPE TO TUBE LEAKOFF TUBE TO NO. 6 INJECTOR, MALE, ONE END,1/8 NPT, OTHER END,3/16 IN. TUBE,3/8-24 THD SIZE	EA 1



TS 6115-449-20P/47

Figure 47. Fuel injector lines

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	PSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE				U/M	
51	1	PA00Z	5300-01-014-4262	2000A	20005 SCREW,FAN BLADE 5/16-18 THD SIZE,7/8 IN. LG	EA	4
51	2	PA00Z	5310-00-010-3220	618A	20005 WASHER,LOCK FAN BLADE MTG,5/16 IN. SCREW SIZE	EA	4
51	3	PA00Z	2000-00-100-2000	200000D	20005 FAN	EA	1
51	4	XBO0Z		C3170X4	70470 PLUG,PIPE WATER INLET PIPE,1/4 NPT,SQUARE HEAD	EA	1
51	5	PA00Z	5300-00-020-0604	M200720-40	20005 BOLT,MACHINE WATER INLET PIPE MTG,5/16-18 THD SIZE,3 IN. LG	EA	1
51	6	PA00Z	5310-00-012-0214	M200320-26	20005 WASHER,LOCK WATER INLET PIPE MTG,5/16 IN. SCREW SIZE	EA	2
51	7	PA00Z	5300-00-700-0220	204220A	20005 SCREW,MACHINE WATER INLET PIPE MTG,5/16-18 THD SIZE,3 3/8 IN. LG	EA	1
51	8	XBO0Z		200710C	20005 PIPE,RADIATOR INLET	EA	1
51	9	PA00Z	5300-00-070-0017	200005A	20005 GASKET INLET 10 PART OF KIT P/N 200000CS	EA	1
51	10	XBO0Z	4730-00-104-7710	200005	20005 CLAMP,HOSE BY-PASS	EA	1
51	11	XBO0Z		200001B	20005 CLAMP,HOSE BY-PASS	E	1
51	12	XBO0Z		200702B	20005 HOSE,BY-PASS WATER PUMP	EA	1
51	13	PA00Z		204420A	20005 SCREW,CAP,HEXAGON HEAD WATER PUMP MTG,7/16-14 1/8 THD SIZE, 3 1/8 IN. LG	EA	3
51	14	XBO0Z		M200320-26	20005 WASHER,LOCK WATER PUMP MTG,7/16 IN. SCREW SIZE	EA	3
51	15	PA00Z	5300-00-040-0446	200005A	20005 GASKET WATER PUMP MTG 30-070-3010 PART OF KIT P/N 200000CS	EA	1
51	16	XBO0Z		200040S	20005 PUMP ASSEMBLY,WATER	EA	1
51	PA00Z	2000-00-070-0018	200000CS	20005 ASSEMBLY,SHAFT AND BEARING WATER PUMP	EA	1	
51	9				GASKET	EA	1
51	15				GASKET	EA	1




Figure 51. Water pump and fan

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
22	1	PAGEZ	4730-00-078-3413	4312A	20205 PLUG,PIPE THERMOSTAT SPACER AND COVER,1/2-14 THD SIZE	EA	3
22	2	PAGEZ	5330-00-078-3016	M2000725-60	90006 SCREW,CAP,HEXAGON HEAD WATER OPENING COVER,3/8-16 THD SIZE, 7/8 IN. LG	EA	4
22	3	PAGEZ	5310-00-543-5101	M2000725-37	90006 WASHER,LOCK THERMOSTAT HOUSING AND OPENING COVER MTG, 3/8 IN. SCREW SIZE	EA	8
22	4	XBOEZ		200700A	20205 COVER,WATER OUTLET	EA	1
22	5	PAGEZ	2000-00-078-3014	200701A	20205 GASKET COVER PART OF KIT P/N 291968AS	EA	1
22	6	PAGEZ	5305-00-702-0238	M2000725-75	90006 SCREW,CAP,HEXAGON HEAD THERMOSTAT HOUSING MTG, 3/8-16 THD SIZE,4 1/4 IN. LG	EA	4
22	7	PAGEZ	5340-00-705-7007	200004A	20205 PLUG,CUP THERMOSTAT HOUSING,0.377 TO 0.384 IN. DIA,7/32 IN. H	EA	1
22	8	XBOEZ		200700C	20205 HOUSING,THERMOSTAT	EA	1
22	9	PAGEZ	5330-00-071-0007	200701A	20205 GASKET THERMOSTAT HOUSING PART OF KIT P/N 291968AS	EA	2
22	10	PAGEZ	0220-00-041-1002	M2000770-1	90006 THERMOSTAT,FLOW CONTROL	EA	1
22	11	XBOEZ		200702B	20205 SPACER,HOUSING,THERMOSTAT	EA	1





Figure 52. Thermostatic water inlet and outlet assembly

TS 6115-449-20P/52

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
53	1	PAGEZ	2888-00-108-7056	288800B		28886 GAGE,BAYONET OIL LEVEL	EA 1
53	3	XPOEZ		08A		28885 PLUG,PIPE OIL PAN,1/4-18 THD SIZE	EA 1



TS 6115-449-20P/53

Figure 53 Oil Pan

(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG. NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
57	1	XBOZZ		A3482	74898	CAP,BREATHER CYLINDER HEAD COVER	EA 1
57	2	PAOZZ	5330-00-531-2587	201184A	28365	GASKET BREATHER	EA 2
57	3	PAOZZ	5310-00-703-8211	203045A	28365	NUT,SPECIAL VALVE COVER MTG,3/8-24 THD SIZE	EA 3
57	4	PAOZZ	5310-00-050-2241	4023A	28365	WASHER,FLAT COVER,3/8 IN. SCREW SIZE	EA 3
57	5	PAOZZ	5310-00-987-6365	206432A	28365	GASKET CYLINDER HEAD COVER SCREW	EA 3
57	6	XBOZZ	2815-00-085-5577	285203E	28365	COVER CYLINDER HEAD	EA 1
57	7	PAOZZ	5330-00-078-3823	285213C	28365	GASKET CYLINDER HEAD COVER PART OF KIT P/N 201988AS	EA 1
		PAOZZ	5330-00-863-3742	291988AS	28365	KIT,GASKET VALVE GRIND	EA 1
43	4					GASKET, MANIFOLD	EA 1
43	10					GASKET,MANIFOLD	EA 6
52	5					GASKET	EA 1
52	9					GASKET	EA 2
57	7					GASKET	EA 1





Figure 57. Cylinder head cover

TS 6115-449-20P/57

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(C)	(D)	NATIONAL STOCK NUMBER	PART NUMBER	F9CM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG. NO.	ITEM NO.	SMR CODE				U/M	
06	13	XBOEZ	C12643	81116	CAP,OIL FILLER	EA	1
06	14	XBOEZ	0115-00-830-0403	283330A8	28365 CHAIN AND PIN ASSEMBLY CAP RETAINING	EA	1
06	20	PAOEZ	4730-00-278-3033	28158A	28365 PLUG, ENGINE BLOCK, SIDE AND REAR, 3/8-16 THD SIZE	EA	2
06	23	PAOEZ	4730-00-610-3076	7100A	28365 PLUG, PIPE, ENGINE BLOCK, RIGHT SIDE, 1 IN.	EA	1
06	26	XBOEZ	00A	28365 PLUG, PIPE, ENGINE BLOCK, RH, 1/4-18 THD SIZE	EA	1	
06	31	PAOEZ	4730-00-278-3307	50A	28365 PLUG, PIPE, ENGINE BLOCK, LH, 1/8-27 THD SIZE	EA	4
06	22	XBOEZ	13331A	28365 PLUG, PIPE, ENGINE BLOCK, 1/8-27 THD SIZE	EA	2	
06	33	PAOEZ	4730-00-614-4734	630A	28365 PLUG, PIPE, CYLINDER BLOCK, LH, 1/4 NPT	EA	1





Figure 63. Cylinder block.

TS 6115-449-20P/63


(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	PCN	DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG. NO.	ITEM NO.	SMR CODE				U/M	
GROUP 18 BASE GROUP							
64	1	PAOZZ	5310-00-543-2628	MS35000-002	98006 NUT,PLAIN,HEXAGON TOOL BOX MTG,3/8-16 THD SIZE	EA	8
64	2	PAOZZ	5310-00-627-6128	MS35336-35	98006 WASHER,LOCK TOOL BOX MTG,3/8 IN. SCREW SIZE	EA	8
64	3	PAOZZ	5305-00-369-3200	MS80725-55	98006 SCREW,CAP,HEXAGON HEAD TOOL BOX MTG,3/8-16 THD SIZE, 3/4 IN. LG	EA	8
64	4	XBOZZ		13216E0046	97403 BOX,TOOL	EA	1
64	5	PAOZZ	4730-00-238-2657	MS28741-5-0142	98006 HOSE ASSEMBLY FUEL TANK SUPPLY	EA	1
64	6	XBOZZ		13214E3350-6	97403 TUBE ASSEMBLY,FUEL	EA	1
64	7	XBOZZ		13214E3350-4	97403 TUBE ASSEMBLY,FUEL	EA	1
64	8	XBOZZ		13214E3350-6	97403 TUBE ASSEMBLY,FUEL	EA	1
64	9	PAOZZ	4730-00-287-1707	702X4	98470 TEE,TUBE FUEL LINE CONNECTING,ALL ENDS FEMALE,1/4 IN. TUBE, 7/16-24 THD SIZE	EA	1
64	10	PAOZZ	4730-00-277-8643	13216E3322	97403 ELBOW,PIPE TO TUBE FUEL TANK DRAIN LINE, ONE END MALE, 1/4-16 THE SIZE, OTHER END FEMALE,3/16 IN. TUBE,7/16-24 THD SIZE	EA	2
64	11	PAOZZ	4730-00-121-0138	C5405X5X4	98470 ELBOW,PIPE TO HOSE FUEL SUPPLY HOSE TO TANK,MALE, ONE END 1/4-18 THD SIZE,OTHER END 5/16 IN. TUBE,1/2-20 THD SIZE	EA	1
64	17	PAOZZ	5305-00-036-0006	13214E3290-50	97403 SCREW,ASSEMBLED WASHER FUEL TANK SENSOR MTG, NO. 10-24 THD SIZE,1/2 IN. LG	EA	8
64	18	XBOZZ		13216E0027	97403 SENSOR,FUEL LEVER	EA	1
64	19	PAOZZ	5330-00-178-1457	13214E3254	97403 GASKET FUEL SENSOR	EA	1
64	23	XBOZZ	4730-00-135-6345	13206E9192-2	97403 CAP AND RETAINER FUEL TANK DRAIN	EA	2
64	24	XBOZZ	4820-00-595-3191	13214E3243	97403 COCK,SHUTOFF,SCREW FUEL TANK DRAIN	EA	2



TS 6115-449-20P/64

Figure 64. Fuel Tank

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	QTY INC IN UNIT
65	1	PAOZZ	5310-00-880-7744	MS51967-5	98804 NUT,PLAIN,HEXAGON GROUND TERMINAL,5/16-18 THD SIZE	EA	1
65	2	PAOZZ	5310-00-880-2527	MS45804-72	98805 WASHER,LOCK GROUND TERMINAL MTG,5/16 IN. SCREW SIZE	EA	1
65	3	XBOZZ	5840-00-140-7050	13316E3377	97403 POST,TERMINAL,GROUND	EA	1
65	4	PAOZZ	5310-00-062-3632	13314E3291-3	97403 NUT,ASSEMBLED WASHER OIL DRAIN PLUG RETAINING, NO. 8-32 THD SIZE	EA	1
65	5	XBOZZ		MS24584-47	98806 SCREW,MACHINE OIL DRAIN PLUG RETAINING,NO. 8-32 THD SIZE, 1/8 IN. LG	EA	1
65	6	XBOZZ	4730-00-177-0035	13314E3238	97403 DRAIN PLUG ASSEMBLY OIL	EA	1
65	7	PAOZZ	5305-00-576-5417	MS35307-360	98806 SCREW,CAP,HEXAGON HEAD BATTERY TRAY MTG, 3/8-16 IN. THD SIZE, 1 IN. LG	EA	4
65	8	XBOZZ	5310-00-080-6004	MS27163-14	98806 WASHER,FLAT BATTERY TRAY MTG,3/8 IN. SCREW SIZE	EA	4
65	9	XBOZZ		13316E3065	97403 TRAY,BATTERY	EA	1
65	10	PAOZZ		MS665310-0	06288 NUT,PLAIN,HEXAGON CABLE CLAMP MTG,NO. 10-32 THD SIZE	EA	2
65	11	PAOZZ	5310-00-596-7001	MS35335-32	98806 WASHER,LOCK CABLE CLAMP MTG,NO. 10 SCREW SIZE	EA	2
65	12	XBOZZ		MS35217-55	98806 SCREW,MACHINE CARLE CLAMP MTG,NO. 10-32 THD SIZE,1/8 IN. LG	EA	2
65	13	XBOZZ		MS21333-00	98806 CLAMP,LOOP	EA	2



(1) ITEM NO.	(2) ITEM NO.	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	(7) Usable On Code	(8) U/M	(9) QTY IN UNIT
GROUP 19 ACCESSORY ITEMS								
66	1	PAOZZ	6180-00-197-4084	13214E7000-2	97403 CABLE ASSEMBLY, PARALLELING	EA	1	
66	2	MFOO	4720-00-021-3320	13211E6770	97403 HOSE ASSEMBLY, RUBBER AUXILIARY FUEL	EA	1	
66	2A	PAOZZ	4730-00-842-2201	MS24587-5	96906 FITTING, HOSE	EA	2	
66	2B	PAOZZ	4720-00-289-9197	MILH6794-6	81349 HOSE, RUBBER	PT	V	
66	2C	PAOZZ	4730-00-040-7450	5LHBTYB	45681 UNION, FLARED	EA	1	
66	2D	PAOZZ	4010-00-186-9412	RRC271TYPE	81348 CHAIN	EA	1	
66	3	PAOZZ	5340-00-543-3321	13216E3191	97403 STRAP, WEBBING HOSE AND CABLE STOWAGE	SA	1	





Figure 66. Accessory items.


(1) ILLUS (a)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG. NO.	ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	QTY INC IN UNIT
GROUP 20 WINTERIZATION EQUIPMENT							
67	7	XBOZZ	12216E0006	97403	SWITCH, TEMPERATURE	EA	1
67	12	PAOZZ	4730-00-000-3103	MS36642-12	98806 CLAMP,HOSE HEATER EXHAUST ELBOW	EA	2
67	13	XBOZZ	13316E3147	97403	ELBOW,EXHAUST HEATER	EA	1
67	14	PAOZZ	5318-00-727-8731	MS171629	98806 PIN,SPRING EXHAUST CAP MTG,0.125 IN. DIA,0.688 IN. LG	EA	1
67	15	XBOZZ	13316E3148	97403	CAP,HEATER EXHAUST	EA	1
67	16	XBOZZ	13316E3149	97403	TAIL PIPE HEATER EXHAUST	EA	1
67	17	XBOZZ	MS28741-5-0206	98806	HOSE ASSEMBLY FUEL	EA	1
67	19	PAOZZ	4730-00-236-3056	MS28741-10-0364	98806 HOSE ASSEMBLY OIL PAN TO THERMOSTAT	EA	1
67	20	XBOZZ	MS28741-10-0186	98806	HOSE ASSEMBLY HEATER TO OIL PAN	EA	1
67	21	PAOZZ	4730-00-222-8715	MS28741-10-0364	98806 HOSE ASSEMBLY HEATER TO CYLINDER BLOCK	EA	1
67	22	PAOZZ	4730-00-061-0780	C5405X10	78470 ELBOW,PIPE TO TUBE WATER HOSE CONNECTING,MALE, ONE END 1/2 NPT,OTHER END 5/8 IN. TUBE,7/8-14 THD SIZE	EA	5
67	23	XBOZZ	4830-00-136-1600	13311E0742	97403 COCK,SHUTOFF HEATER,WATER	EA	2
67	24	XBOZZ	3336X8	78470	NIPPLE,PIPE,HEXAGON COOLANT INLET AND OUTLET LINE, 1/2-14 THD SIZE,BRASS	EA	2
67	26	XBOZZ	3400X8	78470	ELBOW,PIPE COOLANT LINE TO THERMOSTAT HOUSING, 1/2 NPT STREET	EA	1



TS 6115-449-20P/67

Figure 67. Heater Mounting Components, Lines and Fittings

(1) ILLUS	(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a)	(b)	NATIONAL			DESCRIPTION	Usable On Code	QTY INC IN UNIT
FIG NO.	ITEM NO.	SMR CODE	STOCK NUMBER	PART NUMBER			
00	XBOZZ	6115-00-225-4703	13214E5155	97403	CONTROL BOX ASSEMBLY,HEATER	EA	1
00	1	PAOZZ	5305-00-054-0060	M851957-36	96906 SCREW,MACHINE PLATE AND CIRCUIT BREAKER MTG,NO. 6-32 THD SIZE,1/4 IN. LG	EA	4
00	2	PAOZZ	5310-00-579-0079	M836333-37	96906 WASHER,LOCK PLATE,COVER AND CIRCUIT BREAKER MTG, NO. 6 SCREW SIZE,IT	EA	6
00	3	PAOZZ	5305-00-054-0040	M851957-35	96906 SCREW,MACHINE COVER MTG,NO. 6-32 THD SIZE,3/16 IN. LG	EA	2
00	4	XBOZZ		13214E5160	97403 COVER,BOX	EA	1
00	5	PAOZZ	6340-00-155-0714	MS25231-313	96906 LAMP,INCANDESCENT	EA	1
00	6	PAOZZ	6210-00-204-0289	MS25041-4	96906 LIGHT,HEATER	EA	1
00	7	XBOZZ	5025-00-173-7156	MS25017-15	96906 BREAKER,CIRCUIT	EA	1
00	8	PAOZZ	5300-00-055-1575	M836059-22	96906 SWITCH,TOGGLE HEATER CONTROL	EA	1
00	9	XBOZZ		13214E5155	97403 PLATE,FACE	EA	1

TS 6115-449-20P/69
Figure 69. Heater Control Box

(1) REF ID (6)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
(6)	(7)	(8)					QTY INC IN UNIT	
ITEM NO.	ITEM NO.	SER CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION	Usable On Code	U/M
GROUP 21 BULK MATERIAL								
PAGEE			QQ9999			61240 SHEET STEEL		FT V
XBOZ	4710-99-799-0007		538-04			63764 TUBE,COPPER 4 FT,4 IN. REQUIRED		FT V

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5306-00-004-7131	1	9	4730-00-135-6345	30	12
5310-00-010-3330	51	2	4730-00-135-6345	33	11
4730-00-010-3876	63	28	4730-00-135-6345	64	23
4730-00-011-4637	29	2	2920-00-135-6411	13	4T
5310-00-012-0214	46	6	4710-00-135-6412	29	1
5310-00-012-0214	51	6	2910-00-135-6413	30	
4730-00-012-7951	36	12	4820-00-136-1065	67	23
4730-00-013-7400	46	11	2990-00-136-1134	2	6
4730-00-014-0783	30	13	2930-00-136-2099	51	3
4730-00-021-3330	66	2	5120-00-136-8757	23	4
6115-00-033-6833	12	21	6110-00-136-8759	5	
2910-00-036-3612	30	30	5940-00-140-7050	65	3
5306-00-036-6806	11	5	2910-00-141-9758	33	5
5306-00-036-6806	12	14	6240-00-143-3080	9	30
5306-00-036-6806	32	3	2910-00-153-2126	29	25
5306-00-036-6806	64	17	2910-00-153-2188	38	20
5330-00-036-6806	11	6	6460-00-153-2188	36	13
5330-00-036-6806	11	12	6240-00-155-7836	7	11
5330-00-036-6806	11	21	6240-00-155-7878	9	15
5330-00-036-6806	12	5	6240-00-155-8714	9	29
5930-00-044-3518	9	41	6240-00-155-8714	60	5
4730-00-044-4734	63	33	2910-00-156-9228	30	15
5310-00-045-4007	3	2	5340-00-157-9796	34	10
5310-00-050-2241	57	4	5310-00-167-0634	33	10
5310-00-053-3632	9	1	2990-00-167-9860	40	5
5310-00-052-3632	10	1	5340-00-171-2588	33	30
5310-00-052-3632	33	8	5330-00-171-6649	37	7
5310-00-052-3632	65	4	5330-00-171-7032	46	21
5306-00-054-6849	69	3	5330-00-171-7034	43	10
5306-00-054-6850	69	1	5925-00-173-7156	60	7
6140-00-057-2554	1	11	4730-00-177-0035	65	6
5830-00-058-6502	9	36	5998-00-177-1783	29	17
2910-00-061-5397	47	12	5330-00-178-1457	64	19
2910-00-061-5399	47	9	5930-00-179-4882	40	11
2910-00-061-5400	47	7	6685-00-179-8632	27	5
4710-00-061-5416	47	13	4730-00-184-7718	51	10
4710-00-061-5418	47	14	6115-00-185-0682	12	6
4730-00-063-9672	47	18	6115-00-185-0736	1	10
2920-00-064-8946	45	20	5325-00-186-0327	3	11
5330-00-065-6553	3	8	2990-00-192-9266	33	34
4730-00-067-9801			4730-00-194-1715	29	11
5306-00-068-0500	6	1	6460-00-198-7058	53	1
5306-00-068-0500	12	3	4730-00-202-6491	34	4
5306-00-068-0500	12	16	5306-00-207-0928	40	3
5306-00-068-0500	29	25	5310-00-209-0784	5	7
5306-00-068-0502	4	3	5310-00-209-0786	11	2
5306-00-068-0502	5	6	5310-00-209-0786	12	2
5306-00-068-0502	11	1	5310-00-209-0786	13	4
5306-00-068-0502	12	1	5310-00-209-0786	14	19
5306-00-068-0502	12	19	5310-00-209-0786	29	16
5306-00-068-0502	29	15	5310-00-209-0786	33	5
5306-00-068-0502	33	18	5310-00-221-9840	30	25
5306-00-068-0502	33	6	2910-00-222-3216	30	31
5306-00-068-0502	47	1	4720-00-222-8715	67	21
5306-00-071-2236	27	3	4730-00-222-8719	29	13
5306-00-071-2237	37	3	5360-00-224-7579	11	20
2990-00-071-5423	31	9	5306-00-225-3838	1	7
5340-00-079-7837	3	5	5306-00-225-3839	14	18
5310-00-080-6004	34	8	5306-00-225-8494	28	3
5310-00-080-6004	65	8	5306-00-225-8497	18	4
5310-00-081-4219	38	5	5306-00-225-8497	33	13
5310-00-081-4219	46	8	5306-00-225-8497	46	7
2818-00-085-5577	57	6	5306-00-225-8504	51	5
6210-00-107-4121	9	31	6620-00-226-8842	9	20
2910-00-109-3331	30	24	9615-00-230-9628	26	6
6110-00-114-0660	7	3	5075-00-230-9690	41	9
6115-00-114-0663	9	17	4720-00-231-5631	29	12
2920-00-118-1222	38	13	3040-00-234-0274	16	2
2930-00-118-1223	33	24	5306-00-235-2274	30	34
6606-00-119-6662	40	7	6115-00-235-4703	60	
4730-00-121-0138	29	28	4730-00-236-2657	64	5
4730-00-121-0138	30	8	4730-00-236-2658	67	19
4730-00-121-0138	32	15	5920-00-243-3788	8	9
4730-00-121-0138	36	11	5330-00-248-3836	34	6
4730-00-121-0138	64	11	5330-00-248-3838	36	26
5975-00-124-1566	1	3	5330-00-251-4062	33	23
5920-00-131-6697	38	14	5330-00-256-7003	2	7
4720-00-133-3256	41	2	4730-00-268-3696	29	6
4710-00-133-5710	29	18	5306-00-269-3209	30	4
4730-00-138-6345	29	23	5306-00-269-3209	30	5

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5305-00-200-2200	64	3	5310-00-505-7421	14	11
5305-00-200-2210	20	5	5310-00-505-7601	7	2
5305-00-200-2210	53	2	5310-00-505-7601	14	6
5305-00-200-2211	53	21	5310-00-505-7601	23	13
5305-00-200-2211	41	8	5310-00-505-7601	65	11
5305-00-200-2212	36	7	5307-00-005-8227	43	5
5305-00-200-2213	30	1	5307-00-005-8227	43	11
5305-00-200-2213	36	4	5030-00-615-6731	9	27
5305-00-200-2214	30	9	4730-00-020-0004	20	10
5305-00-200-2200	52	6	4730-00-020-0004	22	14
4000-00-270-5436	36	16	5310-00-627-6126	64	2
5310-00-274-0715	46	15	4130-00-633-6302	27	4
4730-00-277-1806	36	14	4810-00-633-6550	20	33
4730-00-277-0643	20	26	5304-00-637-9675	2	8
4730-00-277-0643	64	10	5310-00-638-6385	30	36
4730-00-277-0107	20	14	2910-00-646-9727	31	4
4730-00-278-3023	63	29	5330-00-648-8445	51	15
4730-00-278-3207	63	31	5320-00-655-1514	9	46
4730-00-278-3413	52	1	5330-00-655-1523	9	14
5310-00-284-0200	60	6	5330-00-655-1575	60	8
5305-00-285-5275	33	26	5330-00-655-1581	9	38
4730-00-287-0706	29	5	5330-00-655-1582	9	39
4730-00-287-1797	64	9	5330-00-663-4773	26	30
2010-00-287-1912	30	21	5330-00-663-4773	30	30
2010-00-287-1012	29	20	5330-00-678-3814	52	5
4730-00-287-2261	46	33	5330-00-678-3817	51	9
1000-00-288-0000	37	5	2930-00-678-3818		
5310-00-287-2275	46	18	5330-00-678-3823	57	7
5310-00-289-4104	9	26	5310-00-703-6311	57	3
5305-00-300-0700	11	9	6340-00-705-7007	52	7
5305-00-326-4576	48	19	4730-00-706-2005	20	19
5305-00-343-3306	33	27	2930-00-720-2077	23	23
5340-00-364-1426	47	4	2940-00-720-4050	46	13
2010-00-366-1950	46	16	4330-00-724-1463	48	20
5310-00-373-0573	43	4	5305-00-724-5006	46	3
4730-00-411-5631	32	13	5305-00-726-4187	38	7
4730-00-412-6771	33	3	5025-00-725-0630	4	7
5077-00-419-6734	28	21	5315-00-727-5731	67	14
5075-00-421-0863	5	5	5310-00-723-0558	40	1
5335-00-433-0003	9	11	4830-00-753-9040	30	22
5325-00-437-0004	9	12	4330-00-753-9040	30	27
5315-00-440-2045	9	10	2915-00-753-9138	32	6
4730-00-461-1731	34	1	4710-00-755-0087		
4730-00-477-0670	20	9	5310-00-761-4663	1	5
4730-00-480-4810	20	33	5310-00-761-4663	4	1
6115-00-483-2261	12	10	5310-00-761-4663	12	11
4630-00-483-3614	41	3	5310-00-761-4663	32	16
4730-00-483-4236	36	9	5310-00-761-4663	33	4
4730-00-483-0556	29	10	5305-00-763-6236	51	7
5310-00-514-0074	33	14	5330-00-763-6332	20	21
5320-00-531-2587	57	2	5310-00-767-0445	2	10
4730-00-287-1192	20	16	2530-00-771-5276	46	19
4330-00-543-3000	37	6	4030-00-780-9350	11	10
5310-00-543-2630	64	1	4730-00-781-4997	34	3
5340-00-543-3331	66	3	5045-00-783-0019	10	3
5310-00-543-5093			5330-00-783-6500	9	42
5310-00-543-5101	43	2	5305-00-783-9460	38	11
5310-00-543-5101	52	3	4730-00-802-8156	46	2
4730-00-555-1784	46	10	5310-00-807-1465	34	7
5035-00-564-1366	3	10	5340-00-900-1500		
5305-00-570-5417	65	7	5310-00-909-4058	33	7
5310-00-570-0079	60	2	5310-00-909-5006	14	12
5340-00-580-5304	46	22	5310-00-909-5846	36	15
5310-00-583-5066	1	6	5360-00-812-5803	33	30
5310-00-583-5066	4	2	4730-00-815-0271	37	2
5310-00-583-5066	6	2	6115-00-830-6462	63	14
5310-00-583-5066	12	17	2910-00-838-9974	47	6
5310-00-583-5066	12	20	6020-00-841-1892	52	10
5310-00-583-5066	29	26	5310-00-843-9855	29	3
5310-00-583-5066	32	17	6115-00-857-0687	8	
5310-00-583-5066	33	8	2915-00-857-0619	29	34
5310-00-583-5066	33	27	6080-00-857-0656	9	21
5310-00-583-5066	37	4	6085-00-857-0662	9	33
5310-00-583-5066	47	2	5330-00-863-9044	40	8
5305-00-590-7803	34	12	6035-00-900-3141	9	24
4630-00-595-3191	29	34	6035-00-900-3143	9	18
4630-00-595-3191	30	11	6035-00-900-3144	9	19
4630-00-595-3191	64	24	5310-00-900-7744	38	2
5310-00-595-6200	30	18	5310-00-900-7744	65	1
5310-00-595-6200	30	35	5330-00-863-3742		

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5310-00-888-2527	65	2	5310-00-872-0843	45	
5110-00-888-5380	5	9	5305-00-873-7803	47	11
2610-00-888-6402	29	22	5310-00-874-0786	41	7
4730-00-888-3193	57	12	5310-00-874-0823	3	9
4730-00-888-3194	57	6	5310-00-874-0823	23	4
4730-00-888-3194	33	17	4710-00-883-0857	47	15
4730-00-888-3204	33	1	5310-00-883-0862	3	4
4730-00-888-0827	33	1	5310-00-883-0863	11	13
5310-00-813-0861	2	1	5310-00-883-0862	11	22
5310-00-813-0861	41	6	5310-00-883-0862	12	7
5305-00-816-2800	0	32	5305-00-884-0210	5	2
2800-00-819-0864	27	11	5305-00-884-0210	7	1
4820-00-888-0834	32	19	5305-00-884-0210	14	5
2010-00-830-0887	20	20	5305-00-884-0210	20	12
5310-00-884-0751	45	1	5305-00-884-0210	31	2
5210-00-886-0919	9	16	5305-00-884-0216	32	9
4730-00-851-1938	41	5	5310-00-887-0365	57	5
4730-00-851-0790	67	22	4730-00-886-0346	27	1
5330-00-871-5007	52	9	5305-01-814-4256	45	5
4730-00-872-1630	47	10	5305-01-814-4256	51	1

NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX (CONT)

PART NUMBER	PCBM	FIG NO.	ITEM NO.	PART NUMBER	PCBM	FIG NO.	ITEM NO.
AAL2274	78225	32	7	MS25068-23	98006	9	26
ANG225-2A	88044	37	6	MS25301-6	98006	9	41
AN980-10L	88044	33	10	MS25324-1	98006	9	27
A3482	74930	57	1	MS25331-313	98006	9	29
C12643	81118	63	13	MS25331-313	98006	9	5
C3080X4	79470	29	33	MS26337-337	98006	7	11
C3178X4	79470	51	4	MS26331-4-313	98006	9	24
C5206X5X4	79470	30	10	MS26331-6	98006	9	20
C5355X5X4	79470	29	29	MS27163-10	98006	33	7
C5406X10	79470	67	23	MS27163-12	98006	36	5
C5406X4X4	79470	34	3	MS27163-12	98006	46	8
C5406X5X4	79470	29	26	MS27163-13	98006	35	10
C5406X5X4	79470	30	8	MS27163-14	98006	34	8
C5406X5X4	79470	32	15	MS27163-14	98006	65	8
C5406X5X4	79470	36	11	MS27163-18	98006	14	12
C5406X5X4	79470	64	11	MS27163-5	98006	3	4
C5506X5	79470	34	2	MS27163-5	98006	11	18
C5525X5	79470	33	20	MS27163-5	98006	11	22
C5535X5	79470	36	25	MS27163-5	98006	12	7
C7924X5	79470	32	12	MS27163-8	98006	36	15
F03A250V15AS	81349	8	9	MS28720-6	98006	37	5
LP2978-48	61112	31	7	MS28741-10-0186	98006	67	26
MILG12803TYPE3GRADE3CLASS1	81340	27	13	MS28741-10-0284	98006	67	21
MILM3971-1AMEND1	81349	9	22	MS28741-10-0284	98006	67	19
MSS5310-9	06285	65	10	MS28741-18-0100	97463	41	1
MS122067	98006	26	16	MS28741-4-0164	98006	27	1
MS15667-1	98006	9	30	MS28741-4-0344	98006	34	1
MS15795-009	98006	28	30	MS28741-5-0070	98006	32	18
MS15866	98006	36	24	MS28741-5-0124	98006	23	9
MS171539	98006	67	14	MS28741-5-0142	98006	64	5
MS17311-1	98006	36	17	MS28741-5-0163	98006	28	18
MS17829-8C	98006	14	11	MS28741-5-0164	98006	30	3
MS20366-1032	98006	36	14	MS28741-5-0174	98006	29	10
MS20604AB4T3	98006	11	14	MS28741-5-0266	98006	67	17
MS20604AB4T3	98006	11	23	MS28741-5-0314	98006	29	9
MS20604B4T3	98006	12	8	MS28741-5-0340	98006	29	11
MS20604B4T3	98006	32	28	MS28741-5-0344	98006	29	12
MS20613-4P8	98006	31	5	MS28741-5-0170	98006	46	3
MS21042-4	98006	34	7	MS28741-6-142	98006	46	1
MS21306-1	98006	29	4	MS28775-223	98006	37	7
MS21306-2	98006	27	10	MS28613-012	98006	34	6
MS21306-2	98006	26	17	MS28613-013	98006	36	29
MS21333-107	98006	29		MS3100R18-4P	98006	4	7
MS21333-67	98006	3	5	MS35068-22	98006	9	40
MS21333-90	98006	65	13	MS35068-30	98006	9	14
MS24568-25	98006	9	2	MS35068-32	98006	60	8
MS24568-27	98006	3	6	MS35068-22	98006	6	29
MS24568-42	98006	3	3	MS35306-203	98006	5	2
MS24568-42	98006	9	4	MS35306-203	98006	7	1
MS24568-42	98006	10	5	MS35306-203	98006	14	5
MS24568-47	98006	9	5	MS35306-203	98006	20	12
MS24568-47	98006	65	5	MS35306-203	98006	31	2
MS25017-15	98006	60	7	MS35306-203	98006	32	9
MS25041-4	98006	60	6	MS35217-65	98006	65	12
MS25043-18C	98006	4	4	MS34333-51	98006	10	3

NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX(CONT)

PART NUMBER	FSCM	FIG NO.	ITEM NO.	PART NUMBER	FSCM	FIG NO.	ITEM NO.
MS353276-79	98906	34	9	MS551967-35	98906	69	3
MS353291-5	98906	11	9	MS551967-36	98906	69	1
MS353297-332	98906	2	8	MS551967-14	98906	14	20
MS353297-300	98906	65	7	MS551967-2	98906	1	5
MS353297-300	98906	2	4	MS551967-2	98906	4	1
MS353298-308	98906	34	12	MS551967-2	98906	12	11
MS353298-37	98906	99	2	MS551967-2	98906	32	16
MS353298-32	98906	7	2	MS551967-2	98906	33	4
MS353298-32	98906	14	8	MS551967-5	98906	38	2
MS353298-32	98906	23	13	MS551967-5	98906	65	1
MS353298-32	98906	65	11	MS551967-8	98906	40	1
MS353298-33	98906	5	7	MS551971-2	98906	2	10
MS353298-33	98906	11	2	MS551971-3	98906	2	1
MS353298-33	98906	12	2	MS551971-3	98906	41	6
MS353298-33	98906	12	4	MS87006-13	98906	11	19
MS353298-33	98906	14	19	MS87006-3	98906	36	16
MS353298-33	98906	29	16	MS90725-14	98906	37	3
MS353298-33	98906	33	5	MS90725-156	98906	46	3
MS353298-34	98906	33	14	MS90725-16	98906	27	3
MS353298-35	98906	64	2	MS90725-29	98906	28	3
MS353298-100	98906	2	5	MS90725-3	98906	8	1
MS353298-140	98906	2	9	MS90725-3	98906	12	3
MS353298-140	98906	38	4	MS90725-3	98906	12	16
MS353298-142	98906	41	7	MS90725-3	98906	29	25
MS353298-22	98906	45	2	MS90725-32	98906	16	4
MS353298-25	98906	47	2	MS90725-32	98906	33	13
MS353298-26	98906	46	6	MS90725-32	98906	46	7
MS353298-26	98906	51	6	MS90725-40	98906	51	5
MS353298-27	98906	43	2	MS90725-58	98906	30	4
MS353298-27	98906	52	3	MS90725-58	98906	30	5
MS353298-28	98906	51	14	MS90725-58	98906	64	3
MS353298-29	98906	27	9	MS90725-59	98906	29	8
MS353298-31	98906	46	4	MS90725-59	98906	52	2
MS353298-41	98906	3	2	MS90725-6	98906	4	3
MS353298-44	98906	1	6	MS90725-6	98906	5	6
MS353298-44	98906	4	2	MS90725-6	98906	11	1
MS353298-44	98906	8	2	MS90725-6	98906	12	1
MS353298-44	98906	12	17	MS90725-6	98906	12	19
MS353298-44	98906	12	20	MS90725-6	98906	29	15
MS353298-44	98906	29	26	MS90725-6	98906	32	18
MS353298-44	98906	33	17	MS90725-6	98906	33	6
MS353298-44	98906	33	8	MS90725-6	98906	47	1
MS353298-44	98906	33	27	MS90725-60	98906	33	21
MS353298-44	98906	37	4	MS90725-60	98906	41	8
MS353298-46	98906	16	5	MS90725-61	98906	36	7
MS353298-46	98906	26	4	MS90725-62	98906	30	1
MS353298-46	98906	29	7	MS90725-62	98906	36	4
MS353298-46	98906	30	2	MS90725-64	98906	38	9
MS353298-46	98906	30	6	MS90725-75	98906	52	6
MS353298-46	98906	33	22	MS90725-6	98906	1	7
MS353298-46	98906	38	5	MS90725-6	98906	14	18
MS353298-46	98906	38	10	MS90725-114	98906	38	7
MS353298-46	98906	40	2	MS90725-66	98906	38	11
MS353298-46	98906	38	8	MS90806-1	98906	32	6
MS35347-1	98906	46	21	MS9122-02	98906	28	19
MS35644-1	98906	32	5	MS9152B-2P4B	98906	9	32
MS35650-302	98906	45	1	MS9317-14	98906	26	18
MS35650-302	98906	46	5	QQ9696	91346		
MS35660-001	98906	46	3	QQ9696	91346		
MS35660-302	98906	64	1	WWP400CLASSA	91346		
MS35660-422	98906	36	21	06281	97520	10	6
MS35660-422	98906	43	1	1G1770	96309	33	32
MS35660-422	98906	27	8	1G17704	96309	33	31
MS36770-1	98906	53	10	10092	73370	46	14
MS36802-2	98906	46	22	10124	73370	46	15
MS36840-1	98906	33	25	101487	73370	30	18
MS36842-11	98906	27	6	101487	73370	30	35
MS36842-11	98906	33	17	101488	73370	30	19
MS36842-12	98906	67	12	101489	73370	30	20
MS36842-13	98906	33	1	101489	73370	30	29
MS36842-14	98906	33	1	101979	73370	46	18
MS36863	98906			103326	73370	46	19
MS390176-1	98906			104018	73370	30	16
MS390176-3	98906	29	2	10428	73370	46	23
MS390177-1	98906			1054	96309	33	30
MS390331G4	98906	34	5	1064-2	96309	33	34
MS390331G4	98906	36	27	106496	73370	30	22
MS45604-72	98906	65	2	106496	73370	30	27
MS51331-2	98906	29	29	10768	73370	46	16
MS51613	98906	29	14	1113186	16764	46	

NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX (CONT)

PART NUMBER	FSCM	FIG NO.	ITEM NO.	PART NUMBER	FSCM	FIG NO.	ITEM NO.
1115506	16764	45	30	13214E7486	97463	11	31
11662A	28265	43	6	13214E7486	97463	12	5
118940	73370	46	20	13214E7704	97463	9	16
121601	73370	30	21	13214E7706	97463	9	31
121601	73370	30	36	13214E8647	97463	9	27
122104	12204	46	3	13214E8648	97463	9	29
13114A	28265	43	6	13214E8649	97463	30	34
13114A	28265	43	11	13215E8300	97463	5	9
13123A	28265	43	7	13216E3147	97463	67	13
13206E4770	97403	7	3	13216E3148	97463	67	15
13206E4785	97403	9	42	13216E3149	97463	67	16
13206E4786	97403	9	36	13216E3155	97463	1	11
13206E4787-1	97403	9	30	13216E3164	97463	31	6
13206E4789	97403	9	24	13216E3165	97463	31	4
13206E4790	97403	9	19	13216E3166	97463	21	3
13206E4792	97403	9	18	13216E3167	97463	27	11
13206E4793-2	97403	9	17	13216E3168	97463	31	9
13206E4796	97403	9	21	13216E3171	97463	13	8
13206E4799	97403	9	23	13216E3175-2	97463	28	13
13206E3192-2	97403	29	23	13216E3177	97463	40	7
13206E3192-3	97403	30	12	13216E3186	97463	22	36
13206E3192-3	97403	32	11	13216E3191	97463	65	3
13206E3192-2	97403	64	23	13216E3196	97463	5	
13211E8742	97403	67	23	13216E3196	97463	5	5
13211E8750	97403	32	19	13216E3199	97463	5	4
13211E8770	97403	86	2	13216E3300	97463	12	21
13211E8801	97403	3	8	13216E3300-2	97463	16	3
13211E8802	97403	3	10	13216E3304-2	97463	16	7
13212E3461	97403	28	5	13216E3322	97463	29	26
13213E1637-1	97403	14	21	13216E3333	97463	64	10
13213E8655-3	97403	9	11	13216E3336	97463	11	29
13213E8656	97403	9	10	13216E3337-1	97463	20	22
13214E3155	97403	66		13216E3339-2	97463	41	3
13214E3156	97403	66	9	13216E3331	97463	20	24
13214E3160	97403	66	4	13216E3333	97463	29	15
13214E3165-2	97403	46	11	13216E3333	97463	1	3
13214E3166	97403	46	8	13216E3334-2	97463	1	8
13214E3195	97403	29	18	13216E3337-2	97463	1	3
13214E3196	97403	29	17	13216E3338-2	97463	1	1
13214E3199	97403	29	35	13216E3339	97463	1	4
13214E3306	97403	27	2	13216E3357	97463	32	29
13214E3306	97403	1	9	13216E3300	97463	11	24
13214E3212	97403	1	10	13216E3361	97463	11	17
13214E3223	97403	11	7	13216E3366	97463	12	16
13214E3238	97403	65	6	13216E3300	97463	12	6
13214E3242-2	97403	33	2	13216E3372	97463	27	5
13214E3242-3	97403	33	3	13216E3375	97463	27	4
13214E3243	97403	29	24	13216E3377	97463	66	3
13214E3243	97403	30	11	13216E3384	97463	41	2
13214E3243	97403	64	24	13216E3385	97463	41	6
13214E3245	97403	16	3	13216E3385	97463	16	1
13214E3246	97403	29	31	13216E3386	97463	27	1
13214E3248	97403	31	6	13216E3386-3	97463	5	3
13214E3350-4	97403	64	7	13216E3300	97463	5	6
13214E3256-5	97403	64	8	13216E3400	97463	12	23
13214E3256-6	97403	64	6	13216E3803	97463	34	11
13214E3254	97403	64	19	13216E3804	97463	3	7
13214E3256	97403	32	4	13216E3807-1	97463	3	11
13214E3265	97403	10	3	13216E3803	97463	3	12
13214E3273	97403	9	15	13216E3803	97463	28	3
13214E3276	97403	9	3	13216E3803	97463	33	
13214E3285	97403	9	12	13216E3807	97463	12	
13214E3290-50	97403	11	5	13216E3808	97463	11	4
13214E3290-50	97403	12	14	13216E3809	97463	11	11
13214E3290-50	97403	32	3	13216E38012	97463	11	10
13214E3290-50	97403	64	17	13216E38013	97463	29	
13214E3291-2	97403	3	1	13216E38015-1	97463	11	16
13214E3291-3	97403	9	1	13216E38015-2	97463	11	16
13214E3291-3	97403	10	1	13216E38016	97463	33	12
13214E3291-3	97403	32	8	13216E38017	97463	40	4
13214E3291-3	97403	65	4	13216E38019	97463	32	11
13214E3291-4	97403	5	1	13216E38020	97463	12	13
13214E3291-4	97403	23	11	13216E38021	97463	12	13
13214E3291-4	97403	31	1	13216E38023	97463	16	6
13214E3293-3	97403	9	8	13216E38024	97463	36	12
13214E3299	97403	8		13216E38006	97463	30	6
13214E4770-4	97403	7	8	13216E38027	97463	64	18
13214E7414	97403	12	16	13216E38006	97463	27	13
13214E7488	97403	11	6	13216E38031	97463	33	24
13214E7488	97403	11	12	13216E38006	97463	33	22

NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX (CONT)

PART NUMBER	FSCM	FIG NO.	ITEM NO.	PART NUMBER	FSCM	FIG NO.	ITEM NO.
12214220003	97485	20	7	227633	73370	30	33
12214220005	97485	2	6	227633	73370	30	26
12214220041	97485	58	16	227634	73370	30	25
12214220043	97485	11	8	227632	73370	30	17
12214220044	97485	11	3	227235	73370	30	34
12214220046	97485	12	23	227235	73370	30	32
12214220048	97485	64	4	2260A	22365	51	1
12214220047	97485	20	1	2400	73370	46	12
12214220049	97485	33	15	24004-2	22365	53	36
12214220050	97485	12	15	265300A	22365	51	15
12214220051	97485	58	9	265300A	22365	51	9
12214220052	97485	58	10	265300C8	22365		
12214220054	97485	12	9	265561A	22365	38	23
12214220055	97485	20	1	265701A	22365	53	5
12214220056	97485	2	11	2663	73370	46	17
12214220058	97485	20	4	266200D	22365	51	3
12214220059	97485	20	20	266300B	22365	53	1
12214220063	97485	14	23	265701A	22365	53	9
12214220062	97485	60	0	265300E	22365	57	6
12214220066	97485	35	23	265313C	22365	57	7
12214220072	97485	40	10	265710C	22365	51	8
12214220073	97485	2	2	266304DS	22365	51	16
12214220074	97485	2	3	265700A	22365	53	4
12214220076	97485	20	27	265720B	22365	53	11
12214220075	97485	20		265750C	22365	53	8
12214220069	97485	14	7	265753B	22365	51	12
12214220070	97485	33	19	265200D	22365	43	9
12214220060	97485	11	16	266515AB	22365	47	17
12214220061	97485	11	25	266516AB	22365	47	16
12214220063	97485	26	10	266577AB	22365	47	15
12214220064	97485	24	10	266579D	22365	43	3
12214220069	97485	40	5	265777C	22365	46	9
12214220067	97485	30	8	261066AB	22365		
12214220042	97485	20	10	266332AB	22365	47	10
12214220059	97485	35	13	265334AB	22365	47	9
12214220060	97485	41	9	265332AB	22365	47	8
12214220062	97485	20	14	265336AB	22365	47	7
12214220066	97485	20	21	265337AB	22365	47	12
12214220061	97485	3	9	265436AB	22365	47	13
12214220072	97485	22	14	265330AB	22365	47	14
12214220071-1	97485	4	6	3-4FFB	36337	41	4
12214220074	97485	18	9	3153X4	76470	36	12
12214220075	97485	18	3	3200Y4X5	76470	36	3
12214220076	97485	18	7	3200X6X4	76470	34	4
12214220077	97485	18	1	3220X4	76470	30	14
12214220078	97485	12	11	3304A	22365	43	8
12214220079	97485	18	10	3320X2	76470	40	9
12214220080	97485	18	6	3320X8	76470	67	24
12214220081	97485	18	2	3400X4	76470	50	9
12214220083	97485	4	5	3400X5	76470	67	35
12214220084	97485	18	5	265556	73370	30	30
12214220085	97485	12	4	26570	73370	30	31
12214220086	97485	63	23	353X10	76470	36	2
12214220087	97470	46	13	3750X4	76470	30	13
12214220088	97485	23	27	320015	53100	26	15
12214220089	97485	32	20	402X10	76470	36	10
14001-4	98000	32	23	4023A	22365	57	4
14002	98000	32	23	4023A	22365	2	7
14002A	22365	26	6	40619A	22365		
151233	73370	29	28	4100	34161	32	2
1617604	16764	45	19	4312A	22365	52	1
200010	70470	45	11	4407-5-8	24161	27	7
201184A	22365	57	2	4407-5-8X12	34161	33	18
201500A	22365	48	6	4461	96300	33	33
201753A	22365	49	5	4463	96300	36	38
2021-4-68	01270	32	14	4465	96300	33	36
202046A	22365	57	3	453010	96600	33	26
202020A5	22365	63	14	479135	72365	20	22
202046A	22365	47	11	479136	72365	20	21
202024A	22365	52	7	49X3	76470	47	19
202007A	22365	47	3	51X3	76470	47	18
202046A	22365	47	6	538-84	63764		
204236A	22365	51	7	550X4	76470	20	6
204420A	22365	51	12	57D6413H302	88725	20	3
204432A	22365	57	5	5832X8	76470	46	10
205361B	22365	51	11	59A	22365	63	31
206306	22365	61	10	6C30XB	45001	37	2
20168A	22365	63	28	69A	22365	53	2
227005	73370	29	23	69A	22365	63	20
227006	73370	30	27	615A	22365	51	2
227008	73370	30	36	630A	22365	63	33

NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX(CONT)

PART NUMBER	FSCM	FIG NO.	ITEM NO.	PART NUMBER	FSCM	FIG NO.	ITEM NO.
05951867	04713	38	14	8251	26472	38	1
069A	28265	47	5	8715	73370	46	24
702X4	79470	64	9	88133A	26395	47	4
7165A	28365	63	28	9403902	00000	39	19
72-3865	30554	33	26	9421425	16764	45	4
70033A	28365	43	10				

SUPPLEMENTAL NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX

STOCK NUMBER	FIGURE NO.		ITEM NO.	STOCK NUMBER		FIGURE NO.	ITEM NO.
4730-00-040-7450	66		2C	4730-00-289-9197		66	2B
4010-00-188-0412	66		2D	4730-00-842-2201		66	2A
PART NUMBER	FSCM	FIG NO.	ITEM NO.	PART NUMBER	FSCM	FIG NUMBER	ITEM NO.
MILH5794-5	81349	66	2B	RRC371 Type	81348	66	2D
M524667-5	96806	66	2A	5LHBTYB	45681	66	2C

By Order of the Secretary of the Army:

Official:

J. C. PENNINGTON
Brigadier General, United States Army
The Adjutant General

BERNARD W. ROGERS
General, United States Army
Chief of Staff

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25D, Organizational Maintenance Requirements for Generator Sets, Engine Driven, 30 KW, 60 HZ Precise Power.

SOMETHING WRONG WITH THIS MANUAL?



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

PFC JOHN DOE
CoA, 3^d ENGINEER BN
FT. LEONARD WOOD MO 63108

DATE 16 DEC 74

PUBLICATION NUMBER

DATE

TITLE

TM5-6115-200-20 AND P

1 APR 72

GENERATOR SET 10 KW
NSN 6115-00-231-7286

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG DOTTED LINE

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	
6	2-1 a			In line 6 of paragraph 2-1a the manual states the engine has 6 cylinders. The engine on my set only has 4 cylinders. Change the manual to show 4 cylinders
81		4-3	S	Callout ^D on figure 4-3 is pointing at a shim bolt. In the key to fig. 4-3, item 16 is called a <u>shim</u> . Please correct one or the other.
125	line 20			I ordered a gasket, item 19 on figure B-16 by NSN 2910-00-752-3001. I got a gasket but it doesn't fit. Supply says I got what I ordered so the NSN is wrong. Please give me a good NSN

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

JOHN DOE, PFC (268) 317-7111

SIGN HERE:

John Doe

DA FORM 2028-2 (TEST)
AUG 74

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Troop Support and
Aviation Materiel Readiness Command
ATTN: DRSTS-MTPS
4300 Goodfellow Blvd.
St. Louis, MO 63120

TEAR ALONG DOTTED LINE

FOLD BACK



SOMETHING WRONG WITH THIS MANUAL?

THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER TM 5-6115-449-20P	DATE 16 Dec 77	TITLE Generator Set, Self-Powered, Diesel Engine Driven, 30Kw, AC, 3- Phase, 120/208V, 240/416V, 60 HERTZ
---	-----------------------	--

BE EXACT...PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 1 AUG 74 2028-2 (TEST)

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE
A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimenter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigrams = .035 ounce
 1 dekagram = 10 grams = .35 ounce
 1 hectogram = 10 dekagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 38.82 fl. ounces.
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimenter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	.2540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	3.94
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	grams	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	newton-meters	1.365	metric tons	short tons	1.102
pound-inches	newton-meters	.11375			

Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C



