

RESCINDED

Authority: DA Cir 310-77

Date: 23 July 59

*SIG 7 & 8 SB-18/GT

DEPARTMENT OF THE ARMY SUPPLY MANUAL

*Organizational Maintenance Allowances
and Field and Depot Maintenance Stockage Guide
for*

EMERGENCY SWITCHBOARD SB-18/GT

Department of the Army, Washington 25, D. C.,

28 March 1957

1. A copy of SIG 1 and DA Pam 310-21 should be available to every user of the Signal portion of the Army supply manual.

a. SIG 1 explains the purpose and use of the Signal portion of the Army supply manual.

b. DA Pam 310-21 contains alphabetical and numerical indexes of available manuals in the Signal portion of the Army supply manual.

2. Items marked X under expendability note are expendable within the meaning of AR 735-4; nonexpendable items are marked NX.

3. A percent symbol (%) indicates the item is authorized for use in the category of maintenance indicated and may be requisitioned when required. Not authorized for stockage.

4. The Federal stock number column lists the 11-digit Federal stock number assigned by the Cataloging Division, OASD (S&L). The Federal

stock number will be used for requisitioning purposes.

5. SIG 7 & 8 SB-18/GT comprises two parts as follows:

a. *Maintenance Items.* A list of parts for repair and supply facilities.

b. *Basic Issue Items.* A list of component parts showing the quantities of each that comprise a complete operating equipment, including running spares, that is, those spare parts shipped concurrently with the equipment, and accessories.

6. Comments relative to technical data discrepancies contained in this manual should be forwarded to—

Chief

Logistics Engineering Division
Maintenance Engineering Department
Signal Equipment Support Agency
Fort Monmouth, N. J.

ATTN: SIGFM/ES-ML-1

*This manual supersedes DA Supply Manual SIG 7 & 8 SB-18/GT, 7 July 1954, including C1, 9 March 1955.

PROPERTY OF THE TECHNICAL LIBRARY
DO NOT REMOVE FROM BUILDING

Copy 1

By Order of *Wilber M. Brucker*, Secretary of the Army:

MAXWELL D. TAYLOR,
General, United States Army,
Chief of Staff.

Official:

HERBERT M. JONES,
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

CNGB
ASA
Tec Svc, DA
Tec Svc Bd
Hq CONARC
CONARC Bd
CONARC Bd Test Sec
Army AA Comd
OS Maj Comd
OS Base Comd
Log Comd
MDW
Armies
Corps
Div
US Army Tng Cen
Ft & Cp
USMA
Gen & Br Svc Sch
Gen Depots
Sig Sec, Gen Depots
Depots
AMS
AH
ASMPA
AFIP
Sp Wpn Comd
POE (OS)
Trans Terminal Comd
Army Terminals
OS Sup Agencies
PG
Arsenals
Plants & Works
Sig Fld Maint Shops
ACS
Lab
Mil Dist
Trans Zones
JBUSMC
Mil Msn
Units org under fol TOE:
3-266
5-15
5-16
5-17
5-35
5-36

Units org under fol TOE:—Con.

5-37
5-137
5-133
5-192
5-215
5-216
5-217
5-218
5-225
5-226
5-227
5-367
5-525
6-100
6-101
6-115
6-116
6-117
6-125
6-126
6-127
6-135
6-136
6-137
6-200
6-225
6-226
6-227
6-235
6-236
6-237
6-300
6-301
6-315
6-316
6-317
6-325
6-326
6-327
6-401
6-415
6-416
6-417
6-435
6-437
6-447
6-501
6-525
6-535

Units org under fol TOE:—Con.

6-536
6-537
6-545
6-575
6-577
7-11
7-12
7-14
7-15
7-16
7-17
7-18
7-25
7-26
7-27
7-31
7-32
7-34
7-35
7-36
7-37
7-38
7-95
7-96
8-510
9-7
9-45
9-47
9-57
11-7
11-16
11-18
11-57
11-97
11-116
11-117
11-127
11-128
11-500
11-537
11-557

Units org under fol TOE:—Con.

11-587
11-597
17-22
17-25
17-27
17-32
17-35
17-37
17-45
17-46
17-51
17-52
17-53
17-55
17-56
17-57
17-115
17-116
17-125
17-126
19-27
19-47
19-55
19-56
19-57
19-97
19-247
20-300
20-511
30-600 (AA-AE)
33-77
44-15
44-17
44-35
44-36
44-37
44-75
44-77
55-12
55-56
57-57

NG: State AG; units—same as Active Army.

USAR: None.

For explanation of abbreviations used, see SR 320-50-1.

☆U.S. GOVERNMENT PRINTING OFFICE: 1957—400798/1356