

1
44d *4113*
2
TM
1942

TM 11-432

WAR DEPARTMENT

TECHNICAL MANUAL



CODE PRACTICE EQUIPMENT

February 2, 1942



TM 11-432

C 1

CODE PRACTICE EQUIPMENT

30. Keyer TG-10-(*).—The general instructions given for the Lon-Ga-Tone unit apply to the automatic **Keyer TG-10-(*)**. To disengage the * * * words per minute.

[A. G. 300.7 (27 Jul 48).] (C 1, 30 Aug 43.)

35. Preliminary adjustment of tone level.

* * * * *

c. Using Keyer TG-10-()*.—Same as for Lon-Ga-Tone, type 7.

* * * * *

[A. G. 300.7 (27 Jul 48).] (C 1, 30 Aug 43.)

39. Keyer TG-10-(*).—The circuit diagram of **Keyer TG-10-B** appears as figure 33. Circuit diagrams for other Keyers TG-10-(*) appear in **TM 11-447**. A back view of the chassis of **Keyer TG-10-B**, with the parts marked to correspond with the wiring diagram, follows as figure 34.

* * * * *

a. Functioning of circuit.—The circuit of * * * the 6V6 type. Circuit details for Keyers TG-10-(*) are shown in **TM 11-447**.

[A. G. 300.7 (27 Jul 48).] (C 1, 30 Aug 43.)

* * * * *

BY ORDER OF THE SECRETARY OF WAR:

G. C. MARSHALL,
Chief of Staff.

OFFICIAL:

J. A. Ulio,
Major General,
The Adjutant General.

TECHNICAL MANUAL
CODE PRACTICE EQUIPMENT

CHANGES }
No. 2 }

U.S. WAR DEPARTMENT,
WASHINGTON 25, D. C., 20 April 1944.

TM 11-432, 2 February 1942, is changed as follows:

APPENDIX III (ADDED)

EMERGENCY CODE PRACTICE EQUIPMENT

1. General.—In order that field units and installations may give instructions in transmitting and receiving the International Morse characters even though the regulation code practice equipment is not available, information is furnished in this appendix to permit improvising equipment. The exercise of ingenuity will produce other means for improvising equipment. This information, however, is not to be used as authority to requisition any of the equipment mentioned.

2. Sources of tone.—*a.* A tone source for practice may be obtained by connecting a buzzer as shown in figure 52. The headphones are in series, with a capacitor across the coil of the buzzer. The strength of the signal in the headphones may be reduced by the use of smaller capacitors. The buzzer may be made from a doorbell by removing the gong and clapper. A better tone, and one that is more nearly identical to the note heard in the radio receiver, may be produced by the use of a vacuum tube audio-oscillator as shown in figure 53. In addition to key and headphones, the necessary parts are a grid resistor and capacitor, tube (1G4G or equivalent), socket, and audio-transformer. If the circuit fails to oscillate, one winding of the audio-transformer should be reversed. This equipment can supply power for only a few head sets, but by use of the oscillator shown in figure 53, together with a small audio-amplifier, more power can be obtained.

b. In the use of buzzers or oscillator circuits for code practice training, all necessary precaution should be taken to prevent interference with operational radio equipment.

c. An interference check can be made by the use of a radio receiver adjusted for maximum sensitivity and located near the training equipment and a check of the operational frequencies made.

*These changes supersede section II, Training Circular No. 35, War Department, 1943.




FIGURE 52.—Buzzer circuit diagram.




FIGURE 53.—Simple audio-oscillator.

3. Telegraph set TG-5 as source of tone.—Telegraph set TG-5 may be used as a source of tone and keying for supplying head sets. Buzzer BZ-5 may be salvaged from an unserviceable telegraph set TG-5 and used in the manner indicated in paragraph 2.

4. Instruction.—In the absence of sufficient head sets, a loud-speaker may be used for group instruction.

[A. G. 300.7 (24 Mar 44).]

BY ORDER OF THE SECRETARY OF WAR:

G. C. MARSHALL,
Chief of Staff.

OFFICIAL:

J. A. ULIO,
Major General,
The Adjutant General.

✓ U.S. Library
TM 11-432

C 3

TECHNICAL MANUAL
CODE PRACTICE EQUIPMENT

CHANGES
No. 3 }

WAR DEPARTMENT
WASHINGTON 25, D. C. 17 February 1945

MAR 16 1945
TM 11-432, 2 February 1942, is changed as follows:

14.1. Code Practice Equipment EE-94-B (Added).—Figure 5.1 is a block diagram of Code Practice Equipment EE-94-B for a school of 20 students. The equipment consists of one switchboard BD-57-() with auxiliary patching board, six Automatic Keyers TG-10-(), one Oscillator VO-3-(), one Recorder BC-791-B, one Tape Puller MC-310-B, and various accessories. The physical placement of the equipment is similar to that described in paragraph 14.

NOTE.—This paragraph and paragraphs 14.2 through 14.4 cover typical installations of Code Practice Equipments EE-94-(), EE-95-(), and EE-96-(). The components of these equipments will vary with the different models, but the general arrangements will be similar to the diagrams shown. Official nomenclature followed by () indicates all models of the equipment.

14.2. Code Practice Equipment EE-94-E (Added).—a. Figure 5.2 is a block diagram of Code Practice Equipment EE-94-E for a school of 20 students. The equipment consists of one Switchboard BD-114, six Automatic Keyers TG-34-(), one Oscillator VO-3-(), one Recorder BC-1016, and the various accessories. The physical placement of the equipment will be similar to that described in paragraph 14.

b. When using Switchboard BD-114, wire the auxiliary switchboard tone to a pair of terminals associated with the auxiliary tone jacks. Connect the tone to the primary of transformers C69 by inserting the plug of the white cord into the tone jack to which the auxiliary tone is wired. To connect the instructor's key and headset into the circuit, wire the key and headset to a plug. Insert the plug into the jack on the front panel.

14.3. Code Practice Equipment EE-95-B (Added).—On figure 5.3 the solid lines show the wiring of Code Practice Equipment EE-95-B for a 40-man school. The equipment consists of two Switchboards BD-57-() with auxiliary patching boards, six Automatic Keyers TG-10-(), one Oscillator VO-3-(), one Recorder BC-791-B, one Tape Puller MC-310-B, and various accessories. The physical arrangement of the equipment is similar to that described in paragraph 14.

14.4. Code Practice Equipment EE-96-B (Added).—The dotted lines on figure 5.3 show the additional equipment required to convert the EE-95-B to a EE-96-B which is suitable for a 100-man

AGO 338C—Feb. 622703°—45

TM 11-432
C 3




FIGURE 5.1.—Block diagram of Code Practice Equipment EE-94-B for a 20-man school.




FIGURE 5.2.—Block diagram of Code Practice Equipment EE-94-E for a 20-man school.

TL 14135

AGO 338C

C3

school. The additional equipment required consists of three Switchboards BD-57-() with auxiliary patching boards, six Automatic Keyers TG-10-(), one Oscillator VO-3-(), two Recorders BC-791-B, two Tape Pullers MC-310-B, and various accessories. The physical arrangement of the equipment is similar to that described in paragraph 14.

NOTE—When Recorder BC-1016 is used in place of Recorder BC-791-B in any of the above equipments, Tape Puller MC-310-B is not required.




FIGURE 5.3.—Block diagram of Code Practice Equipments EE-95-B and EE-96-B.

38. Automatic Keyer, Lon-Ga-Tone, Type 7.

b. Maintenance and repair.—Clean the aperture * * * is exposed thereby. Once a week put 1 drop of Oil, Engine, U. S. Army Spec. No. 2-104B, in the oil ducts of the take-up motor and in the oil hole at the left end of the puller motor. If the exciter * * * to the phototube.

39. Keyer TG-10-B.

* * * * *

b. Maintenance and repair.—(1) *Lubrication.*—On units which have a worm reduction gear on the motor shaft running in an oil bath, check the oil level weekly and keep the gearcase full of Oil, Engine, U. S. Army Spec. 2-104B. Drain and refill the case once every 3 months.

(2) On units which have an open helical gear on the motor shaft, apply a light coat of Grease, Lubricating, Special, Ordnance Spec. No. AXS-637 at intervals of 1 month or 400 operating hours.

(3) Lubricate all shaft bearings with Oil, Engine, U. S. Army Spec. No. 2-104B at intervals of 1 month or 400 operating hours.

(4) For detailed lubrication instructions, see TM 11-447 which covers this equipment in detail.

Subparagraphs (2) to (6), inclusive, are renumbered (5) to (9), inclusive.

41. Automatic Keyer, McElroy Model G-813.

* * * * *


b. Maintenance and repair.—Clean the aperture * * * experienced instrument repairman. Once a week place 1 drop of Oil, Lubricating, Preservative, Special, U. S. Army Spec. No. 2-120, in the oil hole located at the top of the rewind. If the exciter * * * soft lead pencil.

44. Tape Puller, McElroy Model CTP-1300.

* * * * *

b. Maintenance and repair.—Once a day place 1 drop of Oil, Engine, U. S. Army Spec. No. 2-104B in the oil hole on the take-up spindle and in the oil duct leading to the puller wheel bearing. The entrance to * * * the puller wheel.

46.1. Switchboard BD-57-B (Added).—*a. Functioning of circuit.*—The complete schematic of this switchboard is shown in figure 47.1. This circuit is the same as the circuit for the BD-57-A (fig. 47) except that the motor alternator, the battery and tone switches, and the terminals for the master key have been omitted; they are not required in code practice equipment. The functioning of the circuit is covered in paragraph 46.



AGO 338C




FIGURE 47.2.—Circuit diagram of Switchboard BD-114-().

AGO 338C

7

b. Maintenance and repair.—See paragraph 45b.

46.2. Switchboard BD-114-() (Added).—*a. Functioning of circuit.*—Figure 47.2 shows the complete schematic of this switchboard. The circuit is the same as circuit of the BD-57-B shown in figure 47.1 except for the following points:

(1) A patching board has been incorporated into the switchboard unit. (See par. 2, app. I, for a detailed description of the patching board.)

(2) The potentiometer in the oscillator tone circuit has been eliminated; the same results are obtained by wiring the tone into the terminals of the auxiliary tone jacks. The tone is connected to the primaries of transformers C69 by inserting plug PL-48 of the white cord into the tone jack to which the auxiliary tone is wired. The potentiometer in the auxiliary jack circuit acts as the volume control.

(3) The terminals for the instructor's headset and key are brought out to a jack on the panel. To connect into the circuit, the instructor's key and headset is connected to a plug.

(4) The auxiliary tone cords have been omitted; they are not required when a patching board is used.

b. Maintenance and repair.—See paragraph 45b.

[AG 300.7 (29 Dec 44)]

BY ORDER OF THE SECRETARY OF WAR:

OFFICIAL:

J. A. ULIQ

Major General

The Adjutant General

G. C. MARSHALL

Chief of Staff

DISTRIBUTION:

AAF (5); AGF (5); ASF (2); T of Opn (5); Dept (5); Def Comd (2); Base Comd (5); AAF Comd (2); Arm & Sv Bd (2); S Div ASF (1); Tech Sv (2); SvC (5); Area ASvC (2); WDGS Lib (5); PC&S (2); PE (2); Dep 11 (2); Gen Oversea SOS Dep (Sig Sec) (2); GH (2); M Conc C (2); Air Base Hosp (2); Gen Sv Sch (5); Sp Sv Sch (10); USMA (2); ROTC (5); Lab 11 (2); Sig AS (2); Rep Shop 11 (2); A (5); D (2); AF (2); Bn 1, 2, 4, 6, 7, 11, 17, 44 (2); T/O & E 11-18 (2); 11-27 (2); 11-97 (2); 11-107 (2); 11-127 (2); 11-437 (2); 11-500, Sig Sv Orgn, Bn Hq (2); 11-587 (2); 11-592 (2); 11-597 (2)

For explanation of symbols, see FM 21-6.

TECHNICAL MANUAL }
No. 11-432 }

WAR DEPARTMENT,
WASHINGTON, February 2, 1942.

CODE PRACTICE EQUIPMENT

Prepared under direction of the
Chief Signal Officer

SECTION I. General.

	Paragraph
Purpose and scope	1
Basic equipment requirements	2
Major components	3
Keyer TG-10-A or TG-10-B	4
Automatic keyer, Lon-Ga-Tone, type 7	5
Automatic keyer, McElroy model G-813, modified	6
Oscillator-amplifier, Amplifier Company of America, type ACA-10-AO	7
Automatic keyer, McElroy model G-813	8
Code practice equipment EE-81	9
Practice tapes	10
Recorder, McElroy model RRD-900	11
Reels, motion picture film, 16-mm, 400 feet	12
Record player for disk records, Columbia model P	13

II. Installation for service.

General arrangement of equipment	14
Instruction tables	15
Total space requirements	16
Interconnection of units	17
Connecting switchboard BD-57 or BD-57-A	18
Input power circuit	19
Connecting oscillator-amplifier ACA-10-AO	20
Connecting automatic keyer, McElroy model G-813	21
Connecting automatic keyer, Lon-Ga-Tone, type 7	22
Connecting keyer TG-10-B	23
Connecting automatic keyer, McElroy model G-813, modified	24
Connecting transmission test table using automatic keying unit, McElroy model G-813	25

*This manual supersedes TR 1215-10, and Instruction Book for Code Practice Equipment for Training Radio Operators, February 10, 1941, and supplements thereto.

SECTION II. Installation for service—Continued.	Paragraph
Connecting transmission test table using Lon-Ga-Tone automatic keyer, type 7-----	26
III. Operation.	
Oscillator-amplifier ACA-10-AO-----	27
Automatic keyer, McElroy model G-813 -----	28
Automatic keyer, Lon-Ga-Tone, type 7-----	29
Keyer TG-10-B-----	30
Automatic keyer, McElroy model G-813, modified-----	31
Recorder, McElroy model RRD-900-----	32
Record player, Columbia model P-----	33
Switchboard BD-57-A-----	34
Preliminary adjustment of tone level-----	35
Initiating complete operation-----	36
IV. Functioning of circuits; maintenance and repair.	
General-----	37
Automatic keyer, Lon-Ga-Tone, type 7-----	38
Keyer TG-10-B-----	39
Oscillator-amplifier ACA-10-AO-----	40
Automatic keyer, McElroy model G-813-----	41
Automatic keyer, McElroy model G-813, modified-----	42
Recorder, McElroy model RRD-900 or R-900-----	43
Tape puller, McElroy model CTP-1300-----	44
Switchboard BD-57-----	45
Switchboard BD-57-A-----	46
Record player, Columbia model P-----	47
APPENDIX I. Changes in switchboards BD-57 and BD-57-A-----	Page
II. Material carried on master tapes-----	77

SECTION I**GENERAL**

Purpose and scope-----	Paragraph
Basic equipment requirements-----	1
Major components-----	2
Keyer TG-10-A or TG-10-B-----	3
Automatic keyer, Lon-Ga-Tone, type 7-----	4
Automatic keyer, McElroy model G-813, modified-----	5
Oscillator-amplifier, Amplifier Company of America, type ACA-10-AO-----	6
	7

Automatic keyer, McElroy model G-813-----	8
Code practice equipment EE-81-----	9
Practice tapes-----	10
Recorder, McElroy model RRD-900-----	11
Reels, motion picture film, 16-mm, 400 feet-----	12
Record player for disk records, Columbia model P-----	13

1. Purpose and scope.—The purpose of this manual is to describe equipment for the training of radio operators in troop and special service schools. There are included a general description of major components of this equipment, detailed instructions for its installation and use, and information as to its functioning, servicing, and repairing.

2. Basic equipment requirements.—The basic requirement in any school for training radio operators is an audio-frequency oscillator of sufficient power to supply tone to a headset for each student in the school. Associated with this tone source must be a flexible distribution system whereby the tone supplied to individual headsets or groups of headsets can be isolated from others. The tone supplied to each group of headsets must be capable of being keyed at various speeds. Keying may be accomplished manually, but a great reduction of instructor personnel and more accurate transmissions are possible if equipment is available for automatically keying the tone by means of previously prepared tape. Of great assistance in teaching students to transmit well-formed characters is a recorder by means of which signals transmitted by them are recorded on a tape. Use of this prepared tape on the automatic keyer, retransmitting his own transmissions to the student who prepared the tape, points out his errors emphatically. The equipment described herein fulfills each of the above requirements and is intended for use in conducting the course of instruction outlined in TM 11-454. Figure 1 shows a typical school for 100 students, using the equipment described in this manual.

3. Major components.—The major components of equipment for training radio operators in troop schools are as follows:

a. Keyer TG-10-A or TG-10-B. (Tone source and keyer combined.)

b. Automatic keyer, Lon-Ga-Tone, type 7. (Tone source and keyer combined.)

Note.—Keyers TG-10-A and TG-10-B and the Lon-Ga-Tone keyer are made to meet the same general requirements and are interchangeable in their use.




FIGURE 1.—Five 20-man tables, each with switchboard, used in typical school for training of radio operators. (Recorder for making of tapes by students is in far center; automatic keyers in separate room.)

c. Automatic keyer, McElroy model G-813, modified. (Tone source and keyer combined.) This is substitute equipment for item *a* or *b*.

d. Oscillator-amplifier, Amplifier Company of America, type ACA-10-AO. (Tone source.)

e. Automatic keyer, McElroy model G-813. This item in combination with item *d* is equivalent to item *a*, *b*, or *c*.

f. Code practice equipment EE-81, less batteries BB-29. (Distributing system.)

g. Practice tapes Nos. 1 to 15. (Master copies of practice transmissions, appendix II.)

h. Recorder, McElroy model RRD-900.

i. Tape puller, McElroy model CTP-1300. (Used with item *h*.)

j. Reels, motion picture film, 16-mm, 400 feet. (For holding tape.)

k. Record player, for disk records, Columbia model P. (For use with the record set MC-209 (radiotelegraph operator aptitude test); (see TM 11-454).

4. Keyer TG-10-A or TG-10-B.—These keyers are identical both mechanically and electrically except that the TG-10-A is equipped with transformers for 110-volt 25-cycle operation, while the TG-10-B is equipped with transformers for 110-volt 60-cycle operation. Reference will be made hereafter only to the TG-10-B, as comparatively few of the TG-10-A keyers have been manufactured. The keyer TG-10-B closely resembles the Lon-Ga-Tone keyer in over-all characteristics.

5. Automatic keyer, Lon-Ga-Tone, type 7.—This keyer combines a tone source and an automatic electronic keying system. The tone source consists of an oscillator-amplifier capable of supplying 10 watts of audio tone at 800 cycles per second \pm 10 percent. This keyer operates from a 110-volt 60-cycle source but satisfactory results can be obtained from a source as low as 90 volts. (See fig. 2.)

6. Automatic keyer, McElroy model G-813, modified.—This unit combines a tone source of considerably lower power output (about 1 watt) and an automatic keyer, and may be used as a substitute for the automatic keyer, Lon-Ga-Tone, type 7. Only a limited quantity has been issued.

7. Oscillator-amplifier, Amplifier Company of America, type ACA-10-A0.—This tone source is capable of supplying 10 watts of tone at 800 cycles per second \pm 10 percent. This power is adequate for supplying tone to 200 headsets. When the number of student groups being independently keyed on a single tone source exceeds six, some slight cross-talk between individual groups may be noticeable. In general, troop schools of 40 students require 6 automatic keyers (see par. 8) but only one oscillator-amplifier. The oscillator-amplifier operates from a 110-volt 60-cycle source but is capable of maintaining adequate output at input voltages as low as 90 volts.




FIGURE 2.—Neat, simple arrangement of Lon-Ga-Tone automatic keyers. (Typical installation readily duplicated in any permanent or temporary building.)

Use of this oscillator-amplifier in installations for which keyer TG-10-B, Lon-Ga-Tone, or McElroy modified model G-813 units are supplied is generally restricted to furnishing constant tone to the switchboard BD-57-A which is part of equipment EE-81.

8. Automatic keyer, McElroy model G-813.—This unit is used to key automatically the separate tone source provided by the oscillator-amplifier ACA-10-AO. It can key the tone supplied to *one and only one* group of students; hence, for as many groups of students as it is anticipated will be formed at any one time during the process of instruction, just as many keyers are required. Keyers operate from a 110-volt 60-cycle source but are capable of keying satisfactorily at input voltages as low as 90 volts.

9. Code practice equipment EE-81.—The equipment EE-81 comprises a switchboard BD-57 or BD-57-A, 22 hand telegraph keys J-38, and 21 double headsets HS-16. Switchboard BD-57-A is a later and improved version of the BD-57. Each unit of equipment is adequate for handling 20 students; for each additional 20 students or portion thereof an additional EE-81 or EE-81-A is required. By means of each switchboard, circuits can be set up which group from 1 to 20 students on a single source of keyed tone, permit the instructor to monitor the transmissions, or permit individuals in the group to transmit to others therein.

10. Practice tapes.—A set of 15 master tapes is made available to each school. Used in connection with any of the automatic keyers, these tapes provide for practice transmissions as follows:

Tape No.	Contents	Speed per minute	
		Characters	Words
1	Receiving lesson I ¹	20	—
2	Receiving lesson II ¹	20	—
3	Receiving lesson III ¹	20	—
4	Receiving lesson IV ¹	20	—
5	Receiving lesson V ¹	20	—
6	Letters and numbers in random order	25	—
7	do	35	—
8	Code groups		10
9	Field traffic		12
10	do		12
11	do		15
12	do		15
13	do		15
14	do		20
15	do		20

¹ See TM 11-454.

These tapes were prepared in such a way, that, regardless of the speed of transmission in words per minute, the actual characters are

transmitted at a speed of 20 words per minute when the tape is running by the photoelectric cell at a constant speed of 12 feet per minute. Thus, on all tapes the speed of the characters is constant but the characters per foot of tape, and hence the words per minute transmitted, vary as indicated in the table above. (See app. II.)

11. Recorder, McElroy model RRD-900.—By means of this unit and a separate tone source (oscillator-amplifier ACA-10-AO or the oscillator-amplifier section only of the keyer TG-10-B or of the Lon-Ga-Tone automatic keyer, type 7), practice manual transmissions by a student can be recorded on a blank tape. Use of the automatic keying feature also permits the preparation of additional practice tapes from the master tapes. A switch can be used to facilitate the interconnection of tone source, automatic keyer, manual key, and recorder so as to make the recorder installation most flexible. The recorder operates from a 110-volt 60-cycle source but is capable of satisfactory recording at input voltages as low as 90 volts. Associated with the actual recorder is a tape puller, McElroy model CTP-1300, which pulls the blank tape past the recording stylus. (See fig. 3.)




FIGURE 3.—Recorder position. (On lower shelf are two McElroy recorders with associated tape pullers; on upper shelf are two Lon-Ga-Tone units. Tapes made on recorders can be played back immediately on Lon-Ga-Tone keyers.)

12. Reels, motion picture film, 16-mm, 400 feet.—These reels hold the practice tapes and are employed in pairs on each automatic keyer. They are standard film reels and fit the TG-10-B, the automatic keyers G-813 (both models), the Lon-Ga-Tone equipment, and the tape puller used with the recorder.

13. Record player for disk records, Columbia model P.—This is a portable phonograph consisting of an electric turntable, a phonograph pick-up, an audio-frequency amplifier, and a loudspeaker. It is used for sonic transmission of the radiotelegraph operator aptitude test from disk records. The speaker can be removed from the unit and mounted in a location more suitable from an acoustical viewpoint to permit sonic transmission of the test to a group of assembled students. The record player operates from a 110-volt 60-cycle source. (See fig. 4.)

Note.—The nomenclature, "code practice equipment EE-94-A" has been assigned to the complete equipment with all accessories except the code practice equipment EE-81 and the record player for a school of 20 students. Similarly "code practice equipment EE-95-A" and "code practice equipment EE-96-A" have been assigned to those for 40 and 100 student schools, respectively.



FIGURE 4.—Record player set-up for transmission of radiotelegraph operator aptitude test :
(Speaker (left) is detached from cover of carrying case.)

SECTION II

INSTALLATION FOR SERVICE

	Paragraph
General arrangement of equipment	14
Instruction tables	15
Total space requirements	16
Interconnection of units	17
Connecting switchboard BD-57 or BD-57-A	18
Input power circuit	19
Connecting oscillator-amplifier ACA-10-AO	20
Connecting automatic keyer, McElroy model G-813	21
Connecting automatic keyer, Lon-Ga-Tone, type 7	22
Connecting keyer TG-10-B	23
Connecting automatic keyer, McElroy model G-813, modified	24
Connecting transmission test table using automatic keying unit, McElroy model G-813	25
Connecting transmission test table using Lon-Ga-Tone automatic keyer, type 7	26

14. General arrangement of equipment.—Figure 5 is a block diagram of a typical equipment lay-out for a school of 40 students, using six McElroy automatic keyers, an ACA-10-AO tone source, a McElroy recorder, two switchboards BD-57-A, and various accessories. Similar arrangements are obviously possible with Lon-Ga-Tone and keyer TG-10-B units. The physical placement of equipment and tables will vary according to building dimensions. The student tables should be arranged to allow proper lighting and sufficient aisle space. The oscillator-amplifier tone source and all automatic keyers are grouped and located with respect to instruction tables so that their operation and adjustment will neither interfere with nor annoy student operators. If space is available, the keyers should be in a separate room. Each unit of the group is placed so as to allow easy access to all connections and to facilitate operation and adjustment of controls. The automatic keyer and the recorder used for making practice records and transmission tests are placed on a table that allows room for the equipment units, table wiring, proper placement of hand key, and comfortable arm space for the student and the instructor. The switchboard preferably is mounted at one end of the table of student positions which it controls. It can be mounted on the table itself or on a switchboard bracket. A suitable method of mounting the switchboard on an instruction table is shown in figure 6. When so placed it must be at sufficient height to prevent the switchboard cords from touching the floor but not so high as to




FIGURE 5.—Block diagram of typical school for 40 students.

prevent an instructor, when standing at the switchboard, from seeing all student positions. Other methods for mounting the switchboard are feasible, but regardless of the method used, it should be placed so as to allow easy access to its front for patching circuits and to its rear for making connections, so that external wiring can be brought in through the round hole at its right end (when viewed from the front).




FIGURE 6.—End assembly of instruction table, switchboard bracket, and switchboard.

15. Instruction tables.—A mess type table measuring 5 feet 2 inches by 24 feet, including seats, will provide 20 student positions and sufficient space for mounting a switchboard BD-57 or BD-57-A. The table top is preferably covered with $\frac{3}{16}$ -inch tempered Prestwood, or equal, to insure a good writing surface. Construction drawings are given in figures 7 and 8 for a 10-position instruction table and a switchboard bracket. Standard sizes and lengths of lumber are employed in their construction. Wood screws, with all screw holes countersunk, are employed for the assembly of the table. This construction facilitates assembly and disassembly for moving the table from one room to another or for storage. Two tables can be bolted together to make a 20-student table if space permits. If the 10-position table is used as a unit, only one switchboard bracket for each two

tables is needed. The 20-student positions on the switchboard will then be divided equally between the two tables.




FIGURE 7.—Ten-position instruction table.




FIGURE 8.—Details of switchboard bracket.

16. Total space requirements.—Approximately 260 square feet of floor space are required for each group of 20 students and an additional 12 square feet per keyer, recorder, and oscillator-amplifier. A code room for 100 students should have approximately 1,500 square feet of floor space to provide for aisles. A room less than 20 feet wide is unsatisfactory.

17. Interconnection of units.—*a. Switchboard BD-57-A.*—Figures 9 and 10 are block diagrams of an installation for a school of 40 students, using two switchboards BD-57-A as the distributing system. If the McElroy G-813 automatic keyers are furnished, the M and S terminals are all paralleled to the 1 and 2 posts of the ACA-oscillator-amplifier, to the AUX SWBD TONE posts of the switchboards, and across to the transmission test table. If Lon-Ga-Tone, keyer TG-10-B or McElroy modified model G-813 units are furnished, the oscillator-amplifier is connected only to the AUX SWBD TONE posts. Combinations of keyers TG-10-B, McElroy, and Lon-Ga-Tone units can be used without interference.






FIGURE 9.—Diagram of typical set-up of code practice equipment for school of 40 students.



*Transmission test table, using automatic keying unit,
Model G-813*

— Constant tone
— Keyed tone



*Transmission test table, using automatic keyer, Lon-Ga-Tone,
Type No. 7*

FIGURE 10.—Transmission test table diagrams showing use of both McElroy and Lon-Ga-Tone automatic keyers.

b. *Switchboard BD-57.*—This switchboard has only one connection for outside tone source. Therefore, all students must take the same keyed tone, or all must practice sending to themselves or to each other at the same time. This arrangement has serious shortcomings from the standpoint of progressive instruction. The switchboard can be rewired to make it the equivalent of the newer BD-57-A by following the special instructions given in appendix I. If the switchboard is to be used as issued, only one keyer at a time can be connected to each, and students of approximately the same speed ability must be assigned to the respective tables. Figure 11 shows the simple connections of this switchboard.

18. *Connecting switchboard BD-57 or BD-57-A.*—Figure 12 is a schematic diagram of the terminal board on a switchboard BD-57-A. This terminal board is an integral part of the switchboard and is accessible from the rear thereof.




FIGURE 11.—Diagram of switchboard BD-57 used with either McElroy or Lon-Ga-Tone keyers. (If more than one switchboard is used with McElroy model G-813 automatic keyers, tone source connections are paralleled across as in fig. 9.)




FIGURE 12.—Terminal board of switchboard BD-57-A.

a. Student positions.—Mount a key J-38 at each student position as shown in figures 6 and 14. At approximately 1 percent of the student positions mount the key so as to facilitate operation by left-handed operators; that is, 12 inches from the left of the student position and rotated 30° to the left instead of the right. Connect a headset HS-16 to each key J-38, as shown in figure 13. Tie the stay cord on the cord of each headset HS-16 to one of the terminals on each key J-38. Starting at the end of the table nearest the switchboard BD-57-A (see fig. 6) and alternating left and right, connect the student line terminals on the keys J-38 to student line terminals 1 through 20 on the switchboard BD-57-A. Use twisted pair wire W-33, or equal, for all student lines. Run the wire to each student position through a small hole in the top of the instruction table located to the right of the key. Cable the wires or group them in cable hooks under the table. Blake No. 3 insulated staples or equal can be used to support individual pairs until they are picked up in the cable or rings. Run the wires (or cable) through the 1 $\frac{1}{4}$ -inch square holes in the table braces under the table top as shown in the end view of a 10-position instruction table (fig. 7). Pass the wires (or cable) through the round hole in the right side of the switchboard BD-57-A.




FIGURE 13.—Connections of key and headset at student position.




FIGURE 14.—Appearance of facing student positions, with student participating in actual keying practice.

b. Instructor's key.—Mount a key J-38 for convenient operation by an instructor at the switchboard BD-57-A. Connect a headset HS-16 thereto as indicated in figure 13. Using twisted pair wire W-33 or equal, connect the line terminals of the key to the terminals marked INSTRUCTOR on the terminal board of the switchboard BD-57-A. This wire can be included in the cable indicated in *a* above.

c. Auxiliary tone cords.—Connect each of the terminals marked AUX 1, AUX 2, AUX 3, AUX 4, AUX 5, and AUX 6 to similarly marked terminals on other switchboards BD-57-A (figs. 9 and 12). The number of switchboards so paralleled is determined from a consideration of the number of available automatic keyers and the number of switchboards to which it is desired to supply keyed tone from a particular keyer. In 40-student schools when only six automatic keyers are made available, all switchboards are paralleled. In large schools, it may be advisable to use terminal strips to provide for increased flexibility in the interconnection of switchboards and the keyers. One pair of terminals on a single terminal strip is provided for each of the auxiliary switchboard cords on each switchboard, and on an adjacent strip there is provided a pair of terminals for the output of each automatic keyer. Interconnection between strips can then be made to connect any automatic keyer to any or all auxiliary tone cords on any switchboard. Jack boards with interconnecting plugs may be substituted for the terminal strips. Use twisted pair wire W-33 or equal in the wiring to all auxiliary tone cords.

d. Master key.—Connect a short piece of jumper wire across the terminals marked MASTER KEY (see fig. 12). A master key is not used in this circuit.

e. Battery terminals.—The terminals marked -12V+ are left open, as no battery is required. The motor-alternator mounted inside the case of the switchboard is not used and may be ignored.

f. Auxiliary switchboard tone.—Connect in parallel, using twisted pair wire W-33 or equal, the terminals marked AUX SWBD TONE (fig. 12) on each of the switchboards BD-57-A which are to be supplied constant tone from a single source.

19. Input power circuit.—A decision having been reached as to the exact location of each tone source, automatic keyer, recorder, and record player, install a 110-volt 60-cycle bus, so that standard outlets thereon will be readily accessible at the location of each of these units (see fig. 5). Use a wire of sufficient size to insure good voltage regulation over the bus. Each unit requiring power for its operation is equipped with an input power cord with standard plug. If power outlets are already available in the instruction room, their location may influence the location of each of the units mentioned above. In general, it is better to extend the length of the power input cords on individual pieces of equipment than it is to disperse units in accordance with available power outlets.

20. Connecting oscillator-amplifier ACA-10-AO.—The terminals of the oscillator-amplifier ACA-10-AO are located on the rear of the chassis and are shown in figure 15.




FIGURE 15.—Terminal board of ACA oscillator-amplifier.

a. Power input cord.—When ready for operation, plug the power input cord into the available outlet on the 110-volt 60-cycle bus (see par. 18).

b. Output terminal strip.—(1) Connect the terminals marked 1 and 2 on the output terminal strip (also marked C and L, respectively) to the terminals marked AUX SWBD TONE on the nearest switchboard BD-57-A. Use twisted pair wire W-33 or equal. This lead connects the constant tone output of the oscillator-amplifier to the primary circuits of the switchboards BD-57-A which were connected parallel as indicated in paragraph 18*f*. Connect the terminal marked 1, the common terminal, to ground.

(2) Connect a second twisted pair lead from terminals 1 and 2 on the oscillator-amplifier to the proper relay terminals on each of the automatic keying units, McElroy model G-813, which are to key the output of the oscillator-amplifier (see figs. 9 and 16). The relay terminals are not marked as such on the automatic keyer; however, they are properly labeled in figure 1 and the correct wiring is indicated thereon.

21. Connecting automatic keyer, McElroy model G-813.—The terminals of the automatic keyer, McElroy model G-813, are located on the top of the chassis to the right rear adjacent to the relay, as shown in figure 16.




FIGURE 16.—Connections to McElroy keyer, model G-813.

a. Power input cord.—When ready for operation, plug the power input cord, located at the left end of the tape puller chassis, into the available outlet on the 110-volt 60-cycle bus. Polarize this plug so that no difference of potential exists between the chassis of the unit and ground. No harm will result when the plug is inserted with either polarization, but with one polarization a slight voltage will exist between chassis and ground which may be annoying to the touch.

b. Relay terminals.—(1) *Constant tone input.*—Constant tone input from the oscillator-amplifier is obtained by connecting the lead mentioned in paragraph 20b (2) across the mark and space terminals (see fig. 16).

(2) *Keyed tone output.*—Using twisted pair wire W-33 or equal, connect the tongue and space terminals on successive automatic keying units to successive pairs of terminals marked AUX 2, AUX 3, AUX 4, AUX 5, and AUX 6 on the terminal board of the nearest switchboard BD-57-A (see fig. 9). A systematic numbering of automatic keying units to conform with the numbering of the auxiliary tone cords on the switchboards BD-57-A is desirable. Connection is made to auxiliary tone cords by means of the terminals AUX 2, AUX 3, AUX 4, AUX 5, and AUX 6. When more than six automatic keying units are supplied, the connections described above may be modified as indicated in paragraph 18c.

22. Connecting automatic keyer, Lon-Ga-Tone, type 7.—The terminals of automatic keyer, Lon-Ga-Tone, type 7, are located on the rear of the chassis and are as shown in figure 17.




FIGURE 17.—Connections of Lon-Ga-Tone keyer, type 7.

a. *Power input cord*.—When ready for operation, plug the power input cord into the available outlet on the 110-volt 60-cycle bus (see par. 19).

b. *Output terminal strip*.—(1) *Automatically keyed output*.—Using twisted pair wire W-33 or equal, connect terminals 1 and 3 of the output terminal strip (fig. 17) on successive automatic keyers to successive terminals marked AUX 2, AUX 3, AUX 4, AUX 5, and AUX 6 on the terminal board of the nearest switchboard BD-57-A (see fig. 9). A systematic numbering of automatic keyers to conform with the numbering of the auxiliary tone cords on the switchboards BD-57-A is desirable. Connection is made to auxiliary tone cords by means of the terminals AUX 2, AUX 3, AUX 4, AUX 5, and AUX 6. When more than six automatic keyers are supplied, the connections described above may be modified in a manner indicated in paragraph 18c.

(2) *Manually keyed output*.—If it is desired that a constant tone output from the unit be arranged for manual keying, mount a key J-38 near the automatic keyer, and connect this key to terminals 5 and 6 on the output terminal strip (fig. 17).

23. Connecting keyer TG-10-B.—The keyer TG-10-B can be used wherever the use of the Lon-Ga-Tone keyer is indicated in any of the diagrams appearing in this manual. Plug the flexible power input cord into the nearest 110-volt outlet. Take the tape-keyed tone output from the screw binding posts on the right back edge of the chassis. There are four such posts, marked COM, 4, 8, 16. The first is the common secondary connection, and the others represent the different impedance taps. Use the COM post and *one* only of the others, depending on how many student positions are to be fed keyed signals. A few quick trials will determine the best output impedance. To key the tone output of this instrument by

hand, connect a key to the posts on the back of the chassis marked KEY.

24. Connecting automatic keyer, McElroy model G-813, modified.—A top view of the chassis, showing the binding posts, is given in figure 18. On the actual instrument, the terminals are not marked at all, but they are identified by numbers as indicated for convenience in establishing external connections. This keyer, having its own tone source, is installed in the same manner as the Lon-Ga-Tone. Where any of the preceding diagrams show terminals 1 and 3, and 5 and 6, of the Lon-Ga-Tone unit, the same connections are used to the correspondingly numbered posts of the modified G-813 unit.




FIGURE 18.—Arrangement of binding posts on McElroy keyer, model G-813, modified. (Tape-keyed tone output is obtained from posts 1 and 3. If it is desired to use keying elements only of this unit to key external tone source (as from ACA oscillator-amplifier), terminals 2 and 4 are employed.)

25. Connecting transmission test table using automatic keying unit, McElroy model G-813.—*a. General.*—Figure 10 shows a method of interconnecting the automatic keying unit, McElroy model G-813, a recorder, a manual key, and a headset to provide for transmission tests, for the preparation of additional practice tapes, or for using the keyed tone output of the automatic keying unit on the auxiliary tone cords No. 1 of the switchboards BD-57-A. Note that the input cord for keyed tone and *not* the local keying posts (fig. 19) is used for connecting the keyed tone input to the recorder. Note also that on this particular automatic keying unit the mark and tongue contacts of the relay (fig. 16) are merely connected in series with the constant tone bus and the recorder. This method of connection facilitates the play-back of tapes prepared by students in that no switching is required. The manual key is connected in parallel with the mark and tongue con-

tacts. A headset HS-16 is connected in parallel with the keyed tone input to the recorder. Auxiliary tone cord No. 1 on switchboards BD-57-A may also be connected in parallel with the input to the recorder.

b. Recorder, McElroy model RD-900.—Figure 19 indicates the location of the terminals of the recorder, McElroy model RD-900.




FIGURE 19.—Connections of McElroy recorder.

c. Tape puller, McElroy model CTP-1300.—The only connection to this unit is the power input cord located on the left side of the chassis.

d. Power input cords.—When ready for operation, plug the power input cords (figs. 16 and 19) into the available outlets on the 110-volt 60-cycle bus. Polarize these plugs so that no difference of potential exists between the chassis of any unit and ground.

26. Connecting transmission test table using Lon-Ga-Tone automatic keyer, type 7.—*a. General.*—Figure 10 shows a method of interconnecting a Lon-Ga-Tone automatic keyer, a recorder, a manual key, and a headset to provide for transmission tests, for the preparation of additional practice tapes, or for using the keyed tone output of the automatic keyer on the auxiliary tone cords No. 1 of the switchboards BD-57-A. The input cord for keyed tone on the recorder (fig. 19) is connected directly to terminals 1 and 3 (fig. 17) on the automatic keyer. A manual key is connected to terminals 5 and 6 on the automatic keyer. A headset with standard two-conductor plug inserted in the jack marked MONITOR on the front panel of the automatic keyer permits a student to monitor his transmission and play-back. Terminals 1 and 3 on the automatic keyer also can be connected to the auxiliary tone cords of the switchboards BD-57-A.

b. Power input cords.—When ready for operation, plug the power input cords of the automatic keyer, the tape puller, and the recorder

into the available outlets on the 110-volt 60-cycle bus. Polarize the plugs as indicated in paragraph 25d.

SECTION III

OPERATION

	Paragraph
Oscillator-amplifier ACA-10-AO-----	27
Automatic keyer, McElroy model G-813-----	28
Automatic keyer, Lon-Ga-Tone, type 7-----	29
Keyer TG-10-B-----	30
Automatic keyer, McElroy model G-813, modified-----	31
Recorder, McElroy model RRD-900-----	32
Record player, Columbia model P-----	33
Switchboard BD-57-A-----	34
Preliminary adjustment of tone level-----	35
Initiating complete operation-----	36

27. Oscillator-amplifier ACA-10-AO.—The controls on this unit are located as shown in figure 20.




FIGURE 20.—Oscillator-amplifier chassis controls.

a. *Low impedance output selector.*—Remove the four screws holding the chassis cover in place and lift cover upward off the chassis. The low impedance output selector is located on the right side of the chassis top. Place the pin plug in the connector marked "4" for preliminary tests. Replace the chassis cover.

b. *Push switch.*—The oscillator-amplifier is turned on by pressing in the push switch. When the pilot light is on, the oscillator-amplifier is turned on.

c. Gain control.—The control marked GAIN varies the output tone level, increasing the level as the knob is rotated clockwise from 0 to 10.

28. Automatic keyer, McElroy model G-813.—The controls on the automatic keying unit, McElroy model G-813, are located as shown in figure 22.

a. Mounting practice tapes.—Mount an empty 400-foot reel on the take-up spindle located on the left of the tape puller unit. Mount the desired practice tape on the rewind spindle located on the right front of keying unit so that the tape comes off the bottom of the reel, i. e., the inked side of the tape is up. Lift the lamp house and tape guide upward and lay the tape over the aperture bar and replace the tape guide. Slip the tape toward the practice tape reel until the end of the tape is just to the right of the aperture in the aperture bar (see fig. 21). Move the aperture bar so that the aperture is directly




FIGURE 21.—Adjustment of photoelectric cell aperture on McElroy automatic keyer.

opposite the top inked line where a dot or dash is made. As the tape is drawn over the aperture the light from the exciter lamp is interrupted by the inked dots and dashes. Lower the lamp house into position. Thread the tape around the guide and puller, then onto the take-up reel as shown in figure 22. This tape path gives the best pulling action. No other should be used.

b. Controls.—(1) *Keying unit line switch.*—The automatic keying unit is turned on by an upward movement of the toggle switch located near the rear on the right end of the chassis. Operation of this switch turns on the exciter lamp located in the lamp house and supplies power to all vacuum tubes in the unit. This switch should be operated 20 to 30 seconds prior to initiating complete operation of the unit so as to permit tubes therein to warm up.




FIGURE 22.—Controls of McElroy model G-818 automatic keyer.

TL-3372

(2) *Tape puller line switch.*—The tape puller motor is started by a rearward movement of the toggle switch next to the ground binding post of the tape puller. When starting, the speed control toggle

switch should be in its forward position and the speed control rheostat located on the left end of the tape puller should be set at 5. After the motor has started, throw the speed control toggle switch to the rear and adjust the speed control rheostat for desired speed. A clockwise rotation of the speed control rheostat increases the motor speed. The tape puller motor should be operated for approximately 15 minutes prior to initiating complete operation of the unit so as to allow it to reach a constant speed. The motor should be operated for this period of time prior to insertion of the tape as indicated in *a* above. More constant speeds are obtained with the speed control toggle switch in its rear position. The switch is left in its forward position only for starting and for very high speeds.

(3) *Photoelectric cell bias*.—The knob control marked "photoelectric cell bias" in figure 22 is adjusted to obtain clean keying. Initially set this control between 1 and 4. If the adjustment of the aperture as indicated in *a* above has been incorrectly made there will be no setting of this control which will result in proper keying. If this is the case recheck the aperture adjustment.

c. Relay model 3A.—The relay model 3A located at the rear of the keying unit should be adjusted only by experienced instrument repairmen. Under normal operating conditions it should require little attention. If clean keying does not result after proper adjustment of the aperture and photoelectric cell bias, the relay should be examined through its glass cover. If maladjustment is noted remove the relay from its plug-in socket and replace with a spare relay properly adjusted.

29. Automatic keyer, Lon-Ga-Tone, type 7.—The controls on the Lon-Ga-Tone automatic keyer, type 7, are located as shown in figure 23.

a. Mounting practice tapes.—Mount an empty 400-foot reel on the spindle indicated in figure 23. Mount the desired practice tape reel on the spindle of the rewind located on the right of the front panel. The rewind is hinged to the panel so that it can be moved away from the panel to facilitate the mounting of the reel. This reel is mounted so that the tape leaves the bottom of the reel, for example, so the inked side of the tape is upward. The tape is passed under the guide, through the track in the photoelectric cell house, between the idler and puller wheels, into a slot on the hub of the empty reel mounted as indicated above. To relieve the tension on the tape between the idler and puller wheel, pull out and upward on the knurled knob on the idler wheel shaft. This locks the idler wheel arm in a position that allows the tape to be pulled between the two

wheels for rewind purposes as well as for threading the tape between the wheels. To disengage the idler wheel arm from its raised position, push in on it, and the idler wheel will drop onto the tape into its pulling position.




FIGURE 23.—Front-panel controls of Lon-Ga-Tone keyer.

b. Controls.—(1) *Main switch.*—The toggle switch marked MAIN controls the 110-volt 60-cycle supply. When the switch is thrown to the ON position, the pilot lamp, the exciter lamp in the lamp house, and all vacuum tubes are turned on.

(2) *Speed control.*—The control knob marked SPEED varies the speed of the tape puller, hence the speed of the tape passing the light beam. A clockwise rotation of the knob gives an increase in speed. The knob is turned so that it points to the letter "S" in the word INCREASE for starting speed. Immediately after the motor switch is turned to the ON position, and the tape reels have started, the speed control is adjusted for the desired keying speed. The puller will not properly start the reels at low tape speed.

(3) *Motor switch.*—The toggle switch marked MOTOR controls the 110-volt 60-cycle supply to the tape puller and take-up motors. This switch is not turned on until the speed control has been adjusted for starting as explained in (2) above.

(4) *Key-tape switch.*—For automatic keying from the tape, the toggle switch is thrown to TAPE position. For manual keying, the toggle switch is thrown to KEY position, and the key J-38 connected as explained in paragraph 22b(2) is used.

(5) *Monitor.*—The jack marked MONITOR is used for headset monitoring of the automatic or manual keying. A headset HS-4 with plug PL-48 is used. Plugging into the monitor jack does not affect the output of the automatic keyer.

(6) *Volume control.*—The screw driver control marked VOLUME controls the output level of the keyed tone. A clockwise rotation increases the tone level. Move this control to the left as far as possible, then move clockwise until the screw driver slot is vertical ($\frac{1}{8}$ to $\frac{1}{4}$ of a turn) and leave in this position for preliminary tests.

(7) *Photoelectric cell house aperture and PEC BIAS.*—Turn PEC BIAS knob so as to point toward the volume control. Pull the sliding barrel with knurled top outward as far as it will go, then push inward gradually until the small square aperture comes under the lower line of the inked tape as shown in figure 24. It is important to note that while the same practice tapes are used in both the McElroy and Lon-Ga-Tone keyers, the adjustments of the apertures are different. The McElroy unit keys on the *inked* sections of the tape; the Lon-Ga-Tone on the *uninked* sections. This adjust-




FIGURE 24.—Correct adjustment of tape in relation to aperture of Lon-Ga-Tone keyer.

ment is best accomplished by slipping the tape end to the right of the track and watching the inward motion of the aperture. After threading the tape, throw the main switch to the ON position and, after 30 seconds, the motor switch to the ON position. The PEC BIAS knob is slowly rotated counterclockwise until keying is heard in the monitoring head set. Slight adjustments of the sliding barrel and the PEC BIAS knob will give proper keying.

30. Keyer TG-10-B.—The general instructions given for the Lon-Ga-Tone unit apply also to the automatic keyer TG-10-B. To disengage the puller roller, when threading on a tape, push it to the right, and it will stay open. To reengage it, raise the puller idler and the assembly will snap back into position. Figure 25 shows a

general front view of the TG-10-B, with a tape in correct position. Of the front-panel controls, the tape speed, monitor, volume, and bias functions are exactly the same as in the Lon-Ga-Tone. However, the power control is different. This is a three-position rotary switch, with the positions marked OFF, KEY, and TAPE. In the first or OFF position, the entire apparatus is dead. In the second or KEY position, the oscillator-amplifier section is turned on, and the hand key controls the tone output; both the puller motor and the exciter lamp are inoperative. In the third or TAPE position, the motor and the lamp are turned on in addition to the oscillator-amplifier, and the unit then functions as a full automatic tape keyer. The numbers on the tape speed dial indicate the number of feet of tape per minute, not words per minute.

31. Automatic keyer, McElroy model G-813, modified.—*a.*
General.—The adjustments and controls of this equipment are shown in figure 26. The model G-813, modified, closely resembles the model G-813 as described in paragraph 28. The identical tape mechanism is used on the keyer itself, and the tape puller differs only in that the auxiliary speed control switch found on the G-813 is not present. All instructions regarding the threading of the tape, the adjustment of the various guides and spindles, as given for the G-813, apply as well to the G-813 modified.

b. Controls.—(1) *Line switches.*—The line switch S1, which is mounted on the back of the keyer chassis, is left in the ON position, and the keyer circuits are controlled by switch S2 mounted on the case of the tape puller. As supplied by the manufacturer, the keyer and the tape puller are already wired together, and a single 110-volt plug provides power for both units.

(2) *Bias control.*—This is adjusted as described in paragraph 28*b*(3).

(3) *Tone frequency control.*—This is located on the back edge of the chassis. Adjust it for a pleasing signal, and then leave it alone.

(4) *Manual keying.*—Two binding posts for a manual key are provided on the back edge of the chassis. Normally, these are kept short-circuited by a brass strap, as there will be little occasion to hand-key the output of the instrument directly at the position at which it is mounted.

(5) *Monitoring.*—A monitoring jack is mounted under the binding posts on the right side of the chassis. A pair of phones can be plugged into it without affecting the keyed output.




FIGURE 26.—Front view of keyer TG-10-B with tape in position.

TL-4039




FIGURE 26.—Arrangement of essential parts and controls of McElroy keyer, model G-813, modified.

(6) *Relay*.—The keying relay is mounted on the underside of the chassis. This is not adjustable, and is not likely to give trouble during the normal life of the equipment.

32. Recorder, McElroy model RRD-900.—Adjustments and controls on the recorder, McElroy model RRD-900, are located as shown in figure 27.

a. *Mounting blank tapes*.—Place a standard roll of $\frac{3}{8}$ -inch un-gummed tape on the tape plate so that the tape will feed to the left from the back of the tape plate. Thread the tape around the back of guide 1, the back of guide 2, the front of the tape roller, and the back of guide 3. Pull enough tape from the roll to reach the tape puller associated with the recorder. This tape puller should be so mounted that guide 3 is lined up vertically and horizontally with the top guide on the tape puller (see fig. 22). Rotate the tape a quarter turn so that the top side of the tape over the latter guide is that on which the stylus of the recorder operates. Thread the tape through the tape puller as shown in figure 22. It is inadvisable to use a take-up reel on the puller while a tape is being prepared, particularly so if the tape puller is mounted adjacent to the recorder. Ink is likely to smear on adjacent turns of tape. Furthermore, if the tape is taken up while recording, a rewind operation is required. A more suitable practice is to allow the inked tape to feed off the puller into a waste basket or other receptacle on the floor, and if required, to rewind the tape therefrom upon completion of a record-

ing. A rewind of a student transmission test tape is seldom required as this short tape may be fed directly into an automatic keying unit.




FIGURE 27.—Controls and adjustment on McElroy recorder.

b. Recorder controls.—(1) *Line switch.*—An upward movement of the toggle switch located on the right front of the chassis supplies power to the recorder. The filaments of the vacuum tubes therein

should light. A flash may be observed within these tubes which is characteristic of the tubes employed. Allow 30 seconds for warming up of tubes prior to initiating operation of the recorder.

(2) *Change-over switch*.—A change-over switch, located on the left front of the chassis, controls the input to the armature coil of the recorder mechanism. Since use of the local keying posts on the rear of the chassis is not recommended, this switch may be used as the off-on switch of the recorder output circuit. An upward movement connects the armature coil to the output of the recorder amplifier. When it is desired to keep the recorder warm but to maintain it in an inoperative condition, leave this switch in its down position.

c. *Ink supply*.—Loosen the inkwell locking screw and lower the inkwell to its lowest position. Remove the top of the inkwell and fill the well about three-fourths full with Higgins Eternal black ink, or equal. Replace the inkwell top.

d. *Adjustments*.—(1) *Lower armature stop*.—Turn the tape roller adjusting screw in a clockwise direction (when viewed from the front of the recorder) until the stylus just leaves the tape. Loosen the lock nut on the lower armature stop. Adjust the stop until the bottom of the stylus is about one-third way up the tape. Tighten the lock nut.

(2) *Upper armature stop*.—Loosen the lock nut on the upper armature stop. Adjust this stop until the travel of the armature between its upper and lower stops is $\frac{1}{8}$ inch. Tighten the lock nut.

(3) *Armature spring tension*.—Loosen the lock nut on the armature spring adjusting screw. Adjust this screw until the armature is firmly held against the lower armature stop by the tension in the armature spring. Tighten the lock nut. This adjustment is not critical but may require readjustment after operation of the recorder is initiated in order to effect clean keying.

(4) *Ink adjustment*.—Rotate the tape roller adjusting screw in a counterclockwise direction (when viewed from the front of the unit) until the tape just makes contact with the stylus. Loosen the inkwell locking screw and raise the inkwell until the level of the ink therein is about 1 inch above the stylus. Tighten the locking screw. Pull the tape by hand slowly by the stylus. A solid black line should be recorded about one-third of the way up the tape. If this line is not smooth and solid, move the tape roller adjusting screw in a counterclockwise direction so as to increase slightly the pressure between the stylus and the tape roller. If no line is recorded, the stylus may be clogged. If this is the case, lower the ink-

well and remove the ink hose from the stylus. By means of the tape roller adjusting screw, move the tape roller away from the stylus. Insert a fine wire in the ink hose end of the stylus and remove any obstructions therefrom. Replace the ink hose, raise the inkwell to the proper level, and readjust the tape roller against the stylus by means of the tape roller adjusting screw.

33. Record player, Columbia model P.—The control marked VOLUME should be turned completely to the left prior to plugging the input power cord into a 110-volt 60-cycle outlet. The desired disk record is placed on the turntable, and the 110-volt 60-cycle supply is turned on by turning the knob marked VOLUME to the right. The initial movement operates a switch in the 110-volt 60-cycle supply; the remainder of the clockwise rotation increases the speaker volume. The needle held in the pick-up head is lowered gently into the outermost groove in the record. The tone control is adjusted for the reproduction quality desired. When the tone control is turned to the left, bass is accentuated; when turned to the right, treble is accentuated. For use in a large room the speaker compartment is removed by sliding it to the left so as to disengage the hinges. A hook is provided on the speaker compartment for use in hanging the speaker on a wall. The wall gives baffle effect to the speaker, resulting in better tone reproduction and sound direction for large rooms.

34. Switchboard BD-57-A.—a. General.—Figure 28 shows the jack field and the cords of the switchboard BD-57-A. The red cords indicated thereon are the auxiliary tone cords which furnish the keyed tone output of the automatic keyers for use at the switchboard. The black cords are student cords and hang directly under the student jacks with which they are associated. They are used for interconnecting student positions for various purposes. The white cord is the instructor's cord and is used for monitoring transmissions or for manually keying to students from the switchboard BD-57-A. This switchboard permits the establishment of circuits to its student positions so as to furnish groups of students with the following instruction:

- (1) Practice transmissions by each student which are monitored only by that student.
- (2) Grouping of all or several of the students into a net so that a transmission by any one of the students is received by all students in the group. This is subsequently referred to as net operation.
- (3) Grouping of all or several of the students so as to receive keyed tone from any one of five automatic keyers.

(4) Grouping all or several of the students so as to receive signals from a radio receiver or from the automatic keyer associated with a recorder on the transmission test table.

b. *Individual student keying.*—When constant tone is supplied to the switchboard BD-57-A and none of the plugs is inserted into any jack, every student connected to the switchboard receives constant tone as long as his key J-38 is closed. Opening the switch on his key permits any student to key this tone and to monitor his transmission independently of any other student.

c. *Net operation.*—Assume that it is desired to interconnect the student at position No. 1 with the student at position No. 5 in order that each may transmit to the other. Insert the plug associated




FIGURE 28.—Jack and cord arrangement of switchboard BD-57-A.

with student position No. 1 into jack No. 5 of the row of jacks marked STUDENT JACK FOR SWBD TONE. Insert the plug associated with student position No. 5 into jack No. 1 on the row of jacks marked STUDENT JACK FOR SWBD TONE. The students at positions Nos. 1 and 5 are now connected in series and either may transmit to the other as long as the other's key is closed. Such a transmission is interrupted when the receiving student opens his key. Assume that it is desired to interconnect all students for net operation. Insert the plug associated with student position No. 1 into jack No. 2 of the row of jacks marked STUDENT JACK FOR SWBD TONE. Insert the plug associated with student position No. 2 into jack No. 3 of the row of jacks marked STUDENT JACK FOR SWBD TONE. Proceed in a similar manner until the plug

associated with student position No. 19 has been inserted in jack No. 20 of the row of jacks marked STUDENT JACK FOR SWBD TONE. Insert the plug associated with student position No. 20 into jack No. 1 on the row of jacks marked STUDENT JACK FOR SWBD TONE. All students are now connected in series and as long as the keys of all other positions are closed, any student may transmit to all others. If any other key is open, the transmission is interrupted.

d. Reception of automatically keyed tone.—Assume that it is desired to furnish the student at position No. 1 with keyed tone from the automatic keyer No. 2 which is associated with the auxiliary tone cord No. 2. Insert the student cord associated with position No. 1 into jack No. 1 on the row of jacks marked STUDENT JACK FOR AUX TONE. Insert auxiliary tone cord No. 2 into jack No. 1 on the row of jacks marked SUPERVISORY OR AUX TONE JACK. The student at position No. 1 will now receive the keyed tone output of automatic keyer No. 2. Assume that it is desired to connect the students at positions Nos. 1 and 5 on the keyed tone output of automatic keyer No. 2. Insert the plug associated with student position No. 1 into jack No. 5 on the row of jacks marked STUDENT JACK FOR AUX TONE. Insert the plug associated with student position No. 5 in jack No. 1 of the row of jacks marked STUDENT JACK FOR AUX TONE. Insert the auxiliary tone cord No. 2 into jack No. 1 or No. 5 on the row of jacks marked SUPERVISORY OR AUX TONE JACK. The students at positions Nos. 1 and 5 may be connected as indicated above, while other students remain interconnected as indicated in *c* above for practice transmissions. Assume that it is desired that all students receive the keyed tone output of automatic keyer No. 3. Insert the plug associated with student position No. 1 into jack No. 2 on the row of jacks marked STUDENT JACK FOR AUX TONE. Insert the plug associated with student position No. 2 into jack No. 3 on the row of jacks marked STUDENT JACK FOR AUX TONE. Proceed in a similar manner until the plug associated with student position No. 19 is inserted in jack No. 20 on the row of jacks marked STUDENT JACK FOR AUX TONE. Insert the plug associated with student position No. 20 into jack No. 1 on the row of jacks marked STUDENT JACK FOR AUX TONE. Plug the auxiliary tone cord No. 3 into any one of the jacks on the row of jacks marked SUPERVISORY OR AUX TONE JACK.

e. Reception of other signals.—Auxiliary cord No. 1 may be used

to introduce into the switchboard BD-57-A the output of a radio receiver or the keyed tone output of the automatic keying unit associated with the recorder on the transmission test table. When so used, circuits for receiving the output of these units are set up in a manner identical to that described in *d* above, except that auxiliary switchboard tone cord No. 1 is used.

f. Monitoring operations.—When it is desired to monitor the transmission on any student line, insert the instructor's white cord into the jack on the row of jacks marked SUPERVISORY OR AUX TONE JACK which is associated with the student's line. The signal which is present in the line actuates the headset HS-16 associated with the instructor's position at the switchboard BD-57-A. If several students are interconnected for the reception of a single transmission, a jack on the row of jacks marked SUPERVISORY OR AUX TONE JACK which is associated with any one of the student positions may be employed. When the instructor's cord is inserted in a jack, the switch on the key J-38 at the instructor's position should be closed.

g. Panel controls.—(1) *Potentiometer.*—Mounted at the right side of the front panel is a potentiometer by means of which the volume level of constant tone which is supplied to students for individual keying or for net operation may be adjusted.

(2) *Battery switch.*—With the equipment described herein the switch marked BATTERY is not used. Leave it in the OFF position.

(3) *Switchboard tone switch.*—The switch marked SWBD TONE as used with the equipment described herein is an off-on switch for the constant tone supplied to the switchboard. When rotated to the right (to AUX), constant tone is supplied to the switchboard from the external oscillator-amplifier. Rotation to the left (to GN-33) opens the constant tone circuit.

35. Preliminary adjustment of tone level.—*a. Using automatic keyer, McElroy model G-813.*—(1) Patch a circuit on a switchboard BD-57-A which will permit each student position connected thereto to receive the keyed tone output of automatic keyer No. 2 (see par. 34).

(2) Turn on the oscillator-amplifier ACA-10-AO. Set the control marked GAIN at 5 (see par. 27).

(3) Mount a practice tape on automatic keyer No. 2. Turn on the automatic keyer and adjust for clean keying (see par. 28).

(4) Note the keyed tone level at any one of the student positions.

Adjust the oscillator-amplifier low impedance output selector (fig. 20) by connecting successively to terminals 4, 8, 12, and 16 until a suitable level of keyed tone is noted in a student headset. A suitable level will be produced by an output of 3.5 to 7 volts, as measured at a student position with an output meter. The oscillator-amplifier has a rated audio output of 10 watts, which is more power than is needed for the largest contemplated school; therefore, the choice of terminals on the low impedance output selector will not be critical. The lowest impedance output that will give a comfortable signal under maximum load conditions is used. The 500-ohm termination on the oscillator-amplifier should never be used as it would give a voltage that would cause serious inductive trouble in adjacent circuits.

(5) Mount a blank tape on the recorder, McElroy model RRD-900. Adjust the recorder for proper operation (see par. 32).

(6) Operate the manual key at the transmission test table. The tone level adjustment effected in (4) above should be adequate to effect clean recording. If not, readjust the low impedance output selector on the oscillator-amplifier ACA-10-A0 until satisfactory recording is accomplished.

(7) With a permanent adjustment made as indicated above, adequate variation in tone levels to conform with major load variations is accomplished by means of the control marked GAIN on the oscillator-amplifier.

(8) With the tone level set as indicated above, variation in the level of constant tone supplied to students for individual keying or for net operation may be accomplished by means of the control marked POTENTIOMETER on the switchboard BD-57-A.

b. *Using automatic keyer, Lon-Ga-Tone, type 7.*—(1) Patch a circuit on a switchboard BD-57-A which arranges all student positions for net operation (see par. 34). Set the control marked POTENTIOMETER approximately at the center of its range. Turn the switch marked SWBD TONE to AUX.

(2) Turn on the oscillator-amplifier ACA-10-AO. Set the control marked GAIN at 5 (see par. 27).

(3) Operating a key at a student position, note the keyed tone level in the headset. Adjust the oscillator-amplifier low impedance output selector (fig. 20) by connecting successively to terminals 4, 8, 12, and 16 until a suitable level of keyed tone is noted (see a(4) above).

(4) Adjustment of the keyed tone output level from the Lon-Ga-Tone automatic keyers is accomplished individually on each

keyer. Utilizing the output terminals, adequate variation in output level for all major changes in load is accomplished on the control marked VOLUME.

c. Using keyer TG-10-B.—Same as for Lon-Ga-Tone, type 7.

d. Using automatic keyer, McElroy model G-813, modified.—This unit is employed in the same manner as the Lon-Ga-Tone. However, it contains no volume control of its own, and its full output is used at all times. This will cause no discomfort in the ears of students, as the actual output is very much lower than that of the Lon-Ga-Tone keyer or that of the ACA oscillator-amplifier when the latter is keyed by the G-813 keyer alone.

36. Initiating complete operation.—*a. Automatic keyers* (see fig. 9).—(1) Check to see that adjustments on all units have been made as previously indicated.

(2) Turn on all tape puller motors about 15 or 20 minutes prior to the hour at which instruction is to be initiated. A practice tape should be mounted on each Lon-Ga-Tone automatic keyer in order that a load be maintained on the take-up motor.

(3) Patch desired circuits on switchboards BD-57-A.

(4) About 5 minutes prior to the hour instruction is to be initiated, adjust the speed of each tape puller so that 12 feet of tape per minute pass the aperture, that is, the speed of the tape is 12 feet per minute. This is the tape speed which must be maintained in order to transmit the actual characters from all practice tapes at a speed of 20 words per minute. Tape speeds can be checked by counting the number of characters transmitted per minute and comparing the count with data as to the words-per-minute speed which are furnished with these tapes (see par. 10). A more accurate speed determination may be made by a speed measurement with a tachometer equipped with a calibrated wheel. If the latter instrument is not available a map measurer and a stop watch may be substituted.

(5) About 2 minutes prior to the hour instruction is to be initiated, shut off the tape puller motors and rewind all practice tapes used during the warm-up period. Remove the tape from all guides and from the puller wheel during this operation. Also remove the spring belt from the take-up spindle on the McElroy tape pullers.

(6) Mount the desired practice tape on each automatic keyer. Turn on the oscillator-amplifier and all keyers. Check the tape speed.

(7) After instruction is initiated, check tape speed at 5-minute intervals for the first 15 minutes and hourly thereafter.

(8) Each reel of practice tape is designed for about 1 hour of

transmission. When transmission from each tape is completed, rewind tapes as indicated in (3) above, and repeat operations (6) and (7).

b. *Transmission test table* (see fig. 10).—(1) Check that the adjustments on all units have been made as previously indicated.

(2) Turn on tape puller motors about 20 minutes prior to the hour at which recording is to be initiated. About 5 minutes prior to the hour at which recording is to take place, adjust the speed of the tape pullers as indicated in a(4) above.

(3) Turn on the line switches on the recorder and on the McElroy automatic keying unit. Shut off the tape pullers. Mount a blank tape and thread it through the recorder and onto the tape puller.

(4) To record a student's practice transmission, start the take puller and allow about 4 feet of tape to feed through the puller. This portion of the tape is used as a leader for subsequent play-back. The student's name and other pertinent data are written in pencil thereon. Throw the change-over switch on the recorder to its up position. If the Lon-Ga-Tone keyer is used, throw the KEY-TAPE switch to KEY. The student now operates the key J-38 and his transmission is recorded on the tape.

(5) While the student is still transmitting, the tape leader can be mounted in the automatic keyer without the use of any feed or take-up reels so that when his transmission is completed play-back may be initiated immediately. However, be sure first that the ink is thoroughly dry.

(6) Upon completion of a student's transmission, stop the tape puller, throw the recorder change-over switch to its off position, and cut the tape to the left of the tape puller. Start the tape puller on the automatic keyer and play back to the student his prepared tape.

(7) To prepare copies of the master tapes, mount the tape to be copied on the automatic keyer. Adjust the automatic keyer to a tape speed of 12 feet per minute. If the Long-Ga-Tone automatic keyer is used, throw the KEY-TAPE switch to TAPE. Start the recorder tape puller and allow about 4 feet of tape to feed through the puller. Throw the recorder change-over switch to its up position. The recorder will record the keyed tone received from the automatic keyer.

SECTION IV

FUNCTIONING OF CIRCUITS; MAINTENANCE AND REPAIR

	Paragraph
General	37
Automatic keyer, Lon-Ga-Tone, type 7	38
Keyer TG-10-B	39
Oscillator-amplifier ACA-10-AO	40
Automatic keyer, McElroy model G-813	41
Automatic keyer, McElroy model G-813 modified	42
Recorder, McElroy model RRD-900 or R-900	43
Tape puller, McElroy model CTP-1300	44
Switchboard BD-57	45
Switchboard BD-57-A	46
Record player, Columbia model P	47

37. General.—The electrical circuits of the units of code practice equipment described in this manual are rather simple, and most of the individual parts are operated well below their rated maximums. Because of the number of moving parts, maintenance is more of a mechanical than an electrical problem. If the various chassis are kept clean, and the bearing surfaces of the rotating elements well-lubricated, the equipment will give long, trouble-free service. Any necessary repairs can be accomplished by a competent radio repairman.

38. Automatic keyer, Lon-Ga-Tone, type 7.—The circuit diagram is shown in figure 29, and the accompanying caption includes a detailed list of parts. The latter are standard radio replacement parts. The outside and inside appearance of the unit is shown in figures 30, 31, and 32. In these illustrations, the parts are numbered to correspond with the markings in the schematic diagram, figure 29.

V1..... Type 923 gas photoelectric cell.	R17..... 5,000-ohm resistor.
V2, V3.... Type 6SJ7 tube.	R18, R19.... 1,000-ohm resistor.
V4, V5.... Type 6N7 tube.	R20.... 1,000-ohm potentiometer.
V6, V7.... Type 6V6 tube.	R21.... 300-ohm potentiometer.
V8..... Type 5Y4G tube.	C1..... Triple 8- μ f capacitor.
R1..... 50-megohm resistor.	C2..... 0.00025- μ f capacitor.
R2..... 500,000-ohm resistor.	C3..... 0.01- μ f capacitor.
R3..... 2-megohm resistor.	C4..... 0.1- μ f capacitor.
R4..... 60,000-ohm resistor.	C5..... 0.2- μ f capacitor.
R5..... 750-ohm resistor.	C6, C7.... 0.1- μ f capacitor.
R6, R7.... 50,000-ohm resistor.	S1, S2.... D. P. S. T. switch.
R8..... 25,000-ohm potentiometer.	S3.... S. P. D. T. switch.
R9..... 400-ohm resistor.	T1..... Power transformer.
R10, R11.... 50,000-ohm resistor.	T2..... Output transformer.
R12..... 100,000-ohm resistor.	L1..... 20-henry filter choke.
R13..... 5,000-ohm resistor.	L2..... 200-mh choke.
R14..... 100,000-ohm resistor.	Exciter lamp, double filament auto headlight bulb.
R15..... 200-ohm resistor.	Pilot light, 6.3 volts.
R16..... 1,500-ohm resistor.	




FIGURE 29.—Circuit diagram of Lon-Ga-Tone automatic keyer, type 7.




FIGURE 30.—Front panel view of Lon-Ga-Tone automatic keyer unit.

a. Functioning of circuit.—Tube V4 is a double triode functioning as the tone oscillator. The frequency of oscillation is determined by the constants of inductor L2 and capacitor C5, which are connected to the grid-cathode circuit of the right-hand section of V4. The plate of the right-hand section of V4 is connected to the grid of the left-hand section through capacitor C2 and resistor R3; the plate of the latter triode section is in turn connected back to the grid circuit of the right-hand section of V4 through the capacitor V4. Thus, in-phase feed




FIGURE 31.—Rear chassis view of Lon-Ga-Tone unit.

back of energy takes place from the left-hand section of the tube to the right-hand section, and oscillation in the L2-C5 circuit is maintained. The output of L2-C5, which is about 800 cycles, is amplified by a two-stage audio-frequency amplifier consisting of the upper half of the double triode V5 and the push-pull output stage using the tubes V6 and V7. The lower triode section of V5 acts as a phase inverter to produce the necessary 180° phase difference between the signals appearing on the grids of V6 and V7, through capacitors C6 and C7, respectively. Tubes V2 and V3 constitute a two-stage direct-coupled amplifier. The voltages applied to the elements of these tubes, and the bias on the photoelectric cell V1, are so adjusted that when no light is

shining into the photoelectric cell the effect of the direct connection of V3 to the left-hand grid of oscillator tube V4 is to block the latter tube completely, thus preventing the oscillator from functioning. This




FIGURE 32.—Under view of chassis of Lon-Ga-Tone keyer.

condition exists when a practice tape is properly adjusted so that the bottom black line of the recorded transmission covers the photoelectric cell aperture, as illustrated in figure 24. When the tape is drawn through and light hits the photoelectric cell through an unlinked section of tape, the photoelectric cell generates current and the previous

bias conditions are upset to the extent that the left-hand grid of V4 is no longer blocked. Therefore the tone oscillator functions, and a signal is heard in the connected output circuit. This form of electronic keying is very smooth and positive. Manual keying is accomplished by short-circuiting the control grid of V3 to ground. The power supply is entirely conventional, and comprises the transformer T1, the full-wave rectifier V8, the filter L1-C1, and the bleeder resistor network R16 to R20. The speed of the take-up motor is controlled by the potentiometer R21.

b. Maintenance and repair.—Clean the aperture in the sliding barrel in the photoelectric cell house thoroughly at least once a day. Dust collecting therein will materially interfere with proper keying. Wipe off the exciter lamp, its reflecting lens, and the exposed surfaces of the concentrating lens daily. About once a week remove the cover of the lamp house and clean the inner surfaces of the concentrating lens and the mirror. About once a week remove the photoelectric cell house by unscrewing the two screws which hold it to the chassis, and clean the envelope of the photoelectric cell which is exposed thereby. Once a week put 1 drop of light oil in oil ducts of the take-up motor and in the oil hole at the left end of the puller motor. If the exciter lamp burns out, replace with a 6-volt 32-32-candlepower No. 1000 automobile headlight bulb. To replace a burned out pilot lamp, remove the chassis from its cabinet, unscrew the pilot lamp from its socket and replace with a 6.3-volt 0.25-ampere miniature base lamp. Replace burned out vacuum tubes with the types indicated for each socket in figure 31. If copies of master practice tapes should tear, always make the necessary splice through a section of the *bottom* of the inked line, using glue, rubber cement, cellulose cement, etc. If the splice is made through a clear section, the double thickness of tape will be opaque enough to prevent light from shining through to the phototube.

39. Keyer TG-10-B.—The circuit diagram of this unit appears as figure 33. A back view of the chassis, with the parts marked to correspond with the wiring diagram, follows as figure 34.




FIGURE 33.—Diagram of keyer TG-10-B.

V1	Type 923 gas photoelectric cell.....	
V2, V3	Type 6SJ7.....	
V4, V5	Type 6N7.....	
V6, V7	Type 6L6.....	
V8	Type 5U4G.....	
R1, R2	20-megohm, $\frac{1}{2}$ -w resistor.....	27350
R3	4.7-ohm, 1-w resistor.....	27358
R4	1,000-ohm potentiometer.....	27310
R5	270,000-ohm, $\frac{1}{2}$ -w resistor.....	27351
R6, R7	4,700-ohm, 2-w resistor.....	27357
R8	68,000-ohm, $\frac{1}{2}$ -w resistor.....	27352
R9	390,000-ohm, $\frac{1}{2}$ -w resistor.....	27353
R10	470-ohm, 1-w resistor.....	27359
R11	10,000-ohm, 10-w resistor.....	27363
R12, R13	27,000-ohm, $\frac{1}{2}$ -w resistor.....	27364
R14, R15		
R16	500,000-ohm potentiometer.....	27311
R17	1,500-ohm, 1-w resistor.....	27360
R18, R19	100,000-ohm, 1-w resistor.....	27356
R20	270,000-ohm, $\frac{1}{2}$ -w resistor.....	27351
R21	250-ohm, $\frac{1}{2}$ -w resistor.....	27355
R22	9,100-ohm, $\frac{1}{2}$ -w resistor.....	27355
R23	270,000-ohm, $\frac{1}{2}$ -w resistor.....	27351
R24	100-ohm, 10-w resistor.....	27362
R25	200-ohm, 10-w resistor.....	27364
R26	4,000-ohm, 10-w resistor.....	27365
C1, C2	10- μ f capacitor block.....	27304
C3, C4		
C5	0.1- μ f capacitor.....	27303
C6	0.0005- μ f capacitor.....	27300
C7	0.01- μ f capacitor.....	27301
C8, C9	0.01- μ f capacitor.....	27302
C10	0.1- μ f capacitor.....	27303
T1	Power transformer.....	27117
T2	Exciter lamp filament transformer.....	27116
T3	Output transformer.....	27291
EL	Exciter lamp.....	27234
L1	Filter choke.....	27234

a. *Functioning of circuit.*—The circuit of the keyer TG-10-B is virtually the same as that of the Lon-Ga-Tone, type 7, and functions in the same manner. The only important difference is that the exciter lamp in the TG-10-B works off a separate filament lighting transformer. Also, the output tubes are of the 6L6 type, whereas the Lon-Ga-Tone uses the 6V6 type.

b. *Maintenance and repair.*—(1) *Lubrication.*—The worm reduction gear on the motor shaft runs in an oil bath and requires no additional lubrication. Since the speed of the other shafts is very low, they need little attention. A graphite grease is recommended for these bearings and also for the sliding bearings on the speed adjustment mechanism.

(2) *Rollers.*—To replace the rubber portion of the puller roller, remove the acorn nut on the front of the roller and take off the outer washer. Remove the old roller, slide on the new one, and replace the washer and the nut. To replace the drive roller, remove the old one by taking the spring belt from its driving puller and releasing the set

screw holding it to the puller shaft. The entire shaft can now be pulled forward. Roll off the old Neoprene ring and roll on the new one. In reassembling, be careful to set up the pulley to prevent excess end play of the puller shaft. The friction surface driving the take-up reel is identical with that used to drive the puller shaft. It can be rolled off its wheel and a new one rolled into place without otherwise disturbing the mechanism.




FIGURE 34.—Chassis view of keyer TG-10-B with parts marked to correspond with figure 33.

(3) *Exciter lamp*.—This is a standard six-volt double-filament 32-32 candlepower No. 1000 automobile headlight bulb. When one filament burns out, turn the bulb halfway around in its socket and use the other filament.

(4) *Fuse*.—The keyer is shipped with a fuse in place. This is a standard 3AG automotive fuse, rated at 3 amperes at 250 volts.

(5) *Transformers.*—The power and audio units used in the TG-10-B can be replaced by standard radio replacement parts as follows:

		<i>Thordarson</i>
Power transformer-----	T13R15.	
Output transformer-----	T17S11.	
Filament transformer-----	T19F98.	
Oscillator coil-----	T18C92 (less core).	
Filter choke-----	T57C52.	

(6) *Voltage readings.*—The following table gives the normal voltage readings between the socket terminal numbers indicated, as measured with a 20,000-ohm-per-volt meter when the line voltage is approximately 115 volts:

Tube	Plate		Filament		Cathode		Screen		Switch position	
	Pins	Volts	Pins	Volts	Pins	Volts	Pins	Volts	Tape	Key
1-----	4-GD	87							x	x
2-----	8-5	26	2-7	4.9	5-GD	14			x	
	8-5	0								x
3-----	8-5	65	2-7	6.2	5-GD	70			x	
	8-5	19								x
4-----	8-3	66	2-7	6.2	8-1	140			x	
	8-3	132								x
	8-6	62							x	
	8-6	58								x
5-----	8-3	145	2-7	6.2	8-1	3.5			x	
	8-3	160								x
	8-6	150							x	
	8-6	162								x
6-----	8-3	370	2-7	6.2	8-1	20	8-4	240	x	x
7-----	8-3	370	2-7	6.2	8-1	20	8-4	240	x	x
8-----	Plate to Plate	760AC	2-8	5.0					x	x

40. *Oscillator-amplifier ACA-10-AO.*—a. *Functioning of circuit.*—Electrically, this unit closely resembles the oscillator-amplifier section of the Lon-Ga-Tone automatic keyer. As shown in figure 35, V1 is the oscillator. Tubes V2, V3, and V4 comprise a two-stage amplifier, with one section of V2 functioning as a phase inverter. No provision is made for internal keying. In installations in which this




FIGURE 35.—Circuit of ACA amplifier-oscillator.

V1, V2	Type 6N7 tube.	R7	1/2-megohm potentiometer.
V3, V4	Type 6L6G tube.	R8	3,000-ohm, 1/2-w resistor.
V5	Type 5U4G tube.	R9, R10	50,000-ohm, 1/2-w resistor.
C1, C2	0.1- μ f, 400-v capacitor.	R11	100,000-ohm, 1/2-w resistor.
C3	10-10-10- μ f, 250-v capacitor.	R12	6,000-ohm, 1/2-w resistor.
C4	0.1- μ f, 400-v capacitor.	R13	100,000-ohm, 1/2-w resistor.
C5	0.01- μ f, 400-v capacitor.	R14	50,000-ohm, 1/2-w resistor.
C6	0.001- μ f, 400-v capacitor.	R15	250-ohm, 10-w resistor.
C7	10-10-10- μ f, 400-v capacitor.	R16	1/2-megohm, 1/2-w resistor.
C8, C9	0.1- μ f, 400-v capacitor.	R17	5,000-ohm, 10-w resistor.
C10	0.0005- μ f, 400-v capacitor.	R18	25,000-ohm, 20-w resistor.
C11	10-10-10- μ f, 450-v capacitor.	SW-S. P. S. T.	On-off switch.
C12	10-10-10- μ f, 450-v capacitor.	FP	3 ampere, 250-volt fuse.
C13, C14, C15	10-10- μ f, 450-v capacitor.	T1	Power transformer, manufacturer's type No. L6PT34AO.
R1	50,000-ohm, 1/2-w resistor.	T2	Output transformer, manufacturer's type No. L60T34AO.
R2	1,000-ohm, 1/2-w resistor.	PL	6.3-v, 1/4-ampere pilot light, miniature screw base.
R3	1/2-megohm, 1/2-w resistor.	RFC 10	Oscillator inductor.
R4	6,000 plus 1,000 (7,000)-ohm, 1/2-w resistor.		
R5, R6	50,000-ohm, 1/2-w resistor.		

oscillator-amplifier is used, keying is performed automatically by a separate McElroy keyer, model G-813, or manually by students.

b. Maintenance and repair.—If excessive hum is present in the output circuit, it indicates an unbalance in the output tubes V3 and V4. One or both tubes should be replaced. When the set is turned on, if the pilot lamp does not light, examine the red screw fuse located on the rear of the chassis. Replace with standard 3-ampere fuse if burned out. If not, unscrew the ruby reflector and replace the pilot lamp with




FIGURE 36.—Front view of ACA oscillator-amplifier, with protective screen cover removed to show placement of parts.

a 6.3-volt, 0.25-ampere miniature base lamp. If the oscillations stop, examine the tubes for burned out filaments. Replace tube, if necessary, with the type tube indicated on the socket. A general front view of the oscillator-amplifier chassis is shown in figure 36 and an under view of the chassis in figure 37.

c. Resistance and voltage chart.—The following resistance and voltage chart will be of assistance to the radio repairman in tracing troubles that develop in the ACA oscillator-amplifier:

RESISTANCE AND VOLTAGE CHART

Measure direct voltage with 1,000 ohms per volt meter.

Measure alternating voltage with 1,000 ohms per volt meter.

Measure resistance with 0-50,000 and 0-5 megohm ohmmeter ranges (tubes removed).

DIRECT VOLTAGE (measured from ground)*

Tube No.	Tube type	Prong terminals							
		1	2	3	4	5	6	7	8
V1-----	6N7	0		³ 190			³ 180		⁴ 4
V2-----	6N7	0		³ 160			³ 160		⁴ 4
V3-----	6L6G	0		² 420	² 300				⁴ 23.5
V4-----	6L6G	0		² 420	² 300				⁴ 23.5
V5-----	5U4G	0	² 420		¹ 360		¹ 360		² 420

*Measured with all controls set at zero.

RESISTANCE (measured from ground)**

Tube No.	Tube type	Prong terminals							
		1	2	3	4	5	6	7	8
V1-----	6N7	0	0	⁶ 80M	⁵ 7M	⁵ 350	⁶ 80M	0	⁵ 1M
V2-----	6N7	0	0	⁶ 150M	⁵ 6M	⁶ 500M	⁶ 150M	0	⁵ 3M
V3-----	6L6G	0	0	⁶ 30M	⁶ 25M	⁶ 106M		0	⁵ 250
V4-----	6L6G	0	0	⁶ 30M	⁶ 25M	⁶ 100M		0	⁵ 250
V5-----	5U4G	0	⁶ 30M		⁵ 70		⁵ 75		⁶ 30M

**Measured with all controls on full.

NOTE.— ± 10 per cent tolerances in all readings are permissible.

¹ 750-volt a-c scale.

⁴ 30-volt d-c scale.

² 750-volt d-c scale.

⁵ 0-50,000-ohm scale.

³ 300-volt d-c scale.

⁶ 0-5-megohm scale.




FIGURE 37.—Under view of chassis of the ACA oscillator-amplifier.




FIGURE 88.—Schematic wiring diagram of McElroy automatic keyer, model G-813.

TL-3380

V1-----	Type 117N7GT tube.
V2, V3-----	Type 117Z6GT tube.
R1-----	40-megohm, 1-w resistor.
R2-----	35,000-ohm, $\frac{1}{2}$ -w resistor.
R3-----	0.1-megohm potentiometer.
R4-----	35,000-ohm, $\frac{1}{2}$ -w resistor.
R5-----	20,000-ohm, $\frac{1}{2}$ -w resistor.
C1, C2-----	10- μ f, 200-v capacitor.
C3, C4-----	10- μ f, 200-v capacitor.
C5-----	20- μ f, 200-v capacitor.
C6-----	0.05- μ f, 200-v capacitor.
PEC-----	Type 923 gas photoelectric cell.
RL-----	Relay, Sigma No. 3A.
EL-----	Exciter lamp, 15-watt, 120-volt, intermediate base.
SW-----	Line switch.

41. Automatic keyer, McElroy model G-813.—a. Functioning of circuit.—The electrical circuit of this keyer is shown in figure 38. Although the unit actually employs only three tubes, these are of the multielement type, and the individual sections are separated in the diagram for the sake of clarity. V1, a type 117N7GT, which consists of a tetrode and a diode in the same envelope, is split up as V1a for the tetrode and V1b for the diode. Note especially that the plate of V1b is internally connected to one side of the heater. V2 and V3 are 117Z6GT full-wave rectifiers. The sections of V2 are used separately (as indicated by V2a and V2b, while the sections of V3 are paralleled to form a single half-wave rectifier element. The tetrode V1a acts as a single high-gain amplifier stage for the photoelectric cell PEC, and operates the relay connected in its plate circuit. Plate and screen voltages for V1a, and also heater current for the entire tube V1, are furnished by V2 and V3 in a conventional "transformerless" voltage-doubling circuit. Closing the switch SW actuates the entire keying unit.

b. Maintenance and repair.—Clean the aperture in the aperture bar thoroughly at least once a day. Dust collecting therein will materially interfere with proper keying. The photoelectric cell, particularly that portion directly under the aperture bar, must also be free from dust. Whenever needed, clean the contacts of the relay by drawing a strip of bond paper, previously dipped in carbon tetrachloride, through the space between contacts. Adjustment of this relay should be accomplished only by an experienced instrument repairman. About once a week place 1 drop of light oil (typewriter or sewing machine oil) in the oil hole located at the top of the rewind. If the exciter lamp burns out replace with a 120-volt 15-watt clear glass, intermediate screw-in base lamp. The photoelectric cell should remain serviceable for very extended periods. The units must be removed from service to effect replacement of this tube. If copies of tapes should tear, always make the necessary splice at a section of the




FIGURE 39.—Schematic diagram of McElroy automatic keyer, model G-813, modified.

V1-----	Type 117N7GT tube.	C3-----	40- μ f, 200-v capacitor.
V2, V3-----	Type 117Z6GT tube.	C4-----	10- μ f, 200-v capacitor.
V4-----	Type 1A7GT tube.	C5-----	20- μ f, 200-v capacitor.
PEC-----	Type 923 photoelectric cell.	C6-----	0.05- μ f, 200-v capacitor.
R1-----	40-megohm, 1-w resistor.	C7-----	20- μ f, 200-v capacitor.
R2-----	35,000-ohm, $\frac{1}{2}$ -w resistor.	C8-----	50- μ f, 25-v capacitor.
R3-----	0.1-megohm potentiometer.	C9-----	0.01- μ f, 200-v capacitor.
R4-----	35,000-ohm, $\frac{1}{2}$ -w resistor.	C10-----	0.02- μ f, 200-v capacitor.
R5-----	20,000-ohm, $\frac{1}{2}$ -w resistor.	C11-----	0.1- μ f, 200-v capacitor.
R6-----	30-ohm, $\frac{1}{2}$ -w resistor.	RL-----	Relay, guardian No. 27298.
R7, R8-----	5,000-ohm, $\frac{1}{2}$ -w resistor.	XX-----	External keying contacts.
R9-----	7,000-ohm, $\frac{1}{2}$ -w resistor.	T1-----	Output transformer.
R10-----	0.1-megohm potentiometer.	J-----	Single open circuit jack.
C1, C2-----	10- μ f, 200-v capacitor.	SW-----	Line switch.
		EL-----	Exciter lamp, 15-watt, 110-volt intermediate base.

A general view of this keyer, with its associated tape puller, appears as figure 40.

top inked line. If a small clear space remains after the splice has been made, make the line continuous by using black ink or even a soft lead pencil.

42. Automatic keyer, McElroy model G-813, modified.—a.
Functioning of circuit.—This unit differs from the model G-813 described in paragraph 41 in that it includes a tone source which is keyed by the automatic keyer. The complete circuit is shown in figure 39. Tube V1 is a 117N7GT, and V2 and V3 are both type 117Z6GT. These are split up into their constituent elements as V1a, V1b, V2a, V2b, and V3, and function exactly as indicated for the model G-813 in paragraph 41. The 1A7GT operates somewhat in the manner of a dynatron oscillator, the frequency of oscillation being controlled by the variable resistor R10. The filament of this tube, which is intended normally for battery operation, is energized by direct current produced by the rectifier system of the unit. This filament is shown separately as V4h and is connected in series with the heater of V1. Because V1 takes 75 milliamperes and V4h takes 50 milliamperes, V4h is shunted by a small resistor R6 to equalize the current distribution in the circuit.

b. Maintenance and repair.—The same data given for the model G-813 should be observed for the G-813, modified. However, the relay used in the latter unit does not require adjustment. Also, it is advisable to provide spare oscillator tubes, as the filament life may be expected to be shorter than usual.




FIGURE 40.—McElroy automatic keyer, model G-813 modified, with associated tape puller. (Exciter lamp is shown in raised position.)

TL-4007

43. Recorder, McElroy model RRD-900 or R-900.—*a. Functioning of circuit.*—Figure 41 shows the complete schematic diagram of the instrument. The tetrode sections of the type 117N7GT tubes, marked V1a and V2a, are connected to form a conventional push-pull amplifier stage. Plate voltage is furnished by a voltage-doubler system similar to that employed in the McElroy automatic keyers. The diode sections of the type 117N7GT tubes, marked V1b and V2b, are part of this power circuit. V3a and V3b are the two diode sections of the type 117Z6GT tube.

The keyed tone signal to be recorded is led into the amplifier at the input posts. The amplified output of T2 is rectified by a full-wave, dry-disk rectifier, and the pulsating direct current from the latter actuates the moving coil element. The latter corresponds to the voice coil of a loudspeaker. To it is attached the ink-bearing stylus, which moves down and across the paper tape in accordance with the keying and the constant pull of the take-up motor.

b. Maintenance and repair.—Practically the only routine maintenance on this unit consists in maintaining a smooth, even flow of ink to the recording stylus. A cleaner wire for the stylus and inkwell outlet accompanies each unit as does a replacement ink hose. The stylus should be left solidly against the tape when the recorder is not in use, and the inkwell should be set in its lowest position. After inoperative periods of an hour or longer, the stylus may require cleaning as indicated in paragraph 32. Once a week, the inkwell and ink hose should be removed from the unit and thoroughly cleaned with water. Infrequently, an overnight soaking of the hose is desirable. A gentle milking action will force water through the hose. Frequent dusting of this unit is necessary, as the blank tape in feeding through it leaves an accumulation of paper lint. Two views of the recorder are shown in figures 42 and 43.




FIGURE 41.—Schematic diagram of McElroy recorder, model RRD-900 or R-900.






FIGURE 42.—Close-up end view of McElroy recorder. (Once various adjustments have been made, unit will operate for long periods without requiring attention.)



TL-4010

FIGURE 43.—Underview of chassis of recorder. (Parts are marked to correspond with schematic diagram, fig. 41.)



44. Tape puller, McElroy model CTP-1300.—*a. Functioning of circuit.*—The connections of the tape puller are very simple and are given in figure 44.




FIGURE 44.—Wiring of McElroy tape puller.

Not all models of this tape puller have the speed control switch SW2. In units in which it is not used, the circuit is equivalent to one with the switch closed. The motor operates as a hybrid shunt type with the armature excitation depending on the voltage drop between the arm of the potentiometer and the junction point of the armature and the field. When switch SW2 is open (corresponding to the forward position mentioned in paragraph 28b(2)) the motor operates as a conventional series type, and R1 acts merely as a series rheostat.

b. Maintenance and repair.—Once a day place 1 drop of light machine oil in the oil hole on the take-up spindle and in the oil duct leading to the puller wheel bearing. The entrance to the latter duct is located on top of the unit directly above the puller wheel.

45. Switchboard BD-57.—*a. Functioning of circuit.*—The circuit diagram of the switchboard BD-57, which is part of code practice equipment EE-81, appears as figure 45. A front view of the board with the cords exposed is given as figure 46.

The motor alternator mounted in the switchboard is not used in modern installations of code practice equipment. If the board is employed as issued, the master key terminals are short-circuited, and keyed or steady tone from an external source is fed to the terminals marked **AUXILIARY**. When the auxiliary plug (red cord) is inserted in the jack marked **AUXILIARY**, this tone signal goes through the primaries of the twenty-one individual transformers, which are connected in series. The secondary of each transformer is isolated by means of a plug. Tracing out the circuit at any trans-




FIGURE 45.—Complete circuit diagram of switchboard BD-57.

former, it will be seen that secondary terminal 4 is connected to the *tip only* of the plug. Therefore, it is necessary to insert the plug into the corresponding "student" jack directly above it, in order




FIGURE 46.—Switchboard BD-57 set up for operation with cords exposed.

for the tone signal to appear in the earphones of the connected student position. If the tone is keyed, the student keeps his key closed. If the tone is steady, the student can open his key and practice sending to himself. The instructor can listen in by plugging the "instructor" plug (white cord) into any of the "supervisory"

jacks along the top of the board, at the same time closing the switch on his key. Each of these jacks is in series with the "student" jack under it. When steady tone is supplied, simulated nets can be set up for groups of students by interchanging their black cords, exactly in the manner described for the BD-57-A. With any type of operation, the potentiometer continues to act as a volume control on the input signals.

b. Maintenance and repair.—Very little trouble develops with this board, as the parts are rugged and are subjected to very little strain, either mechanical or electrical. Cords and plugs may wear out after long service but are readily repaired or replaced. The main items to watch are the transformers. Because of their series connection, the entire board will go dead if only one primary becomes open. The faulty unit can be identified quickly with the aid of an ohmmeter or a simple continuity tester consisting of a headset in series with a dry cell and a pair of test prods.

46. Switchboard BD-57-A.—*a. Functioning of circuit.*—The complete schematic diagram of this board is shown as figure 47. Comparison of this diagram with figure 46 reveals several important improvements. There are three rows of jacks instead of two, permitting much greater flexibility of student circuit arrangement. The transformer primaries are still in series, but they are connected only to steady tone (through the AUX SWBD TONE posts) for purposes of hand keying by students and simulated net operation. This tone is available at all student positions when the plugs are *not* in any of the jacks. Tracing through the circuit of any transformer and its associated jacks, it will be seen that the secondary terminal 3 goes to one side of the student position through the tip and inner contacts of the bottom jack, which are closed when the jack is idle. Terminal 4 goes back to the other side of the student position through the two upper jacks in series. Note particularly that the frames of the bottom and middle jacks are not connected at all. One student can be fed keyed signals of any desired speed if his black cord is inserted in his middle jack, and if the auxiliary cord connected to the proper keyer is inserted in the top jack. The resultant circuit is a simple series one, with the transformer entirely out of action. Students can be connected in series for keyed signals by cross-connecting plugs in the middle jacks, just as they can be cross-connected for local net operation by means of the plugs and the lower jacks.

b. Maintenance and repair.—See paragraph 45*b*.




FIGURE 47.—Circuit diagram of switchboard BD-57-A.

47. Record player, Columbia model P.—*a. Functioning of circuit.*—This record player is a very simple unit, consisting merely of a turntable, a crystal pickup, a one-tube amplifier, and a 6-inch permanent magnet loudspeaker. The circuit is shown in figure 48.




FIGURE 48.—Circuit diagram of record player, Columbia model P.

The 70L7GT tube is a combination diode-tetrode, the diode section functioning as a half-wave rectifier to furnish plate and screen voltage for the tetrode amplifier.

b. Maintenance and repair.—The simplicity of this unit makes it practically foolproof. About the only part likely to require replacement is the tube. This is mounted on a small subpanel under the turntable deck. Access to it is had by removing the Phillips head screws that hold the latter in position. The motor is of the self-starting type. It requires no lubrication.

APPENDIX I


CHANGES IN SWITCHBOARDS BD-57 AND BD-57-A

1. **Improving switchboard BD-57.**—As mentioned in paragraph 17b, the switchboard BD-57, as issued, does not meet the requirements of modern installations of code practice equipment. However, if training or other funds are available for the purchase of 20 inexpensive single closed circuit telephone jacks, the board can be made the equivalent of the newer BD-57-A by a competent radio repairman. The extra jacks are added in a row under the present row marked STUDENT JACKS, and the wiring is changed to conform to that of the switchboard BD-57-A, as given in figure 47. To allow the connection of more than one keyer, the single red AUXILIARY cord can be supplemented by extra cords fitted with two-connection plugs. If regular patching cords are not available, standard radio plugs and ordinary flexible lamp cord will be found perfectly satisfactory. Extra terminals should be provided on the back of the board for these cords to facilitate connection to the automatic keyers. An alternative arrangement is the use of a separate patching board, described in the following paragraph.

2. **Patching board for switchboard BD-57-A.**—Code practice equipment set up as indicated in figures 5 and 9 will operate quite satisfactorily. However, the use of an extra patching board, containing volume controls for each keying circuit, has been found very convenient. As shown in figure 49, the outputs from the various keyers terminate across the ends of 1,000-ohm potentiometers, instead of at the auxiliary tone cords of the switchboard itself. A single open circuit jack is connected across the arm and one end of each potentiometer. Patching cords, consisting of short lengths of flexible wire with a two-connector phone plug at each end, provide a quick means of transferring the tone signals at any particular keyer jack to any student position. The potentiometers serve a double purpose:

- a. They allow the signal volume in the students headsets to be adjusted to a comfortable level, or to a low level to simulate poor receiving conditions.
- b. With the entire resistance connected permanently to the keyer output circuits, a constant load is maintained on the keyers, and the

signals in one switchboard circuit will not change noticeably if changes are made in another switchboard to which the same signals are being piped. With this set-up, the six auxiliary tone cords on the BD-57-A



are not required; in fact, if these cords are removed and the remaining free ends fitted with phone plugs, they make excellent patching cords. Another arrangement is the direct connection of the auxiliary cords to the arm and one end of each potentiometer. While this set-up is

not quite as flexible as the use of full patching cords, it is adequate for small installations where the number of available keyers is limited. The number of jacks and potentiometers to be provided on the patching board will depend on the size of the school. Figure 50 shows a




FIGURE 50.—Switchboard BD-57-A with patching board on top.

20-position board mounted on top of a BD-57-A in a large school. This provides outlets for all 15 of the master tapes supplied for the automatic keyers, the fixed tone source for local keying, and for signals from several radio receivers. An average of 12 positions is sufficient for most schools. It will be seen from figure 50 that the patching board has been made to match the switchboard in width and depth and general appearance. The front panel may be bakelite, hard rubber,

any of the "pressed wood" boards, or even plywood, as insulation is not particularly a problem. The box is made from scrap shelving. This illustration also shows how the cabled leads are brought into the boards. A hook for the patching cords is provided on the right end of the mounting bracket.

3. Monitoring board.—Another convenience in a school using a large number of automatic keyers is a monitoring board. As shown in figure 51, this consists simply of several rows of single open circuit jacks. Each jack is connected to the output terminals of a keyer, paralleling the leads that go to the switchboard or the patching board. The monitoring operator is thus able to check the output of all the keyers from one position in a very short time. Directly above the monitoring board shown in figure 52 are two small permanent magnet loudspeakers, mounted in the wall. These have cords and plugs attached, and either can be left plugged into the jack representing any keyer when the operator wants to make a continuous check on a tape, while he is doing other work around the keyer room. As in the case of the patching board, this monitoring board can use bakelite, hard rubber, pressed wood or plywood for its panel.




FIGURE 51.—Monitoring board used in connection with automatic keyers.

APPENDIX II
MATERIAL CARRIED ON MASTER TAPES

The material carried on the 15 master tapes furnished for the code practice equipment described in this manual is published herewith as an aid to instructors. It should be noted that random errors may occur in the tapes.

Tape No. 1—20 characters per minute

(Receiving lesson I, TM 11-454)

F	F	F	F	F	G	G	G	G	H	H	H	H	M	M	M	M	M
J	J	J	J	R	R	R	R	R	U	U	U	U	F	F	F	F	F
G	G	G	G	H	H	H	H	H	M	M	M	M	J	J	J	J	J
R	R	R	R	R	U	U	U	U	U	F	F	F	F	G	G	G	G
H	H	H	H	M	M	M	M	M	J	J	J	J	R	R	R	R	R
U	U	U	U	F	H	U	R	G	H	M	J	R	U	F	G	M	J
F	G	M	H	M	J	H	R	U	F	J	R	J	G	U	M	F	H
U	F	M	G	H	M	R	H	F	R	R	J	U	G	U	J	H	F
R	M	F	R	U	G	M	H	F	H	G	R	U	J	J	H	U	F
R	R	J	F	M	U	M	H	G	J	J	G	H	F	U	R	F	M
G	J	R	J	F	H	R	G	U	M	H	G	F	U	J	F	H	U
J	H	R	M	G	F	J	H	H	R	U	M	U	H	F	J	R	M
J	M	G	J	R	H	F	U	U	J	R	H	H	M	G	M	F	R
H	R	M	H	G	J	R	F	J	M	U	G	H	U	M	F	G	J
G	H	M	R	U	M	R	J	F	H	M	J	H	G	R	U	J	F
H	M	G	R	M	J	H	R	M	F	R	G	J	H	J	U	F	U
H	M	J	R	H	G	R	H	G	R	F	H	M	J	U	F	U	J
H	M	H	J	H	U	G	R	J	G	R	F	U	J	M	R	F	F
J	G	J	R	U	M	M	H	F	J	H	U	F	R	G	R	F	U
J	R	G	U	J	F	U	M	H	R	J	M	R	F	M	F	H	G
M	F	U	G	U	H	J	M	J	R	J	R	G	F	F	H	M	H
M	H	R	U	F	R	R	U	G	U	F	M	H	J	J	F	G	J
G	F	H	U	J	G	J	M	H	M	G	R	U	H	F	M	F	R
F	G	J	F	M	H	J	G	M	G	H	J	M	F	U	R	H	F
M	G	F	J	H	F	G	J	M	U	R	G	M	H	U	F	H	F
J	M	H	G	F	R	J	U	J	M	G	M	G	J	H	U	F	H
J	H	R	G	H	U	M	F	J	G	M	H	M	J	F	G	U	F
J	G	H	R	U	H	U	J	G	M	F	M	H	M	F	R	J	G
H	G	J	U	R	H	G	J	M	F	H	M	R	F	M	U	F	J
G	F	U	H	G	H	R	J	H	R	M	F	J	M	U	J	F	G
G	F	G	H	U	H	H	R	M	F	J	M	F	R	J	M	G	U
F	F	F	F	G	G	G	G	H	H	H	H	H	M	M	M	M	M
J	J	J	J	R	R	R	R	R	U	U	U	U	F	F	F	F	F
G	G	G	G	G	H	H	H	H	H	M	M	M	M	J	J	J	J
R	R	R	R	R	U	U	U	U	U	F	F	F	F	G	G	G	G
H	H	H	H	H	M	M	M	M	M	J	J	J	J	R	R	R	R

Tape No. 1—Continued

U U U U U F U R R G J J H G H H H J J M
 M G F M J J J H G G G F M R J H M R H M
 M M G R F H F G G M H G G F F M M F J R
 R G M M G J H J G U R H J F H R H J U G
 H G R F J M J H R R R J R U G U U F J G
 G R U H H M H U M F G R G U M H H U J U
 F J M H F H U R G U F J M G U H F H J M
 J G U M F H R G H F R U H H H H H R M
 M R J F R R H R G M U J R J J G J M U G
 R H U R H H H G H U F J R H R H M M U M
 G J U F J J J R R U F F G U H U J F M G
 J F H J G H M M J J G M H M G F R H J M
 R J M H F R G J R R U M G U M M G M F R F
 H J R G J H U R U M R F R H J J F G H R
 G M F H M J M R J R G G M H G J G M F U
 M R M R J G M H M M F M J J U U H F U H
 H H J M U F R G H U M M G M H R J F R G
 G J F U H M U G H J J R F F J H F H J J
 M F M R U U U J U J F G M R J U M G M F
 J F U U H F F M U J F M J H R F J M F U
 U F R R F H F M R F U G R U J M G F H U
 F H R F G J F U F F H M G F H H F U J F
 F G M H F F M U M R J F U J F U G H J R
 F F H F G J G U J R M J H M F F G U F F
 M H H R H J R U F R U G U F H U J M U R
 U U F F U U U M U U M U U R R U F U M U

Tape No. 2—20 characters per minute

(Receiving lesson II, TM 11-454)

B B B B B D D D D D K K K K K N N N N N
 T T T T T V V V V V Y Y Y Y Y Y B B B B B
 D D D D D K K K K K N N N N N T T T T T T
 V V V V V Y Y Y Y Y B B B B B D D D D D
 K K K K K N N N N N T T T T T T V V V V V
 Y Y Y Y Y B F U T V M N H Y N M T G D H
 B Y G F V R D B G Y J T K V H J G V V F
 F K H G Y F M K R B F D V U T F Y T R Y
 J G U M J B G Y N D B Y D Y D N F N V K
 B J H B R D V H Y T K V U N B K G N T K
 D U D M R K M N V D V U T K T B H N D T
 N K R J U K N J T M N Y N T D B V B K T
 K R N B N U V D T R K K T N Y Y J Y D V
 T R U T D Y K G R V V N D D V K F T B Y
 V J V K F N T U B Y D T B B G V D Y B R
 Y M N Y G T N F D K T B B N V U H M K Y
 K H T V F K H D T V D B R K N T D M B J
 B N Y D T G U V K T K J K V D N M D J B

Tape No. 2—Continued

D	U	B	T	H	V	Y	N	R	B	M	T	Y	J	K	U	B	K	N	R
K	Y	F	M	R	K	J	B	D	H	R	V	Y	N	D	B	R	N	T	K
N	J	F	G	U	D	M	V	D	G	J	T	K	U	V	D	V	J	Y	T
T	G	M	H	Y	B	D	K	H	K	T	R	M	N	Y	F	B	B	Y	V
B	K	F	K	U	D	Y	R	N	F	V	U	K	J	B	T	M	D	B	M
V	N	T	D	G	D	B	V	J	G	Y	K	D	N	M	V	J	B	U	H
N	T	V	B	T	H	K	U	K	H	N	D	D	Y	R	H	T	B	D	G
N	V	T	N	K	M	N	J	Y	M	K	T	F	R	D	V	U	G	R	K
J	Y	K	N	K	T	K	V	D	G	J	N	T	M	Y	R	B	J	F	N
T	D	Y	N	V	M	Y	U	H	M	D	B	R	V	U	T	F	B	T	N
B	V	T	Y	H	F	N	M	K	V	J	Y	U	V	G	T	D	V	K	D
T	Y	V	N	B	G	J	Y	B	K	B	H	V	B	U	Y	R	T	Y	D
F	Y	G	T	R	H	D	D	N	K	F	D	B	R	Y	U	N	K	Y	B
B	B	B	B	D	D	D	D	D	K	K	K	K	K	N	N	N	N	N	N
T	T	T	T	V	V	V	V	V	Y	Y	Y	Y	Y	Y	B	B	B	B	B
D	D	D	D	D	K	K	K	K	K	N	N	N	N	N	T	T	T	T	T
V	V	V	V	V	Y	Y	Y	Y	Y	B	B	B	B	B	D	D	D	D	D
K	K	K	K	K	N	N	N	N	N	T	T	T	T	T	V	V	V	V	V
Y	Y	Y	Y	Y	B	F	J	B	D	N	K	T	V	Y	K	B	D	K	N
T	B	V	B	N	J	T	B	T	F	Y	K	G	J	U	K	R	R	J	M
H	N	U	Y	J	G	K	N	T	V	Y	D	V	Y	Y	G	H	U	H	D
R	N	U	V	N	T	Y	B	F	F	M	F	T	V	T	K	Y	T	V	G
F	G	M	B	M	J	B	T	K	Y	V	D	T	M	G	H	K	D	B	N
N	N	Y	N	T	V	Y	J	R	R	U	N	D	F	G	F	T	H	R	U
Y	U	G	T	K	K	V	H	B	R	B	R	F	B	D	K	K	U	Y	N
T	K	G	V	K	D	B	D	D	H	M	T	M	F	G	H	F	D	M	G
V	M	N	V	K	T	N	H	U	Y	J	M	D	Y	B	K	N	K	Y	N
J	D	U	B	K	Y	H	N	J	D	G	U	F	D	V	N	B	V	K	R
V	U	J	V	U	M	Y	D	T	G	R	N	Y	V	T	T	R	B	D	T
K	R	D	D	H	N	J	K	Y	D	H	K	B	N	V	Y	B	D	T	D
M	R	V	Y	K	V	T	B	H	G	K	F	G	H	M	G	M	V	K	K
M	J	F	B	K	V	N	K	V	D	T	D	K	M	R	J	T	V	Y	N
K	J	D	J	B	F	N	T	D	Y	V	U	Y	K	N	T	B	B	J	T
V	T	R	U	K	D	T	N	B	Y	H	D	H	K	V	D	U	T	N	T
D	B	B	R	K	Y	Y	K	M	K	D	D	F	T	R	U	V	B	Y	V
U	Y	N	K	T	N	D	B	N	K	V	J	N	U	N	J	N	Y	R	M
V	V	B	R	N	H	T	D	B	T	D	Y	V	G	V	N	D	K	D	V
Y	B	M	R	D	Y	U	G	U	Y	M	J	F	N	K	B	B	Y	K	V
U	T	N	U	B	D	F	T	V	H	V	R	T	T	Y	U	T	G	Y	F
G	H	V	J	F	D	H	D	M	B	R	V	B	M	J	T	U	B	F	D
R	N	G	V	T	N	N	N	B	Y	T	Y	M	M	D	K	N	J	B	D
B	B	G	J	B	V	T	K	D	V	R	V	T	D	K	D	B	B	K	B
J	N	T	Y	Y	B	U	D	R	F	T	K	Y	Y	H	F	Y	K	K	T
T	V	Y	R	Y	J	B	R	K	T	V	M	H	G	K	N	N	D	D	B

Tape No. 3—20 characters per minute

(Receiving lesson III, TM 11-454)

C C C C C E E E E I I I I I I L L L L L L
 O O O O O S S S S S W W W W W W C C C C C C
 E E E E E I I I I I L L L L L L O O O O O O
 S S S S S S W W W W W W C C C C C C E E E E
 I I I I I I L L L L L O O O O O S S S S S S
 W W W W W W C F L O I B C Y W E C L S O W C
 C E S C I G E W S D E W L V C O L S B E
 I C Y I H S C I U K S O F I E T W S O S D
 V E L M L L Y R N O S C G I L S U K W O
 E O J I S O W V L W L E H L O N W C F L
 S I O R Y N T I B S O M E L G C T S S W
 L W S O U N E D O S J W I R V K E O I S
 O T C J V C K W K R C T E J Y I L B D L
 S M I E W N E D U C E M W E L C O E N T
 H S W T I V D B E I C I C O B I F C I O
 W N V I W L Y L I B E H S L E G D B C S
 C Y T C S K O L D O E W G O S H W I K E
 I E L N O K W S L C I L O F M E S L F W
 W S I O I L O E W B Y C L S J W C E O G
 E N D L E S U S I C O R I L I O E S H M
 T B W I W L W W E C E U V S L O C Y I S W R
 C V K S O E S W C S W I L O C Y I S W R
 C L O K F U I W B V U O N S H W L J O S
 H E W G B D G C T L C K W Y C G S I L G
 O E K H S G O I Y W E S W E W O I O I S
 L I F T S L E F C S D Y I H L S I O E M
 I L N W I C Y E R C I L L I M E L C C L
 O W K M E T J I O N O L E S J I V U M H
 C S J C D B M L K L C O R W F W J C L R
 E R W C W B D O S G I N S T U E R C R W
 U V M I E H S W F K S V E W Y C W J W E
 C C C C E E E E I I I I I I L L L L L L
 O O O O O S S S S S S W W W W W C C C C C
 E E E E E I I I I I I L L L L L O O O O O
 S S S S S S W W W W W C C C C C E E E E
 I I I I I I L L L L L O O O O O S S S S S
 W W W W W W C I V E S L O O S H W C I W E T
 C C H O L I O C E U E C E O I W T M S N
 Y E S N B V L E E I L W S R V S Y L J O
 S C I W V T L I D W K O W K F N K J W M
 C I M I R O J E T I C N O L I S K G H T
 W M C C I I H L S Y U V W I W S O I E W
 O F B S S I E D W E C G S L O N N C N V
 L K K L S L E U D G L C T B B H F E C Y
 W T E K E D Y O W O U W S I G O E Y J M
 D S L W I R V I D W D B L L S E S W W W W
 C I F E I L O W O S U N L B O K U E I D

Tape No. 3—Continued

L	W	I	E	C	B	T	Y	C	R	O	K	S	F	I	D	K	O	W	S
S	R	C	I	B	O	C	B	C	C	S	V	L	W	S	C	N	L	G	K
B	E	S	S	L	O	J	C	E	C	E	E	I	Y	O	E	W	U	C	E
D	I	O	C	I	S	C	W	O	C	E	M	W	T	M	I	H	W	L	C
R	U	I	O	K	S	Y	L	L	O	N	V	Y	L	F	G	H	E	I	E
W	C	S	G	O	L	I	V	L	N	W	W	I	L	E	R	S	E	W	V
I	I	L	L	R	J	E	O	L	O	F	S	L	S	O	S	Y	E	H	I
S	W	T	W	E	C	E	L	O	G	V	Y	L	B	E	S	M	J	I	L
C	H	C	W	L	M	J	F	U	Y	C	O	T	S	N	C	K	I	G	I
G	H	E	W	O	O	Y	W	G	O	S	E	I	W	E	C	L	L	W	U
W	T	E	L	O	F	D	W	S	C	E	C	I	L	S	I	I	L	V	J
R	W	O	S	O	K	C	S	O	B	E	C	B	I	L	E	S	W	S	J
I	O	O	C	U	C	C	J	W	B	S	W	F	S	I	D	N	I	C	K
F	O	H	J	W	O	L	I	E	C	M	L	R	W	C	E	D	O	L	W
S	L	T	O	S	E	W	G	M	S	R	S	G	S	M	L	H	R	W	E

Tape No. 4—20 characters per minute

(Receiving lesson IV, TM 11-454)

A	A	A	A	A	P	P	P	P	P	Q	Q	Q	Q	Q	X	X	X	X	X
Z	Z	Z	Z	Z	4	4	4	4	4	5	5	5	5	5	A	A	A	A	A
P	P	P	P	P	Q	Q	Q	Q	X	X	X	X	X	Z	Z	Z	Z	Z	
4	4	4	4	4	5	5	5	5	5	A	A	A	A	A	P	P	P	P	P
Q	Q	Q	Q	Q	X	X	X	X	Z	Z	Z	Z	Z	4	4	4	4	4	
5	5	5	5	5	A	Q	K	P	X	A	N	B	D	P	T	Q	A	X	Z
4	E	A	X	P	W	A	U	5	A	Z	4	F	L	5	Q	Z	T	4	Q
5	P	I	Q	A	S	5	M	R	K	P	4	V	G	K	A	N	Z	4	P
Q	Z	X	J	Z	Q	4	Z	Q	P	X	A	5	A	H	S	N	4	P	Z
X	C	Y	Z	P	X	4	K	A	Y	Q	4	O	P	Q	M	5	T	L	X
X	Q	A	Q	4	V	S	E	P	5	O	Q	Z	M	5	W	J	F	Q	Q
4	V	Z	W	N	5	X	I	Q	Z	I	S	4	F	M	5	H	R	X	P
D	X	H	5	T	U	A	Z	Q	M	E	Y	G	W	5	V	U	4	G	A
4	C	Y	V	4	P	F	P	D	B	X	Z	E	P	A	X	Q	Z	B	X
K	R	5	B	R	Z	A	H	5	Q	X	B	Q	4	Y	C	J	X	D	Z
P	D	5	B	X	E	L	K	G	X	P	X	A	5	U	I	Q	Z	5	H
Q	4	A	Q	C	X	4	O	G	N	Z	Q	5	A	X	4	J	W	R	A
X	5	P	5	Z	4	H	S	Z	T	P	4	I	P	Z	E	P	V	A	P
5	A	4	A	G	5	L	4	O	Z	4	P	5	A	P	C	A	O	Z	Q
P	J	Z	Q	Z	M	U	V	A	5	Q	F	L	A	Y	C	A	5	X	Q
U	P	5	R	X	X	4	P	A	X	D	I	4	O	P	A	Z	Q	P	P
4	A	N	J	W	Q	A	T	S	L	P	5	F	5	Z	Q	4	X	Z	5
F	A	Q	5	I	P	Z	Q	4	U	K	H	5	Z	A	X	A	5	4	U
A	G	4	A	Q	A	S	H	O	X	4	N	P	Z	Q	4	V	P	C	Y
P	Q	H	S	M	W	X	P	K	5	Z	Q	T	X	F	Q	E	Z	D	B
X	5	4	M	5	N	P	D	4	L	N	X	4	V	U	I	Z	G	Q	V
W	X	4	T	J	5	A	I	Z	N	T	5	Z	J	Y	C	O	X	R	K
L	Q	A	Z	Q	R	W	R	4	K	4	X	G	4	Z	P	X	4	V	U
S	Z	P	X	P	D	U	4	P	E	Z	5	L	F	S	4	R	Q	Y	C

Tape No. 4—Continued

O	A	J	Q	A	E	M	B	5	M	A	Q	X	G	5	J	P	4	Q	P
P	X	B	Z	C	Y	H	5	D	5	H	U	A	P	Z	A	F	X	5	A
A	A	A	A	A	P	P	P	P	P	Q	Q	Q	Q	Q	X	X	X	X	X
Z	Z	Z	Z	Z	4	4	4	4	4	5	5	5	5	5	A	A	A	A	A
P	P	P	P	P	Q	Q	Q	Q	Q	X	X	X	X	X	Z	Z	Z	Z	Z
4	4	4	4	4	5	5	5	5	5	A	A	A	A	A	P	P	P	P	P
Q	Q	Q	Q	Q	X	X	X	X	X	Z	Z	Z	Z	Z	4	4	4	4	4
5	5	5	5	5	4	5	Q	X	Z	4	D	4	K	P	Q	X	5	P	U
4	F	A	P	X	W	L	S	O	P	E	P	Z	C	Q	V	X	C	R	D
4	5	A	J	P	A	A	G	Q	5	X	Q	Z	A	X	A	I	X	Y	A
Z	H	Y	5	5	A	P	4	Z	5	N	Q	4	H	4	4	A	P	J	B
X	Q	J	Z	Q	W	5	V	B	B	Q	5	A	Q	R	J	5	A	S	M
T	Z	X	Q	Z	P	A	Z	P	4	N	T	4	R	X	C	Z	G	Z	X
W	I	Q	M	5	J	Q	P	A	C	A	W	S	Q	X	V	5	U	P	Z
E	X	4	5	M	X	Q	P	A	W	N	5	R	D	E	Y	Q	A	5	4
4	S	X	A	F	A	L	4	H	L	U	4	A	Z	S	X	P	A	W	U
M	H	K	U	M	Z	K	E	I	Z	P	H	K	O	S	4	V	P	T	Q
H	P	D	I	R	4	B	5	P	5	R	Q	A	P	Q	Q	D	5	G	G
Z	O	A	A	S	4	O	K	4	Z	4	P	5	D	X	A	K	P	Y	5
Z	M	B	Q	X	N	T	Z	5	X	L	U	X	5	L	N	K	E	M	5
A	Z	P	X	Q	O	I	E	X	X	P	Z	P	4	Q	D	P	K	4	Z
N	T	4	Z	A	H	N	4	4	A	4	Q	S	Y	Z	B	X	Q	4	P
F	I	5	H	N	Q	X	5	X	5	Q	U	B	F	V	5	O	Z	4	G
E	Q	A	5	I	5	L	4	F	5	P	T	4	Z	G	L	X	A	D	L
G	A	P	M	F	W	P	4	5	A	P	A	A	Q	5	Z	Z	X	V	J
4	F	G	P	P	5	K	H	Q	5	M	5	A	Y	U	X	Z	P	Y	P
Z	A	Q	F	U	Y	Z	S	5	Z	T	Q	A	S	M	W	5	V	X	C
I	4	E	C	C	A	Q	X	4	Q	I	C	P	4	J	A	Q	Z	N	N
5	J	H	U	Q	J	Q	J	P	A	A	Z	4	A	V	E	Z	O	X	R
P	F	A	T	Z	4	T	F	R	4	Z	X	Z	W	V	V	O	5	Q	X
P	Z	G	X	4	Q	4	X	X	4	4	P	L	Q	X	G	B	D	5	R
A	Z	X	P	Z	4	C	D	Q	R	V	Y	Q	5	Z	Q	P	Z	X	Q
P	A	X	Z	H	A	P	Q	Q	P	5	U	Y	B	V	K	U	C	P	A

Tape No. 5—20 characters per minute

(Receiving lesson V, TM 11-454)

1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	3	6	6	6	6
7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	9	Ø	Ø	Ø	Ø
1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	3	6	6	6	6
7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	9	Ø	Ø	Ø	Ø
1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	3	6	6	6	6
7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	9	Ø	Ø	Ø	Ø
1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	3	6	6	6	6
7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	9	Ø	Ø	Ø	Ø
8	6	P	3	Z	7	M	8	E	9	J	O	Y	Z	1	3	O	1	L	9
T	1	L	9	A	Ø	Y	C	D	Ø	E	6	K	1	N	9	A	1	E	6
9	O	2	F	8	P	Ø	A	Ø	I	7	V	4	L	T	Z	U	8	I	Ø
S	1	M	3	G	7	Y	S	8	L	Ø	2	W	1	O	3	5	6	R	9
2	Z	7	A	6	B	X	H	5	7	E	S	7	C	Z	W	4	V	7	Z
8	W	3	Q	Z	7	6	1	J	I	7	O	P	6	R	3	X	8	Z	3

Tape No. 5—Continued

2	X	B	9	D	6	8	5	H	6	R	4	Q	1	2	U	6	Y	C	9
3	M	Ø	7	6	L	U	9	B	6	G	O	B	D	1	N	1	7	4	2
7	Q	1	K	I	8	G	5	Ø	P	7	S	2	C	3	T	Ø	Z	8	6
2	J	9	E	6	N	3	E	9	K	8	1	V	9	Y	1	W	I	R	3
9	3	C	Ø	F	L	T	8	U	2	Y	3	T	8	Q	6	Ø	U	1	2
6	8	2	9	1	R	7	V	2	6	1	N	9	1	8	F	Ø	2	8	5
Ø	7	2	3	H	6	B	1	J	4	V	5	H	2	K	5	H	3	9	1
X	B	Ø	7	3	A	8	3	Ø	6	2	W	1	J	6	B	3	Y	7	8
Q	9	7	K	E	Ø	9	3	7	2	B	F	G	Z	J	Z	S	2	A	R
Z	A	8	G	6	Z	D	6	I	6	F	1	H	3	D	6	A	3	B	1
O	3	H	6	9	7	Ø	P	7	B	7	6	L	8	N	L	R	6	A	9
P	3	Z	6	L	6	P	5	R	E	M	Y	Ø	Y	X	Z	8	U	G	3
T	7	B	8	6	3	N	7	I	7	Q	Z	W	9	1	8	C	A	S	H
1	5	9	5	F	8	V	1	3	9	F	2	G	8	X	1	D	3	U	J
E	D	Ø	8	5	J	H	B	Ø	9	U	2	J	Ø	G	7	F	9	Z	9
P	8	J	7	8	9	Ø	I	L	7	I	6	6	P	K	2	6	4	6	8
K	Ø	E	Q	Y	9	D	1	W	C	J	E	7	Ø	E	7	R	G	7	8
Y	1	V	2	Q	1	C	1	1	6	2	Ø	L	1	7	Ø	6	V	2	S
O	4	O	S	1	3	N	5	W	Ø	N	4	M	2	Ø	3	T	O	S	X
Y	K	4	W	7	P	Q	B	2	V	T	9	H	1	K	9	V	8	K	3
K	Z	8	4	B	Z	1	L	1	C	6	1	D	C	9	8	1	2	J	7
F	5	1	9	G	6	N	2	V	6	3	9	2	3	W	3	U	N	T	1
6	F	5	B	6	D	H	7	Q	Ø	F	7	T	8	M	3	9	2	3	W
3	U	N	T	1	6	F	5	B	6	D	7	W	7	N	9	M	8	Y	9
O	A	U	S	4	X	6	1	Ø	W	Ø	Ø	H	3	8	3	T	Z	X	8
Y	Ø	U	9	R	1	1	8	6	V	8	Y	7	Z	7	U	2	3	Y	2
G	6	A	3	Ø	I	D	9	P	Ø	L	E	I	R	7	Z	C	4	8	R
1	9	9	7	X	1	S	8	Z	6	8	7	6	H	7	9	6	Ø	9	Z
3	9	2	6	3	2	5	1	8	3	7	9	4	7	2	9	8	7	5	6
9	8	Z	2	D	9	6	9	G	8	Q	Ø	K	7	M	6	8	2	X	3
Ø	7	1	B	6	P	3	F	7	K	1	N	9	F	8	D	3	G	1	7
9	K	1	F	A	3	N	2	F	Ø	C	4	V	5	H	7	T	6	8	9
6	B	2	G	3	Z	7	G	9	E	1	M	8	1	7	W	2	A	8	4
3	8	7	2	B	6	1	8	Z	Q	1	2	K	9	Q	7	X	3	Z	7
9	V	3	J	1	L	7	X	9	Y	6	Ø	3	G	Ø	N	8	Ø	6	2
2	1	C	Z	O	6	Q	1	P	9	2	3	K	6	F	9	Y	I	8	9
3	E	Ø	S	3	P	Z	D	8	D	Ø	T	2	N	7	M	Ø	D	7	8
O	3	L	2	H	5	W	3	J	1	L	O	8	2	T	8	U	9	6	7
6	U	1	A	6	R	9	U	7	W	1	S	4	V	8	Y	9	P	H	5
3	I	1	R	9	E	1	J	8	C	7	X	B	6	M	9	R	Ø	7	6
1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	6	6	6	6	6
7	7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	Ø	Ø	Ø	Ø
1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	3	6	6	6	6
7	7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	Ø	Ø	Ø	Ø
1	1	1	1	1	2	2	2	2	2	3	3	3	3	3	3	6	6	6	6
7	7	7	7	7	7	8	8	8	8	8	9	9	9	9	9	Ø	Ø	Ø	Ø
8	T	9	S	2	8	2	3	7	2	9	6	Ø	X	9	Ø	9	6	3	9
2	3	O	6	3	6	1	O	1	Z	W	X	M	Q	J	3	8	7	B	8
7	K	B	8	V	1	E	3	U	I	P	L	2	M	7	3	B	Ø	1	9
C	2	2	Ø	Z	1	1	2	7	3	C	Ø	L	1	1	3	9	F	3	A

Tape No. 6—25 characters per minute

(All letters and numbers in random order, 5 words per minute)

A	S	D	F	1	A	P	L	K	J	2	P	Q	E	N	G	E	Q	X	I	4	H	6	X	Z	
O	B	R	7	Z	4	W	T	U	8	4	5	C	Y	M	9	5	A	S	D	F	Ø	A	V	H	
N	H	7	D	Q	D	Y	U	6	S	S	M	U	R	D	N	Y	N	G	F	V	Z	H	T	N	
G	E	C	Q	D	H	R	N	4	D	C	K	F	K	S	A	Y	B	J	V	5	X	U	D	H	
Ø	W	E	F	N	J	O	M	H	W	R	U	M	L	4	D	F	F	2	R	X	N	H	U	1	
R	H	Y	J	M	Ø	P	B	K	R	H	V	Z	C	U	N	M	V	V	A	I	F	G	4	F	
X	I	U	G	Y	Z	L	O	H	F	W	I	G	V	B	H	7	W	X	C	F	J	J	Z	5	
N	V	F	5	P	5	I	M	H	Z	X	P	U	V	H	4	A	Z	G	Y	M	9	G	A	Y	
D	M	X	5	5	N	V	U	J	T	S	T	Y	U	R	D	Q	U	B	U	1	Z	A	J	V	
G	Z	B	Z	Z	O	R	J	8	A	D	L	N	G	K	Q	I	E	F	F	2	4	Y	H	M	M
8	C	Q	E	N	R	B	Q	P	G	B	J	I	P	A	N	H	U	D	4	P	B	M	R	L	
Y	9	S	R	M	H	4	V	B	V	G	I	Y	A	G	Y	F	E	B	H	H	U	U	Q	J	
Z	D	K	H	Ø	Q	O	H	D	R	K	X	Q	C	D	U	D	T	4	J	B	U	9	H	F	
H	H	G	4	L	Z	R	B	F	O	5	W	H	D	U	V	W	Z	U	R	H	B	4	X	C	
F	U	Ø	S	Y	C	B	H	G	Q	V	E	J	J	D	Z	S	Y	R	H	6	4	P	K	J	
F	Y	C	O	K	Y	J	S	Q	5	B	H	J	C	A	N	U	N	F	Q	S	A	H	J	H	
U	Q	G	I	M	F	O	S	U	W	T	M	A	X	4	G	H	J	S	Z	J	G	D	H	R	
E	H	I	D	J	I	5	O	K	U	U	H	L	T	H	M	H	C	Z	P	Y	D	U	K	A	
H	R	F	G	D	J	Q	O	V	M	Q	4	X	U	V	H	3	Y	S	J	R	F	Q	L	U	
W	M	U	9	G	D	C	D	M	W	4	D	G	B	H	G	5	U	I	U	M	R	A	4	V	
J	H	D	S	X	Y	J	H	9	Z	T	W	N	M	2	C	A	J	K	R	T	F	M	O	J	
U	J	W	J	E	H	G	K	S	B	U	B	F	9	T	D	K	V	U	X	X	5	R	V	R	
W	O	4	K	H	U	G	P	P	C	J	R	U	W	4	W	U	U	W	P	D	B	D	G	5	
F	P	Y	D	H	3	A	X	S	X	U	U	Q	V	F	M	M	Ø	5	Z	K	N	U	N	Q	
P	V	U	F	W	W	V	J	V	U	Ø	M	Y	W	J	H	Y	T	X	N	Y	F	7	S	G	
F	F	M	C	E	4	W	B	U	I	P	P	R	B	U	A	U	4	S	F	H	5	Y	A	C	
R	U	W	D	Q	J	K	R	S	M	C	L	H	J	F	L	X	W	M	M	6	5	X	C	V	
J	J	5	O	G	T	H	7	4	D	C	G	U	Ø	X	G	V	B	J	T	J	Q	N	V	U	
7	X	D	C	N	G	1	X	S	R	V	J	P	5	4	E	F	G	N	Q	A	J	H	U	V	
D	A	G	R	U	D	F	Q	N	D	U	4	4	5	Y	N	U	Ø	W	Z	U	H	G	Z	U	
4	S	D	M	5	P	W	I	N	U	9	P	V	U	U	U	U	U	J	H	K	U	6	R	5	
D	J	F	4	5	V	R	H	M	S	P	P	F	D	U	4	B	G	C	M	R	C	Y	O	G	
V	U	Q	H	X	I	K	R	I	L	U	F	N	U	9	X	5	W	T	M	A	V	A	D	B	
J	G	J	P	H	D	F	3	Z	W	C	T	U	8	Z	5	E	V	U	Ø	Z	P	V	D	F	
Q	Z	4	S	M	H	Q	S	X	E	T	H	I	4	B	L	Y	M	I	Z	U	B	D	U	5	
P	F	Y	B	H	2	V	4	U	H	H	O	Z	4	H	N	F	K	A	C	W	D	J	W	P	
I	Y	B	H	7	H	T	B	N	J	Y	X	W	D	F	M	J	4	R	F	B	H	7	W	5	
F	F	F	O	L	P	K	K	H	U	A	J	R	D	H	D	4	Z	W	J	H	5	O	P	V	
G	U	W	U	N	U	V	F	S	5	S	H	J	U	Y	W	A	O	H	M	Ø	4	T	S	K	
U	C	A	M	K	H	J	A	F	S	B	G	R	Z	C	A	Y	J	G	T	Z	R	V	V	F	
D	B	V	R	B	H	C	V	C	W	V	H	W	Q	F	O	J	M	B	Q	M	E	J	G	J	
S	S	I	D	F	Ø	Y	5	U	B	J	Z	H	D	G	U	M	O	4	X	S	R	F	8	I	
U	R	N	U	F	P	L	J	H	M	P	J	P	I	U	J	C	H	U	J	B	H	B	S	X	
U	J	M	9	5	A	C	H	G	Ø	S	T	R	R	H	X	5	V	Y	J	U	A	A	W	K	
T	R	O	V	F	D	J	H	E	Z	Z	U	B	T	S	P	I	N	D	U	9	J	X	S	K	
R	U	P	L	G	T	H	D	A	M	B	B	J	Y	P	P	C	A	D	1	S	F	A	D	1	
P	K	2	L	J	P	K	2	Q	N	3	E	G	Q	N	3	X	V	6	I	H	X	V	6	Z	
B	7	O	R	Z	B	7	4	T	8	W	U	4	T	8	5	Y	9	C	M	5	Y	9	A	D	

CODE PRACTICE EQUIPMENT

Tape No. 6—Continued

Ø	S	F	A	D	Ø	V	V	9	I	H	4	H	8	Q	G	X	C	U	A	R	Y	S	M	Q
H	R	T	W	I	Y	H	4	H	F	S	D	S	H	Y	Q	L	G	5	D	7	Q	F	7	R
R	A	F	Ø	D	F	J	I	F	4	V	G	A	J	5	B	J	N	H	1	X	B	4	B	H
Q	B	C	E	B	8	I	J	A	G	D	H	B	D	G	U	5	B	I	4	J	T	H	F	P
Y	D	X	D	Q	R	U	X	T	3	H	M	W	R	M	U	U	9	B	J	Q	T	H	V	B
4	C	K	S	U	M	A	B	Ø	A	V	D	Y	G	U	H	Ø	X	M	G	W	G	D	R	1
L	G	J	G	F	A	B	K	G	J	E	T	H	4	J	R	X	D	Y	D	J	4	K	Z	5
U	P	C	F	Q	V	C	5	H	T	W	H	Q	H	9	P	B	X	U	H	W	K	A	T	6
S	M	X	U	8	A	D	C	K	M	R	D	Ø	5	J	P	C	U	N	M	D	S	U	N	R
U	X	V	F	Q	F	L	W	U	X	J	V	A	D	Ø	K	G	X	T	7	Z	Y	U	H	J
U	K	9	D	B	7	N	G	4	V	T	I	G	Y	D	F	Z	J	M	Y	V	A	F	M	4
U	S	Q	J	4	T	R	L	T	S	P	R	V	U	J	J	R	A	G	9	D	U	Q		

Tape No. 7—35 characters per minute

(All letters and numbers in random order, 7 words per minute)

A	D	1	S	F	A	D	1	P	K	2	L	J	P	K	2	Q	N	3	E
G	Q	N	3	X	V	6	I	H	X	V	6	Z	B	7	O	R	Z	B	7
4	T	8	W	U	4	T	8	5	Y	9	C	M	5	Y	9	A	D	Ø	S
F	A	D	Ø	5	B	2	O	G	Z	D	6	X	K	Ø	O	M	P	K	Y
X	V	2	O	H	T	D	Ø	Z	D	6	G	U	Q	Y	O	4	N	9	U
M	P	N	2	X	K	N	L	F	4	T	M	P	T	6	I	R	I	V	3
Z	Y	6	W	R	4	T	8	Q	D	3	S	H	H	J	B	Z	T	2	W
H	O	K	7	X	K	3	V	G	A	Y	2	4	B	7	I	J	U	B	1
4	N	8	C	H	5	Y	V	N	V	7	W	R	4	H	6	5	H	7	L
M	Q	U	8	Q	Y	8	R	J	P	B	S	Z	F	8	W	J	A	J	1
4	G	7	W	H	Q	B	2	5	V	6	L	U	Z	N	8	5	Y	6	O
F	Z	T	A	Q	V	W	S	J	4	R	Ø	Q	N	J	N	U	Q	K	1
4	V	3	L	H	5	T	9	Z	G	Ø	O	H	4	V	7	5	Y	Ø	I
M	B	M	2	X	H	7	J	U	X	Y	8	A	K	Ø	O	H	P	Y	Ø
U	D	9	I	M	X	B	Ø	R	T	8	H	G	I	U	9	4	B	3	E
F	A	H	9	Q	K	9	O	G	4	B	9	A	K	2	J	H	A	G	7
A	J	8	I	H	M	N	9	Q	D	3	N	J	Ø	B	1	K	N	8	T
H	E	N	1	X	T	9	S	G	4	T	3	5	B	7	W	F	Z	D	Z
T	Y	2	O	G	X	N	Ø	P	N	D	S	M	Q	B	7	H	V	4	C
G	4	B	Q	A	K	8	E	M	O	K	6	Z	Y	P	R	M	C	V	2
X	B	8	U	H	F	T	7	4	Y	8	O	H	P	D	O	X	B	9	L
M	Q	F	6	X	U	2	O	R	Q	V	2	N	V	6	M	H	R	M	Ø
5	T	6	I	H	A	Y	2	Q	V	6	E	J	Z	B	9	A	Y	8	L
H	X	M	7	P	N	7	I	M	4	K	M	4	F	M	E	H	X	U	Ø
5	B	7	L	H	5	T	Ø	E	B	9	J	M	Q	Y	9	V	B	9	S
G	Q	V	3	S	V	Ø	I	M	4	N	6	A	V	2	S	G	5	B	3
4	T	R	C	J	Q	U	J	Z	D	6	O	G	4	D	A	A	B	K	I
H	4	K	1	Z	B	3	E	H	Z	B	6	L	K	1	L	J	4	T	7
Q	K	2	O	H	P	K	7	O	N	1	O	G	P	G	1	A	N	2	W
H	U	K	6	1	J	1	C	U	R	R	2	T	F	7	I	H	Q	T	5
A	B	1	D	H	A	V	Ø	5	N	7	K	H	5	D	Ø	4	D	2	E
H	Q	D	N	Q	N	3	L	U	Z	Y	6	4	B	3	S	H	Z	J	C
H	B	Ø	O	G	X	K	Ø	N	Y	7	S	H	Z	K	Z	4	H	8	S

Tape No. 7—Continued

G	Q	N	8	F	K	3	O	H	A	V	6	X	D	3	L	U	X	V	8
Q	V	T	O	U	Q	H	1	Q	K	2	I	M	E	T	8	A	K	Ø	L
H	W	T	G	4	N	6	I	U	5	Y	J	4	K	P	S	H	4	B	7
P	Y	H	G	R	X	T	O	A	N	S	E	U	X	J	Ø	M	Y	8	E
J	L	D	7	Q	D	B	L	R	4	K	B	Z	N	Ø	Y	H	X	D	3
Z	V	1	W	M	A	V	2	4	B	8	O	M	Z	T	2	4	N	1	S
H	P	F	8	V	B	I	W	H	Q	Y	E	5	N	Ø	L	U	X	D	1
5	B	1	W	F	Z	H	Ø	X	V	8	T	H	R	D	1	5	N	7	L
F	G	K	2	4	U	S	C	M	N	K	Ø	P	Y	9	C	U	A	N	2
5	T	2	W	J	Q	Y	9	4	K	B	F	U	E	Y	9	4	B	2	C
R	4	U	1	5	V	K	C	G	A	N	8	C	N	3	W	H	A	B	6
5	N	6	E	M	S	U	6	4	V	S	J	H	A	K	8	V	N	1	O
U	Z	F	Ø	T	F	1	F	J	Q	B	B	P	R	9	E	R	X	T	7
A	D	7	B	G	X	T	8	O	B	Ø	G	R	L	T	8	Q	K	9	K
H	5	Y	6	Z	Y	2	I	J	Y	V	9	R	N	6	U	H	I	H	7
P	D	X	C	H	D	B	7	X	N	1	C	M	Z	G	8	P	K	1	L
A	J	5	B	J	N	H	1	X	B	4	B	H	Q	B	C	E	B	8	I
J	A	G	D	H	B	D	G	U	5	B	I	4	J	T	H	F	P	Y	D
X	D	Q	R	U	X	T	3	H	M	W	R	M	U	U	9	B	J	Q	T
H	V	B	R	C	K	S	U	M	A	B	Ø	A	V	D	Y	G	U	H	Ø
X	M	G	W	G	D	R	1	L	G	J	G	F	A	B	K	G	J	E	T
H	4	J	R	X	D	Y	D	J	4	K	Z	5	U	P	C	F	Q	V	C
5	H	T	W	H	Q	H	9	P	B	X	U	H	W	K	A	Z	T	6	S
M	X	U	8	A	D	C	K	M	R	D	Ø	5	J	P	C	U	N	M	D
S	U	N	R	U	X	V	F	Q	F	L	W	U	X	J	V	A	D	Ø	K
G	X	T	7	Z	Y	U	H	J	U	K	9	D	B	7	N	G	4	V	T
I	G	Y	D	F	Z	J	M	Y	V	A	F	M	4	U	S	Q	J	4	T
R	L	T	S	P	R	V	U	J	J	J	4	A	G	9	D	U	Q	V	D
P	D	Q	C	R	C	B	V	9	B	M	N	M	M	K	M	V	V	4	V
G	J	N	L	A	D	3	N	F	F	G	S	H	J	B	Y	U	X	B	C
Z	F	U	K	H	E	B	X	O	Y	1	I	R	X	N	2	Q	H	Q	W
U	W	N	4	4	K	E	N	U	V	F	W	F	V	U	B	G	5	U	T
Z	V	H	N	F	R	T	C	W	Y	2	V	U	5	H	F	X	K	9	R
H	I	T	7	X	U	X	H	U	X	G	2	Y	M	J	W	H	4	D	8
V	V	Z	E	J	P	K	R	S	H	Q	E	H	5	H	5	P	T	J	C
F	Z	D	U	O	V	Z	H	J	M	B	1	5	V	B	T	J	Z	R	B
N	V	4	N	F	D	D	Ø	A	J	J	C	H	Q	B	G	G	K	9	V
F	4	G	7	U	M	3	W	M	X	D	S	4	B	Ø	H	J	P	U	2
J	B	B	F	H	W	N	Ø	G	H	E	V	J	X	H	S	O	B	4	G
U	W	G	W	T	J	N	C	H	S	H	Q	P	T	1	J	U	B	N	6
H	B	R	W	G	5	J	7	Q	N	M	S	M	X	H	M	X	U	5	C
H	V	F	7	S	T	N	G	F	P	B	Y	U	V	A	F	U	Q	G	4
D	N	5	H	M	A	H	B	D	H	U	T	H	B	J	V	U	F	L	P
M	H	K	Ø	4	D	T	K	H	H	T	W	X	V	6	E	H	X	D	S
T	G	E	F	M	X	R	V	A	V	S	R	R	W	F	S	M	M	U	Y
U	A	V	6	J	D	8	D	G	Q	J	D	B	K	J	T	F	V	F	Ø
D	D	9	C	U	Z	N	5	5	R	4	H	R	5	D	4	4	F	U	G
U	U	U	N	P	V	M	T	R	P	B	5	4	B	4	O	U	H	T	5
D	V	C	W	G	S	G	X	P	U	X	O	H	H	T	9	X	H	W	I

Tape No. 7—Continued

U	P	B	S	V	R	V	U	M	O	V	P	Z	Y	4	H	U	5	R	C	
P	M	5	Y	F	U	J	2	V	H	R	G	U	4	K	A	Y	V	Z	C	
H	5	H	S	X	B	2	V	F	G	U	U	G	J	I	R	M	A	B	5	
4	N	6	E	U	D	J	B	P	H	D	I	U	Y	N	5	4	V	O	C.	
H	Q	B	N	A	J	S	B	U	Z	D	3	Q	V	E	N	R	R	J	Z	
C	T	2	K	J	Q	N	Ø	X	Y	C	E	M	U	D	B	X	G	Q	K	
J	X	B	V	O	H	M	D	H	Z	J	2	D	B	C	J	U	P	V	V	
G	J	D	W	J	Z	U	O	1	Q	Y	H	K	U	4	H	8	D	R	S	
G	H	G	C	S	T	B	C	J	A	Y	Y	4	J	U	F	G	T	J	3	
A	H	2	I	U	4	K	J	A	M	F	H	U	B	B	Z	Q	T	A	V	
U	5	B	W	5	J	X	T	U	B	U	L	Z	H	V	C	G	Q	H	I	
4	J	C	W	M	S	G	B	W	H	D	S	U	J	R	6	V	M	D	R	
U	M	B	O	J	Y	7	L	U	S	Y	T	5	D	6	N	F	A	T	N	
V	G	8	S	M	Z	J	Q	P	V	2	N	U	D	N	W	G	H	Y	H	
R	A	J	5	O	V	2	Y	U	4	G	U	X	D	P	L	R	S	D	F	
U	B	D	U	U	Q	R	O	5	V	1	R	M	Q	U	H	A	F	C	H	
J	W	M	X	P	K	9	K	F	Q	Y	Ø	W	B	K	B	U	Q	V	J	
5	J	M	W	U	U	V	V	X	P	G	C	I	F	B	D	L	4	R	2	F
H	D	K	Ø	X	V	D	I	H	H	D	G	B	B	Q	V	M	Q	H	U	
U	G	Z	W	U	S	R	L	F	M	C	O	H	X	G	2	5	D	9	4	
H	A	K	X	4	F	Ø	F	F	J	Y	W	C	J	T	J	J	D	J	5	
I	U	D	B	H	E	M	T	T	H	4	B	J	U	D	Ø	W	T	6	J	
M	S	G	E	R	R	Y	H	H	Q	Y	V	5	V	Ø	L	F	E	D	X	
P	B	V	H	H	X	J	V	J	N	J	W	H	J	H	Q	Z	R	G	G	
H	4	K	B	P	V	4	C	U	4	H	K	N	T	4	S	F	Y	U	6	
S	D	7	U	U	H	B	6	A	Y	N	G	M	Q	V	S	T	B	2	L	
U	X	M	9	M	D	C	W	J	5	U	4	S	J	3	H	R	G	Y	R	
A	M	F	D	G	G	H	U	R	H	D	V	F	A	A	T	V	K	7	C	
H	5	J	M	C	R	2	K	H	B	Y	D	F	H	H	B	M	5	F	Ø	
M	V	S	J	G	X	9	S	D	K	F	F	H	B	J	5	U	R	C		
J	U	D	8	D	Y	3	C	M	J	B	G	X	D	4	D	F	Z	G	I	
U	J	6	W	U	O	H	L	L	J	6	W	M	A	N	T	P	M	9	F	
J	D	B	U	U	V	2	Y	H	H	V	D	X	D	W	T	M	Q	H	6	
A	F	Z	E	G	N	N	7	T	H	N	R	H	C	U	5	V	H	U	T	
U	M	V	3	W	V	W	V	R	A	Y	V	F	V	J	D	H	X	G	M	
A	H	K	F	U	4	B	J	I	Y	Ø	1	U	P	H	4	X	U	Q	B	
R	4	V	1	L	M	L	F	H	Z	J	P	M	G	V	E	J	O	N	D	

Tape No. 8—50 characters per minute

(Groups of five letters and numbers, 10 words per minute)

ALTHR POMTR DLSMT WOESX THBUW ZOXIC TUELX QPSIX ZTRMN BPQIR MSIW
 ALCIT TUZRO 13597 ZAIQB PRIWS ZIVBC OPQIV MIROW NONES AIMES GKPQZ
 ICUTY VISLX N10WZ QPSOT EIPQZ IRVEX PZXBN MNPOQ RVEMP TYRIE PXIZO
 WQRVP XIALE ASCMY 87651 IRYQO PZXGI MPNOS ZRATP YAMSO QPWXM YRUAV
 IRABU BEZZB M10QR VDXSG GHRMP PQXET EMIEZ PTWPZ AXCRQ GUMOU EUIRY
 13579 IHYGM NBMVI ISLXI QPZXY IYHGM NURIZ PQRVE CIMPL YMAXZ TYEXP
 AWQHG HRMLV TPQVM RVQPO 64720 IMXQP WXONA PXINE WHYAR TYEXP AWQHG
 HRMLV TPQVM RVQPO 64720 IMXQP QWXON NIXPE YAWHR YCOMN CRACT IYWOX
 ZTQPP AXIIF QPOWI ERYTA LSKDJ FHGZM MXNCQ RASTP UTONG HORMO PQRWS
 TYZZL LMHYU UMNQG QOXIX ZAZIE FORMD 01932 WHIXZ ARPHU GUHIL WZXGA
 ILLXT YEISL XIXLW PQOSL IELMS NXIO Q EOWLX TEQUM WHGIW SOXLA YSOEL
 HGUEI NSIWL ZHXOC COIES ANDIH THROG EMPUS ZIPIS RPSIX SOGHU ELNSI
 WLZHX OXCOE ESAND INTRO GIMPU ZAEPI SRPSI ZALTH HRPOM TROLS MTWOE
 SXTHS UWZOX ICXRS LXQPS IXZRT MNBPQ IRNSI WLAAI TUZRO 17362 ZAIPR
 IWSZV BCPPQ IVMRO WNOWN SAIME QSPQX UTYVI SLXNI OWZQP SOTIE PQZIR
 HTXPZ XBNMO PQRVE NPTYR IETXZ YAMPQ WXMYP UAVIR ABUBE ZXVMI OQRVD
 XSGHR MOPQR WSTYZ XLMHY UMNOG QPZAF ORMWH PUGHJ LWZKG AISLX YEISZ
 67325 YOSHG ELUNS IWZZH XOCAN DIHTR OGIMB USZEP ISREZ SOGEL HUNSI
 WLZHX PMOTR LDSMT WOSEX THERXX VBOCP QVIRM OWNSI IRQSP ZWSTX YMTPQ
 12089 XLNSN1 OXQYX PMIYW UAZOX MPTPQ ODHCT NMWXU QPOSA YEISD IYZPN
 TWSYH GZCOT QWMNO RWPQX LUQXF NUGWH WIGSO ZLAYS APDWT ZOTQB 47361
 ITBQW RWLUM WGZAD TWEXD URGNL ZHMOR LDXWH VQMRZ BOART PLWQR STCCY
 AROYX PQIES BIYQP IEQZZ ISXLW IUWEH GRSPZAMBA PQOWK LHMGO PURMZ
 QEPWZ ARMQY OARQW BVNMR AIWQP APXCB ZBAIP EXYUW 09873 RQPTD OEKAS
 ZXSTO CEU1P ZHN0V URWPQ ABWLU PATBN RSYP1 SOUQP LUGML NOUXZ XRTMP
 GAHYW PIQZR LRPPWW BBZXX PRWIB ULQGH XRMOL SRHNP WBZZX BCOIU IAGVY
 YHWQP LMNPO 56209 PZBAM EROLK KPYOU METOL ZCPOK HNMWV PLWTV ZPKIY
 SPIRT WBTLZ NKEID NKIWL HDURH SUHYF KORDS CITHD LAOTY NAEWQ PUDJR

CODE PRACTICE EQUIPMENT

GREOV JDEWQ NASIT JEIGZ FOPTS BOVRI MASPL JDYRU BDZAJ KTREU KDHRU
 URYTE OJGRD XIYRA VOURS CJLOD ZKUWR QUTRX MURSA 76430 UTIYR LIHQW
 KFGDT SLPEX NKLRU VJIDR XTHFS NSEOG SIEIS EEWQP JUTRS 91538 DTRSA
 MLPDY TWEIV TVVDE CYPDL BALSA WVVPY QGZAP WNAUR ELUMS RXUQV TYXZZ
 YSAOI UVXTF IDWKL OFERL PASDQ LTDQQ KNTRX JDTRE HAWQE GVIIW FMWPI
 DCOT SAWQL AWERT ZSTVP XFBIE CDERT ØØ917 VBLAS BTUIL XWNMT NJILQ
 MHGRX WS DGK FJCBB MLIOS NTHIY EREHT HDRBB CHIDX RAMPV NELDQ BURPA
 GOOLX NUTCA 74531 LOUIE BGETY NSIGA VGKIS HZAPT GAPS E JUSEW APWER
 HITZA KWQPL FRIKW FMCIH LNAEQ GROUPD FPBRM FPYRU BKKRO CVCZQ 15390
 ULMSN VXNSE JDMMT CBSQG WERTY UTOPL KJHGF DSAAZ CVBZN MWRMN EHCRN
 BGNLB NVVGJ AHXFF LGFPV CUVJC WUKDC MEVNA ALCWVN KKDUO 57390 ULMSSN
 VXXNST JOMTT QTZSI LUMUU EDASD RXARW TXURS GSPSA YVEGA TRPVB JIFLL
 WPXEE WITLT PERBT XVQAK AEYAS 619Ø8 TEWRA LWHQD MUOQN ETGYL XNNBN
 JFBCA CMORS VIUDW SAYVL ETDDTS DASKN LNAAWW LSNDK NURLE JEBFJ NDJEN
 OMDRH VHNLC ADWSJ HJXSNN TGBCV 5Ø133 CNZXCLJQNB OAWGA CCATH NBMSWW
 QJAST GKUJW VURSR XTYWE WEBRV VNKCY HZADT WIXDS YBITA TANWH TCWKD
 WASOW NNLSR RUVXA HNRZP DBJBM 11468 WOJKY TNOCWGASA NVHET RXTDT
 HWLEY TEBVF PVCLM AGXUY HLNEJ WWOJX TYCNC WTNOC NTQVV RGAS KTACU
 NDWCV DWJOQ NOYWN ZLWDC 89753 XWFNTN JEUID CIOSI JEUIZ SORWA OOEAK
 VOUOL NEPZI LWQPV NMJIQ LTQZX OMOTA XYTMB AMATA AJRRW BNTRX VDPHW
 SAVCL LZOJC PUCCZ TMN1Q OXSDM 1Ø937 QWXAS OJATI BYVFA PWDDAN LINYM
 BELLS YAWCL EAIST TVSPV VS DGR RSJYK YHATI VATMX TISYD ZQUELF 1Ø828
 OJJIE DOTJH SOUNA DIOQH SWMEW HARWD AYNOW DDPEJ QIDEO WCJOX VTEXN
 QGNSSV CLSRX SNLYL QRACV KFVAW LQMPV RRALN TJNDA DEXNL SJXSTYWNB
 KOVTW 74523 GDOWS NVJXT MPOAC QRMIN AZIY ZARLQ CNSXD XMLMA IAWIN
 NVKTY QNOFM RANWX HASSR NTNWC PATXD RUMBA DELXV CYKWS MIARQ CLXZP
 MITFK MPRPS DELCO OTLOS 9971Ø RIQPB NMRTZ XISPQ XLEUT CIXOZ WUBHT
 WSEOW TMSLD RMOPT RHTLA SENON TMRIM VIQPO CBVIZ SWIRP OQIAZ 76541
 PRZUT IICLA LWISN OPPNM NBXZP XEWRI XQHIE TOSPQ ZWOIN XLSIV YTUCU
 AQPOG SLMIA SONPM IGXZP OQYRI 15578 YMCSA ELAIX PVRPQ OXIIXT EIDTT
 PMEVE TEXQP PMHRG GSXDV RQOIM VXEZB URZRI FVURY MXWPQ OSAMY PTARZ
 DTCZQ ISLXI IVMBN MGYHA TRIGH UOMUG UAXXZ ZPWTQ XEIME OPQVR MVOPR

Note.—On tapes Nos. 9 to 12, inclusive, some of the recordings terminate before the end of the material given herein. The material on the tape is continuous as given herein to the point where the tape ends.

SIGNAL CORPS

Tape No. 9—60 characters per minute

(Tactical traffic, 12 words per minute)

WZ1 V WX3 NR1 P GR19 NINTH BT
 NR1 CD MHNBT NJIUY MSHGT NNBG P QPIUY MNVXS WEIPT IPRTY
 MNSSXT TIWPQ MANTP MNTOC VCPQW PIQWX MNGPQ QPOWY 102P II II
 WZ1 V WX3 NR2 GR21 NINTH BT
 NR3 CD MPRT IOEQP MNOWL KNQPA STHGC DEGST IEMHS YMTOZ
 MAXCV BCPQR ONTOZ MNTAS LDdap SHIES OTILM BOMTE NATMA ZXMVY
 105P II II

WZ1 V WX3 NR3 GR14 NINTH BT
 NR5 CD MNTP ALNDD KLKKL OPQWT SDHNG HKNSA SLTIO NEPAD
 NORMD SNDPQ WIRSE 108P II II

WZ1 V WX3 NR4 Y P GR12 NINTH BT
 90 INFANTRY TROOPS ENCAMPED ON OUR LEFT FLANK MACHINE GUNS NECESSARY
 EXECUTE 110P II II

WZ1 V WX3 NR5 I I WZ1 V XL7 GR21 NINTH BT
 NR6 DFCT1 NHTY ME0E MAME KJHT HJNH HNMK ZXSE REQ
 MNIP QWE C XZVG HUIN QWPY UNRY MNQP EXCV MNPY SHIE
 115P II II

WZ1 V WX3 NR6 P GR24 NINTH BT
 NR8 CD MNTP SOPRT EIPAT PQIRE PTIAT XCPTY UIMNP QPRIY
 MAOEC VCOP QPRUM XCZBV PUWYT MEPTO QPEIT MANTI AUTIK DLKRB
 MATNA EMTYU CVZXS 118P. II II

WZ1 V WX3 NR7 NITE GR18 NINTH BT
 NR10 CD SPRIT MENTI SHTIP NMJRU QWPOJ NBVER EIPQI METIP
 NJTYU NHGZX ASWEP PONMO SSLKU OUTYE WPOWX 119P II II

TM 11-432

CODE PRACTICE EQUIPMENT

WZ1 V WX3 NR8 Y P GR25 NINTH BT
NR12 CD OMER C WZAST MEOTO HGNBW QPOUN FHTYU KJMNT EINJT
MNZZE WTEQP QPZMA LAQPM MSKLD KNHGU NJGUT NGSER EIPTH HBNTO
NSOEP NAOEP QYURS TMATE 119P II II
WZ1 V WX3 NR9 Y P GR16 NINTH BT
NR15 CD MUTYE HGBNI WE SDN HNXCE OJUJO MNHSSW WRTYU NOQPU
MAPTD APPRM NQWUR MAPTE SDHEI 121P II II
WZ1 V WX3 NR10 GR20 NINTH BT
NR13 CD KNPQR MARST INEAU RYTUN AQWPPO MNKIT TYHBG ZX SOP
NJPER NCXVB QWCVY EIMXT APKLD HGTYD TYDKR AIGHT NBVZX 12 5P II II
WZ1 V WX3 NR11 G Y O GR19 NINTH BT
NR15 CD MNOPQ QPLAN RYGHB QIJHX ZAQWE RTNGB EPQPE EIMBV
NQQRK KLTOX XOMTE MADVO DSSHSDDIRT NDITE QWURP 127P II II
WZ1 V WX3 NR12 P GR23 NINTH BT
91 NR16 CD MENTP EPEID NOWRS EIMVS OPWEP NCOSG SGOHT TMWTA
MAPRT ZXVYP SNDAL DIECT MXCVP PQMDT EIDMG QPODK AMDKP ASKPL
NDPQU URSP 128P II II
WZ1 V WX3 NR13 II WZ1 V DO9 NITE GR14 NINTH BT
NR18 CD NRRIOR DEOOU WPETAD SAPR SIVCP EIPEU EIIMS NAPET
MANDO NAPRO NEOPQ 129P II II
WZ1 V WX3 NR14 G P GR7 NINTH BT
ENEMY CAVALRY ROUTED DRIVE SUCCESSFUL HERE 131P II II
WZ1 V WX3 NR15 P GR27 NINTH BT
NR19 CD MENTI AONER NAPRQ MTOPR GHFMH EOTPE PQIRT MEOTP
MNTZX WOTHD GHKLD AKDLS DNWOJ JKLLD DALSN EPMTU MSOLK GHTRYR
MATIR MSOET XFHPQ SORMH DMSTK STAMX 134P II II

SIGNAL CORPS

Tape No. 9—Continued

WZ1 WZ1 V WX3 WX3 NR16 NR16 F F GR21 NINTH NINTH BT BT
 NR21 NR21 CD CD GIESS GIESS MS PRG MS PRG QPWEB QPWEB EIRMT EIRMT
 OWDHT OWDHT WWMKJ WWMKJ SJLKT SJLKT APRJL APRJL NDEMT NDEMT
 TMASS TMASS SILKER SILKER MTEMJ MTEMJ JKLNQ JKLNQ DMTRJ DMTRJ
 KLSTS KLSTS ISLES ISLES NDJDK NDJDK SLTSE SLTSE 134P 134P VA VA
 II II

WZ1 V WX3 NR17 NITE GR20 NINTH BT
 NR22 CDEIGHT MSFKT SHBDK SGTIM SOEPE MAXNV OTOMD SOPEM
 DMS TE SPETD KANEI SNDIT AJDKM DKTIO SMDKT SKDLS EIRY Y 138P II II
 WZ1 V WX3 NR18 T XD1 V WX3 G NITE GR31 NINTH BT
 NR25 DFCT1 EIMG HOLD HARS DKMG DMSI EIHN SLNS SLPR
 MSJD SPEI XNCX MSTO QPRM MAPE XMVN QWOP SLPN SPMN
 NPEN DOWP WORU STON SNDP ASE N QPRY TS LT MADT PEEN
 92 139P II II

WZ1 V WX3 NR19 GR20 NINTH BT
 NR27 CDMSTOP NSORI NXPET SORMN VCIEI SMSOP NDOEN SPARN
 MAPXG YUROG HJI PC VOTAL COMPT MSPTS SORIE SJHND DNOTC 142P II II
 WZ1 V WX3 NR20 NITE GR18 NINTH BT
 NR29 CDDOPSX SRIDH JRNXD LKS RW QPRYR UMONZ WOELX SIRNS
 NDGEI ZDCIP DNIPD FESNP DNSIP EIGHN SITEM 145P II II
 WZ1 WZ1 V WX3 WX3 NR21 NR21 F F GR19 NINTH NINTH BT BT
 NR31 NR31 CD CD SPEUM SPEUM TIMSX SIOXX DKAPL DKAPL
 SNDOP SNDOP QPRUR QPRUR THSMD THSMD MADND MADND MSNDL MSNDL
 SNDIP SNDIP SMDKL SMDKL NDISL NDISL KYRUS KYRUS NSMHD NSMHD
 SMDAL SMDAL DOPQU DOPQU 147P 147P VA VA II II

WZ1 V WX3 NR22 O GR12 NINTH BT
 LOST HILL TWO SIX SUFFERING HEAVY LOSSES NEED SUPPLIES AND
 AMMUNITION 151P II II

WZ1 V WX3 NR23 P GR23 NINTH BT
NR34 CD SNDIN SIPEI SMNDP XDCVC IDMSL MDTRC DPEIT MSTND
JGHTY DKJFU AKNCV AWERD MBNB J HGFRT DTBCV EIHDK SLNDI XCZWE
DPEIT URYUN 153P II II

WZ1 V WX3 NR24 G NITE GR21 NINTH BT
NR25 CD SDDJK SNDKL EIMXL SBGHT NCMKW WOPKD NMLPA NVBEQ
MDNPE UOYJK LDGBV SMEMT YURST MXOMD QWADK LJUYR HDNBB TYUNB
155P II II

WZ1 V WX3 NR25 T XD5 V WX3 NITE GR29 NINTH BT
NR41 CD DKIEH MNHTI MNVKS EUTYH NBVRFG RUIMK SIEHD SMDHX
MN DJH SMKDI TNDDS NDIEY MSJDH SJDI P UTYQV BDGKI 158P II II
WZ1 V WX3 NR26 Y P GR20 NINTH BT
NR43 CD MSJUT NSITY SMKSL DKITH SKSILK DNТИX SMDKT SKJNC
MSPEI QPEIR MSNBE SRTYU MSNEPEIMXL XCNDK DILET MSKSY 159P II II
93 WZ1 V WX3 NR27 GR15 NINTH BT
NR45 CD MSKLS KDIHT KDNSK DKUTH SKKID MIJTK SLITH XFKMC
MSITH SLPKP QURYT SKMDO 159P II II

WZ1 V WX3 NR28 P GR19 NINTH BT
NR49 DFCTI EIMD SIMG NJDN DKPE MDJS NXOS IPQI MDMX
MDNS SMDP QPIE MSND MSKD MEKT IENT NJUT 202P II II
WZ1 WZ1 V WX3 NR29 F NITE NITE GR22 GR22 NINTH NINTH BT BT
NR51 NR51 CDDMSIRD MSIRD IPSJK STHNB DISMD DISMD ISMDI
ISMDI
TIME TIMEL SMXSP SMXSP MSOED MSNDX VICEO VICEO SNXCP
SNXCP
QURYT QURYT MXDKP MXDKP DMXPE DMXPE XHHZD XHHZD KLJEL KLJEL DISND
DISND
ADJEP ADJEP DISXH DISXH 203P 203P VA VA II II

Tape No. 9—Continued

WZ1 V WX3 NR30 GR15 NINTH BT
 NR53 CD UIKLO FWSDX ZAQSW JFHGX DHFGT CGFTR KFHGJ
 GGBCN EYRTF WXADS GTYFH HVGSK 204P II II

Tape No. 10—60 characters per minute

(Tactical traffic, 12 words per minute)

FQ1 V XL7 NR1 G O GR18 EIGHTH BT
 NR11 CD OWYRI UONHV JKLSA NCERT UBZXS QMNCB HLKDF NJOPQ
 HAYTG SPOIL NYTG QUOET GHDA ERYQP HUITS 112P II II
 FQ1 V XL7 NR2 GR12 EIGHTH BT
 MORALE OF THE MEN LOWERED CONSIDERABLY BY ENEMY ATTACKS FROM
 AIR 114P II II
 94 FQ1 V XL7 NR3 O GR25 EIGHTH BT
 NR21 CD QAZXC RFVBN UJMLP OKMNB YGV CZ ESSZAQ WSXDR TGBHU
 IJNHY TFCDE WAQWA RFTYG UKKIO PLKJH YGFDS QASDF QWSDC RTGHB
 MNHGR BVFDW ASCVT JUNHV 118P II II
 FQ1 V XL7 NR4 P GR9 EIGHTH BT
 ENEMY TANKS THIS SECTION HAZARDOUS FOOT SOLDIERS HELPLESS
 AGAINST
 119P II II
 FQ1 V XL7 NR5 T FU1 V XL7 Y GR19 EIGHTH BT
 NR31 CD QOWOW UNIKL UIRYT SIELV NMZK SITUE SIQPY DJITY
 MSITL SLITE SITHD NBYEI SLAPQ NGYTJ SLEYT SKITY 121P II II
 FQ1 V XL7 NR6 G GR22 EIGHTH BT
 NR41 CD DFHJU EISLR KIOUY BCHJK MKTRE XSDVG BNFGH NMJUI
 MBVDE ZXCVB HGFDs UIYBV NTRED MKJYC VFDSI OPIUN MJBVc HYDRC
 VHJUT 125P II II

F Q1 V XL7 NR7 GR17 EIGHTH BT
NR51 CD INCGJS IEOHG MOESSZ OJGGVC BFWAM OIUUXS BRJKI MHTRD ZSTYN
MKLOI NJRFB BHVTG KIEXC NJWAS 127P III II

F Q1 V XL7 NR8 GR19 EIGHTH BT
NR61 CD NIEYT MCJAL CBNGS PZIET CIESL WHTRA VHAKL INTOT
KUYRS SDALE LITCK SCGBA NJHRT MJARY REWA A NINTP 129P II II

F Q1 V XL7 NR9 O GR16 EIGHTH BT
NR71 CD QPALZ MALQP IEURY RIOER NAITO EOTIE KELSB NUTHE
TOUTY HJDZN JSOTU SLIET NKELT 132P III II

F Q1 V XL7 NR10 GR25 EIGHTH BT
NR81 CD WORIO SKELT LROTU SOELT SLETU SLEIT ALSIE SLEIT
TIEKLE OTHR EILZZX NNELE ELTIT DKFJG DLLSY KKEIT GHTUE DKWMZ
EEOUU JJAKE LELEI UTYRW 134P III II

F Q1 F Q1 V V XL7 NR11 NR11 FF NITE NITE GR19 GR19 EIGHTH EIGHTH BT
BT

95 NR91 NR91 CD CDO LIKU OLIKU JHYTG FRED S WAQWA WAQWA
AZSXD AZXS D
CFVGB CFVGB HNJMK HNJMK LPOLPLPOLP QWEAS RTYFD RTYFD
UIOHG UIOHG
OPLKJ OPLKJ ZXCFG ZXCFG VBNHJ MKLOP YGUGH YGUGH 135P

VA VA

F Q1 V XL7 NR12 O GR17 EIGHTH BT
NR12 CD QWOET EILTO EOTJS IJNBH UHBVG TFCDR EDCFR OLICKJ
OPQWZ ITUEI KSMTU EOTUR KDLEN LIKEO 137P III II

F Q1 V XL7 NR19 G GR21 EIGHTH BT
NR72 OD UIEOE PPIOT OSITY RONCL ZSLAO OLEHI ROQIR APZOD
SOTYFLKIYT SOTLD ELUTY SITYQLLSITY OTOWI SLPRY TUQPE GHSSKL
156P III II

Tape No. 10—Continued

F Q1 V XL7 NR20 T PQ9 V XL7 P GR16 E I GHTH BT
 NR82 CD RURIR SLEIT TUIPQ ISUTY EOUTN FHALD SLEIY EILSI
 NTURPELUTLIEOTQ SKELY 202P II II

F Q1 V XL7 NR21 GR16 EIGHTH BT
 NR82 CD ITYHE UTHAL ENOTP ISQPR ALZNC SLIQQ UTYRA EITYQ
 UTHLC MALLY SIELT ALTYQ ALITY 204P II II

F Q1 V XL7 NR22 Y GR21 EIGHTH BT
 NR13 CD TOQPW SLTUR SIELT LEIAL NELZL ENGLS ZELAI TNALE
 NALDI ELTUA NKEFD SLENF NSKEL NEUTY SMALL UTALE EJALI HURYT
 206P II II

F Q1 V XL7 NR23 G P GR19 EIGHTH BT
 NR23 CD NVLSK ALIRT NSLZL MAIEL MENTL SITYE ZLCKXN SLEIP
 96 UQOSPTYSLX CMXLZ SLEIT NSITY MAOPR EOTYH MEIGH 208P II II

F Q1 V XL7 NR24 Y NITE GR14 EIGHTH BT
 NR33 CDAEIOUEOITH LEITH MAITY HLEIT MELTI SLEIQ
 YSLPQ MEPRD FGHAL EMTHA 210P II II

F Q1 V XL7 NR25 Y O GR6 E I GHTH BT
 FO2 NR7 FIFTEENTH 1145P 210P II II

F Q1 F Q1 V XL7 XL7 NR26 NR26 F F GR26 EIGHTH EIGHTH BT BT
 NR43 NR43 DFCT1 DFCT1 QPWO EIRU EIRU TYGH TYGH FJDK FJDK SLAP
 SLAP

ZIMXZIMX JFUR LAUT LAUT ZWXE CRVT BYNU BYNU MIKO MIKO
 LPJILPJIBNTRBNTR DEWQ XDSA XDSA ZGRY ZGRY KUOY QPNC QPNC
 ZXCVZXCVJKLOJKLO UIOPUIOP QAZS QAZS 214P 214P VA VA II II

F Q1 V XL7 NR27 P GR17 EIGHTH BT
 NR53 CD MCJKD LEITS MELTY SIELT SLEIT EIOPT TOSIE NEUTL
 MAUTY ENKTU SLEIT LSIEH NEITB NNUTH 21 5P II II

F Q1 V X L7 N R28 O G R19 E I G H T H BT
 N R63 C D E I O R Y E O M E I S K A L U L E I A Y D K E I A N C K E L E T C H E E E L I S
 Q P P A O E O T U N E I L T T I E L T S L E I U E I T L S M A U G J E L I T Y 217P II II
 F Q1 V X L7 N R29 Y N I T E G R22 E I G H T H BT
 N R73 C D Q P O E I I T U E J S L E I T L I U T Y E I T A Y Z L H N V L E I T H H H A L E
 L E I A L T M E K T T H I E L T T M E I T F I E K T M M E I T A A Z X C S O O K X M E I T H N E L T Y
 A L L O K 218P II II
 F Q1 V X L7 N R30 II F Q1 V K 9P G G R16 E I G H T H BT
 N R83 C D A B B F U X N A M M A E L T I E P O I U R S L E I T N N E L T L S I T Y M E K T L
 U X N D K D K E L U T I E L A M E K T L Q P S O I 219P II II

Tape No. 11—60 characters per minute

(Tactical traffic, 12 words per minute)

97 F U1 V F Z2 N R1 P G R16 T E N T H BT
 N R10 C D J H N Y T B N H G T B G F R E B G F D E C V F T Y V G Y U I N H T R E K L F R E
 W U Y R E B G U W E B Z X C Q I N H Y T N G B D R 112P II
 F U1 V F Z2 N R2 G R18 T E N T H BT
 N R11 C D N H G T R V G F C X C D E W Q Z X C E W D S U T N H G T R W N M H G I N V C Z Y
 P G Z I W N B F X A C X E Y H M N B G R F V D E W B X C D T B G F R E 113P II
 F U1 V F Z2 N R3 T W Z1 V F Z2 G R18 T E N T H BT
 N R12 C D M N B V Z C D Y U I B G F E W C V D F G H G T R E D C B G T M K J L U O T Y B G
 M J N F B G V D S Z X D W A S R D F T Y B H F G R B M N D T B V D W Q 114P II
 F U1 V F Z2 N R4 G Y O G R22 T E N T H BT
 N R13 C D X Z S D E F G V C R H G B V T G H Y U I M N K J Y H G B J I L K M H N K M D F W
 O U I J N B H G T R F D E W S Z X S D R V G F B H N J K M G J N B F V C G R F E V G H Y T U I O P L
 M V G E D 115P II

Tape No. 11—Continued

FU1 V FZ2 NR5 P GR17 TENTH BT
 NR14 CD O JK YH BG FTR VDFRE BVFG R HG C XZ MH J KY MNEIP VDXZW
 PIO UY I URT V SWWQ ASDFR SD FGT KJ HGR 116P II

FU1 V FZ2 NR6 Y NITE GR15 TENTH BT
 NR15 CD MN BHG BVFDS XC FGT HB FVC VFDES XC DFT VG FR Y BG HFR
 MN HGB BV FDC CDSAX I UHGT 118P II

FU1 V FZ2 NR7 G P GR17 TENTH BT
 NR16 CD MN HHG HY TG F GFRTE FDREW KMNGH BV FDC VC FDE MHNTI
 DL CMF AN SHD BV GFR VDU JT BHGRE OISHE 119P II

FU1 V FZ2 NR8 G NITE GR19 TENTH BT
 NR17 CD MN BVG J HGF T HG FDR MKLJ J KJ HUY J HGYT H J GNB BV GFR
 MN J HK J HGU T NB HGG HG YTR BG HFT MN BJR FS CXD ZX CES 111P II

88 FU1 V FZ2 NR9 T XU1 V FZ2 Y GR18 TENTH BT
 NR18 DF CT1 NJ NH NJ YT BV GF BV GF VCRE ZX PO NJ HU GY TR
 MKLJ KJ JU J HUY HRTF GF RE BC FE DW SA 120P II

FU1 V FZ2 NR10 GR17 TENTH BT
 NR19 CD NM JK I H J TYU FG ERT CV XZD CF DRE FG YTR MN K LJ BF Y SZ
 PIO UJ JK LYU J GYTR VDGHR V C XZS NM J LU 121P II

FU1 V FZ2 NR11 Y P GR19 TENTH BT
 NR20 CD IU H JK J GYTR Z XC SD SA DEW S REDF FD TGR SQWEA Z C X DR
 I JK HY NB GHR BG FVR CF DEW SD TRF BV GFT HG UY J LKIOU 122P II

FU1 V FZ2 NR120 GR24 TENTH BT
 NR21 CD IU J HY NB HGT FX ZEC F DEWA BV GFT KFN BH CV DRZ SD WA Z
 NB HGF VF CDX CF DTR GY THB NM J KO KL JUY H J N B Q GTR FD FREDW FDR WS
 NB V GU BF DCI V C X SA 123P II

FU1 V FZ2 NR13 Y GR15 TENTH BT
NR22 CD IJKGT XSDEW ZXSSRE VGF DZ CVBNJ MNHUY KLYHU BFGRS
L JMNT GVF RW CSFDR VCGRU 124P II

FU1 V FZ2 NR14 NITE GR18 TENTH BT
NR23 CD MN JGY HVFTT VGDFFE BVHGU IOJUY HGYRT GVFD C CDSXA
MKLGY BN JHU JHYTG HGFRE DFRTE NBHGR XZCSW II

FU1 V FZ2 NR15 T WZ1 V FZ2 G Y NITE GR17 TENTH BT
NR24 CD XZES SD FDREF GFTRY BGHYT GFRED CFDXA ZXDV C BGHJU
MVBF R FGDCF VCFDE SXDZX VBCVF HFGDR 126P II

FU1 FU1 V FZ2 FZ2 NR16 F F P P GR23 GR23 TENTH TENTH BT
NR25 CDD CDD MNKJU MNKJU KJHYT KJHYT GHTRF GHTRF VBGFT VBGFT
FDRED FDRED CXDSZ CXDSZ ZXASZ ZXASZ BVPXT BVPXT MNJKT GHVBR
GHVBR FVCDT FVCDT VGBFC VGBFC CVDWS CVDWS VCFDT VCFDT GYUO GYUO
PKLIJ PKLIJ KJUYT BHGRX BHGRX BVGFR BVGFR FVCEQ FVCEQ 127P
99 11

FU1 V FZ2 NR17 G P GR17 TENTH BT
NR26 CD NH JGY BCVXX XSDRE GFVTR GFVCD FUYTG BHGIU JNVDC
NVBF D CVFDE CXZSD CFVRE VGHBN NJHMB 129P II

FU1 V FZ2 NR18 GR20 TENTH BT
ENEMY ADVANCING ON ALL SIDES PLEASE LET US KNOW BY PIGEON
WHETHER YOU CAN SUPPORT US AT THIS TIME 130P II

FU1 V FZ2 NR19 Y O GR17 TENTH BT
NR28 CD NH JYG HGBFT GFRDE BGHVF DCFTIO MKJUY HJUYT BGFEW
MKLDG VCFRE FDCYU BGHTW CXDSE JKRTQ 131P II

FU1 V FZ2 NR20 P GR18 TENTH BT
NR29 CD MN HDR VCDWA SREFT BCXZE QWEDS FGDR E BVGFT MNKYI
POIUH JKLOI NBVGF VCFDS BVCKZ 132P II

Tape No. 11—Continued

FU1 V FZ2 NR21 NITE GR18 TENTH BT
 NR30 CD PILKO KJIUY JHUUT NBHJU JHGYT HGBVF VBGFT VCFFZ
 BVGFR FD CSE SC DFTT GFVBB YTRFG NBJHU XDSZA 133P II

FU1 V FZ2 NR22 P GR16 TENTH BT
 NR31 CD NBVGF GFVFR GHYRF BVGHY NBJHU HGYTH BVFDS CXDSE
 MNJHY HG BVF GVFDL CVFDE DSXCA 134P II

FU1 FU1 V FZ2 NR23 FF O O GR17 TENTH TENTH BT BT
 NR32 CD CD BVCFR BVCFR FVCD E FVCD E CFDTG CFDTG BHGYT BHGYT
 NJHUI NJHUI MNJUY MNJUY HGTYB HGTYB CXZSW CXZSW KEYVX KEYVX
 BVGFT BVGFT FHGUk FHGUk LHKG E LHKG E VSYTn VSYTn NBGHR NBGHR
 135P 135P VA VA II II

FU1 V FZ2 NR24 T LC1 V FZ2 P GR18 TENTH BT
 NR33 CD BV CXX ASDFG HYTG R SDEWA BVGSX BSAZX 136P II

FU1 FU1 V FZ2 NR25 NR25 FF GR19 TENTH TENTH BT BT
 NR34 NR34 DF CT1 DF CT1 JHUT JHUT BVGR CFDE CFDE CVFG CVFG
 BHGY BHGY MNUY MNUY SXHG SXHG GFVT GFVT TRFG HYTG HYTG
 NJHU NJHU YGTF YGTF VBDL VBDL CXZS CXZS SXCZ SXCZ GWSA GWSA
 138P 138P VA VA II II

FU1 V FZ2 HR26 T LC2 V FQ1 Y GR22 TENTH BT
 NR35 CD TFGTE VCD FE DSXAZ CXDFG GFHJK HJKLO IUKL BSKFJ
 MNBHJ HGYRT GFVBT GFVBT GFD ET GFD ET GYGT UIOPJ MNHJK
 CFDET 139P II

FU1 V FZ2 NR27 P GR16 TENTH BT
 NR36 CD XZCVG VCFDR YTGHU NHJUY HBGER DETV D CVEGGY HJUOI
 LKMMJU NHUTG NHGFR BVFED VF CXX 140P II

FU1 V FZ2 NR28 Y GR17 TENTH BT
 NR37 CD NBHGF VCFDE CDFEW BVGHY JNBHG BHGYT GFTRE BVGFR
 NJHGY BVGFR CVFDE DXCSA ZXSEW LMNYY 141P II
 FU1 V FZ2 MR29 GR18 TENTH BT
 NR38 CD MNJUT ZXCVB OIJKU BHGTR FDEWQ ASSXD PQALG BVFDE
 JHYTF VCFED CGVHB NBHFR DSXAW BVGFR FDCTS 142P II
 FU1 V FZ2 NR30 P GR17 TENTH BT
 NR39 CD FGDRDF FDESWEFTYR BHGFT JHUO KJIUY PLKIU KJYHT
 JHGTR ZXCCDS CXDFR GFTRE BVHGT NBHJY 143P II

Tape No. 12—75 characters per minute

(Tactical traffic, 15 words per minute)

KX7 V KZ3 NR1 P GR10 FOURTH BT
 NR5 CD TYRSD GHOLY MKLRO BHTRY OPYCG NMURG LIJHK 1100A II II
 101 KX7 V KZ3 NR2 P GR15 FOURTH BT
 NR8 CD MKTOP MKLSH IPYTS BSHTD ISPHS MOPGD KLPHYQ MNVXS
 UISDG MJOLY SETYD FOOEY 100A II II
 KX7 V KZ3 NR3 GR20 FOURTH BT
 NR19 CD MOIJH PUYTQ MJKHD PETYD LFLFL OMOMINTYQWI PKLJH
 UDFTS MNBCX YQUQY MKNLI PUYES MJHGF ASDFG LFJKD OIURS 1144P IIBII
 KX7 V KZ3 NR4 NITE GR9 FOURTH BT
 NR13 CD TYREW NGFTW PUYTV VBHSF OUAAL MPOWS 800A II II
 KX7 V KZ3 NR5 P GR19 FOURTH BT
 NR15 CD LFHJI EABCD MNHST GRTOP GOOTY MKLFG BNGER PIITYQ
 HS DRT BVGFL QYUIT LPRST KJLHG EPTRS ADGKP MOIYT 745P II II

TM 11-432

SIGNAL CORPS

Tape No. 12—Continued

XX7 V KZ3 NR6 GR21 FOURTH BT
NR19 CD LOIUY JHTRS KHBGD MLFGH PIOXT DWTRP MDGFS QYUTE
TYREW GHSDE SSHST MABVC PUTYE MKL FH OYTHR CGFTS ABCDF THOPR
950 III III

XX7 V KZ3 NR7 O GR26 FOURTH BT
NR22 CD TRSRE MNBVC CYOIT PLKUT EDFRS MJHGT WDMNX ZMOIP
BHGF1 OMPQW MBVCZ JYTHW PUYYTS DETRS LKJHG DGFS A BVCM ABWSU
RWQOP GHDES BN CXX GHROY LHGJD 855P III III

XX7 V KZ3 NR8 GR21 FOURTH BT
NR25 CD TYPIU DEPHL MHGTL EDFRP PUMNB VDBFG QRWTE MHGFT
BVCFG MKLTY ERTYU QWERT GHTRYP MHYTR EFLGH QYRTS MERTS GHRTA
855A III III

XX7 V KZ3 NR9 Y GR27 FOURTH BT
NR27 CD KODZS OPYHG MNBVC TYREW SDFHK PUWQ MGTWS PIUYT
VHGF D KDLJG PUYEW BVCHD PYGWS SEGHF ITERS HSPYT MGHT B HGT P
GHRYS PIUHR SHETR MFGL LFITE GBNC 111P III III

XX7 V KZ3 NR10 P GR22 FOURTH BT
NR19 CD TYPRE MHSDG FLKJH REWQY YQRTS PIOYT MENKL ERTYU
AFGRQ MGHTY SHIPE MNHKE THYRE GHTRYW WDFHG KJHFG MEPIE MNSSLG
MNHGT 625A III III

XX7 V KZ3 NR11 G P GR27 FOURTH BT
NR19 CD TYPRE MHSDF FLKJH RRWQY YQTRS PIOYT MENKL ERTYU
AFGRQ MGHTY SHIPE MNHKI THYRE GHTRYW WDFHG TYERS LKJHO EIGHTY
GHRYS PIUHR SHETR MFGL LFITE GBNC 111P III III

XX7 V KZ3 NR12 P GR23 FOURTH BT
NR46 CD FGHHJY QWRITY QUIOE GHTRYR HNGT Q QYPT MEFGT PTYRS
MAHSG MNVGF PTYWQ AMSNL MERTY RTYWE MGHTP BHGJS DCVBF BVDRH
OITYR TYQWE 1100P III III

KX7 V KZ3 NR13 O GR18 FOURTH BT
 NR4 CD FGHJK BETRS METRS GHBN TPTYUE MASDF GHSDF METGH
 QWERT TYUIO DFGER MASTY METYU GHRWA ADSFD 835A II III
 KX7 V KZ3 NR14 Y GR7 FOURTH BT
 NR7 ATTACK AT DAWN REINFORCEMENTS FOLLOW 105PA II III
 KX7 V KZ3 NR15 Y GR17 FOURTH BT
 NR12 CD GHRES METYU UDJKP GHRET MQOPE NEKLS ADFKL MENIP
 NRGHU IERPO MELSE MENZZ ZYRTX NTHRY 1010P II III
 KX7 V KZ3 NR16 P GR24 FOURTH BT
 NR34 CD RETYS ZCXB SLPIT FGTKL TNPOZ ZFGTY MLSKJ GHREW
 ALPEX MLDKJ DEOIF MSLPE MANLT MENPE DEZCY MLSQI MILPYJ QTRYU
 ANKEP IOKJE MEPYI 900A II III
 KX7 V KZ3 NR17 GR20 FOURTH BT
 NR15 DFCT1 THIE SPIL NEKL THIP MLKJ MKLS QRSTS MLSH
 103 NOIU QERT MLHK MGHt MLHJ RSTY GHTU WERS MPOR 455P II III
 KX7 V KZ3 NR18 GR21 FOURTH BT
 NR14 CD TPOIG CVBNM ANMLE THIUY QYFGGL ALFGJ MKLST MLSHR
 NOIKP MNDKS ADHKL NMLKJ MNYYAN THOIS SHIEP MLKHP ERTYG MLAPW
 1012P II III
 KX7 V KZ3 NR19 GR8 FOURTH BT
 NR8 MACHINE GUN NEST CAPTURED NO LOSSES 125P II III
 KX7 V KZ3 NR20 GR24 FOURTH BT
 NR11 CD KLIQ NKLQW MANYD GHTYU ARETZ XCVBN MNALE QRTYU
 NKLAE TPOIW NKLS TMEITY QPOIS NOIUR SDFGH HSIFT MILPAR IOSHE
 RTYUI QWRTS NKLSE 95PA II III
 KX7 V KZ3 NR21 GR21 FOURTH BT
 NR5 CD THOPS IOZZU MJKHT SLSER MFLFK TYQWD DOI PA MLKPW
 NATGH HYRES TRYUP QWYPO OMKOU NAFGH ALPRY CMLAR POITY CVBNV
 1010A II III

Tape No. 12—Continued

KX7 V KZ3 NR22 O GR24 FOURTH BT
 NR67 CD QWUIT FOOME SPOET GHDVBB ASDHGH POIEN LKASD THGSR
 QWTXYU UDFGH AILNK QRYVH VVDUI GHWEYYQTSMD MPONT MLSKJ
 QTYUP VCDVD GHTVB SHOPE 1245A III III

 KX7 V KZ3 NR23 P GR7 FOURTH BT
 NR10 OBJECTIVE REACHED AWAIT FURTHER ORDERS 250A III III

 KX7 V KZ3 NR24 G GR17 FOURTH BT
 NR25 CD THIOP ERGTS NOIRT NIGHTW WDFFGH QPOTU QYTFL NHBGJ
 THYER FHTOP OMOJM SOTHW WWGHT BVVFE 145P III III

 KX7 V KZ3 NR25 GR21 FOURTH BT
 NR25 DFCT1 MOMO THYR WEDT MNBV VDFT WDRT GHRY VBMN
 QWRT TOMT JOMJ RTHY AMLE GHRE WSHIA LOP PHOM SLOT
 255P III III

 104 KX7 V KZ3 NR26 G GR25 FOURTH BT
 NR23 CD GOIUY SDFFGH APOET GNMVBB BBBTB RTTRRW CYCTI APOID
 ABHVF PIOUY WTRFG HSIEG METRY YQWYR REDGF FLDGH POOPO GHURD
 ANHVT TETYTT TTOIT GHCDC 100P III III

 KX7 V KZ3 NR27 O GR21 FOURTH BT
 NR13 CD VBNMS RTYU FHVBE ALPER VBETR ISSIT MLAGF ENTRE
 NOETD DDDKD NLSLF GOETD NODKD NOPER MLARE EPTIZ ZZNNKZ WRRTYS
 910A III III

 KX7 V KZ3 NR28 P GR8 FOURTH BT
 NR50 ADVANCED TEN KILOMETERS SEND SUPPLIES REINFORCEMENTS
 200P III III

 KX7 V KZ3 NR29 GR18 FOURTH BT
 NR45 CD GHIUR QWRDF FLASH GHINT SLPEO ALSKT MENTH RETYA
 NALRT TREWY SNKLD GHTYI WNLET GHBNV FVTYV WETVB 755A III III

KX7 V KZ3 NR30 GR22 FOURTH BT
 NR22 CD GH TYU WRET FFLIE EGHRF FTYHG QWRTU AMLST MKOTE
 NLORT WEFGH SETRS NLET DODOD NKLWE FGHLT MERET NKLPS THYRS
 NSDSI 700A II II
 KX7 V KZ3 NR31 GR20 FOURTH BT
 NR24 CD TOTPO METU JEPET BNHGT WESWT MDGTY MELPR SDFGH
 NPEOR TRESO EIMLP NLKET SISLS METRY SLPOE MSLTE NOIET 1100P III III
 KX7 V KZ3 NR32 O GR8 FOURTH BT
 NR78 BARBED WIRE ENTANGLEMENTS HOLDING OUR ADVANCE 836A III III
 KX7 V KZ3 NR33 G O GR21 FOURTH BT
 NR77 CD BH GRE MPOEN SLKEK GHWER RETTR NLPOO MOTOE NKLSSE
 NKLSSE EITZS ZYEQT MLSPE MALSQ NKSTZ XXDIX NLTEX AZAGZ NPETO
 756P II II
 KX7 V KZ3 NR34 G P GR17 FOURTH BT
 105 NR42 DF CTTI INGR TRKA DHUT NCNX AGHI YEWS OPYT
 RDX EWPU NHKL RESA FTOP NRPV YHVZ 849P III III
 KX7 V KZ3 NR35 NITE GR22 FOURTH BT
 NR53 CD YR QNP JITWC THEMA NGKLA NOPIT JKLAS ASFUX MKHFS
 EQPMZ ZITBV OA FSL LHSGH NOVAM RIYHA JLDAN MRQYW TQPMZ FHSLA
 RQINX 853P II II

Tape No. 18—75 characters per minute

(Tactical traffic, 15 words per minute)

FL2 V FQ3 NR1 GR16 FIRST BT
 NR6 CD XEIRT PITUR NFVOV QITGB CIPXS ORHAM QINHF PNVA
 PRWYL KFJOS YROMS TOMKE TPVNH 831A III III

TM 11-432

SIGNAL CORPS

Tape No. 13—Continued

FL2 F Q3 NR2 GR14 FIRST BT
PROCEEDED ON ROAD ROUTE R4 AT A SPEED OF TWENTY MILES PER HOUR 120A
II II

FL2 V F Q3 NR3 GR21 FIRST BT
NR28 C D MLUVF VFGUT HGDAL VTNUM VFEXP OLESO NJTRC NYIOE
SDCVT BHGRZ TEUBR AIRFC HUTGB RIPVA QYETC TPMHA FBXRH NJSSL
844A II II

FL2 V F Q3 NR4 GR17 FIRST BT
NR37 C D HETDA NITCM HGNKA RQOPA NHRE J MFDCZ TNKS LHOPT
GADWN R P QNB V CDGJ URYWA EBSOH QOPRD 848A II II

FL2 V F Q3 NR5 P GR18 FIRST BT
NR42 DFCT1 INGR TRKA DHUT MCCX AGHI YEWS OPYT BGJI
REDX EWPU NHKL RESA FTOF NRPU YHVZ 849A II II

106 FL2 V F Q3 NR6 G GR22 FIRST BT
NR53 CD YRPQN JITWC THEMA NGLKA NOPIT KJLAS ASFUX MKHFS
EQPMZ ZITBV OAFLSL LHSGH NOVAM RIYHA JLDAN MRQYW TQPMZ FHSLA
RQINX 903A II II

FL2 V F Q3 NR7 O GR16 FIRST BT
NR29 C D JREPQ TRNKS LEKAD TADCK QOOTD TNALD RNIAF RDKAL
TOAKS EO CBN ZIRPQ NHGSD NAOTA 907A II II

FL2 V F Q3 NR8 GR23 FIRST BT
NR18 DFCT1 PQRX DTLL FOPU HJK AXDD HBNM GEIT IENN
NBVJ WERZ MERL IBTX LIKJ KIOP POPP TELE PONK MLPE
VTNU MITF 910A II II

FL2 V F Q3 NR9 NITE GR19 FIRST BT
NR43 C D HREPQ QWENF HAULE TCXMA ZMXNC XNCBF TROPQ FKLAG
QMPZY NORDC HRIBT GEIMP WNOXG UMRXA YTHFS JKLAS 917A II II

FL2 V FQ3 NR10 GR12 FIRST BT
MUSTARD GAS DEPOSITS IN THIS AREA THICK ADVISE
DISPOSITION OF SUPPLIES 265P II II

FL2 V FQ3 NR11 P GR25 FIRST BT
NR74 CD QNZSE PLMKO QUAAZP TROPE NOITA NAKLED HMBAX ROFAN
NAUTD KLAHN IEATP SUSPA NUMTD KJASSL SLTYP NPETZ HAJHS ZXASW
POKLM ANSIE NAKEL TMEIS 926A II II

FL2 V FQ3 NR12 GR17 FIRST BT
NR29 DFCT7 QPZM OWNX FOEO TAIS TIAL KFEL AIRE FHJK
FHLA SJDK ROAO ISSM THAK KAND 929A II II

FL2 V FQ3 NR13 P GR18 FIRST BT
NR37 CD PQIOT NORKS TOAIG NAITE MAIRT SKLEG ALTJD DJAHF
MAOPE NUTYQ MEFPT ANYOH MILKAS NTAGS NRAPK 932P III III

FL2 V FQ3 NR14 O GR20 FIRST BT
NR28 CD TRAI0 MEEP PER SLEAL MATIY PQMZH AILTA MOTNH PAHSL
MJAKL LEAIT MATYD NJTIQ JKEQR YPQMZ XNVAC ORYUW NAKTU 936A II II

FL2 V FQ3 NR15 GR15 FIRST BT
NR49 CD WQPRT YAPER MITBZ SHALFAEIT PQALS MAITY RAIGH
MATHA JANGD FCVZS MJNKL 937A II II

FL2 V FQ3 NR16 Y GR24 FIRST BT
NR12 DFCT1 TRAY NJKL RITH TWDC AIRO SIEL AIEP MAIT
AGSF ALDK QPWQ RQIP THRT MZNX BAJD HARI QMPZ KALG
QMZP WONV CPAT 942A II II

FL2 V FQ3 NR17 P GR17 FIRST BT
NR13 CD TOPER NAITJ AMTOP KLAGJ ELAIT APTQC MAPTB NAKLR
ATITY AMTAP NAPTE EOFTW QPNMC TRWYR 946A II II

Tape No. 13—Continued

FL2 V FQ3 NR18 GR19 FIRST BT
 NR14 CD U I PTH J A P R Y M A P E N T W P Z M J K L A D F A L K E M P Q U T R P W N V
 H A K L S L E P T E P Q L T Y Y Q P Y Q H A P G L R P Q U T A L T I R M N C X Z 948A II II
 FL2 V FQ3 NR19 G GR18 FIRST BT
 NR15 CD P Q I O T A I T P R J A L K E E M T I P T O A P E A I O P R T O P Q V T P A I K
 T A P R U A O R P Q A M P T U M N V Z Z A P C V N A I M N Z A P T X M 951A III III
 FL2 V FQ3 NR20 P GR15 FIRST BT
 NR16 DFCT1 TPQE A P E T H Y T B Y H A P I R P M P B V Z X N J G K L H F
 A P R I O Q M Z H A K T L A P T 955A II II
 FL2 V FQ3 NR21 O GR17 FIRST BT
 NR17 CD A S D F V L K J H B Q P W O E L K J H Y T R E W S U I O P H W E R T G O U U Y G
 M N B V F Z X C V G I F N B G R F V G H U H B V F B H U I O 1004A II II
 108 FL2 V FQ3 NR22 P GR18 FIRST BT
 NR18 CD Q W E R F O K M N H I J N B G U H B V F Y G V C D T F C X S R D X Z A Q A Z X D
 W S X C F E D C V G R F V B H U Q H B V Y W G V C I J N M K O K M L P 1006A II II
 FL2 V FQ3 NR23 G GR24 FIRST BT
 NR19 CD R E W S D T Y U H G U I O K J L K J N U K J H B Y H G F R C Q P O W Y H J K U Y
 R E D F V J I O N M C D E R T B G T Y U N J I O P M J U Y T V F R E W Q W E D C Y U J M N I J M K U
 H Y F R D H U B T Q Z C B M L 1008A II II
 FL2 V FQ3 NR24 Y GR18 FIRST BT
 NR2 CD U I Y T R K J H G F H J K L O I J N D L L I G T D W D Y B H I Y T B V N O P Q R
 P Q Y T R N J I O K H N U I R P T N K Y M A O R T N A H V J N I P Q T 1009A II II
 FL2 V FQ3 NR25 Y GR21 FIRST BT
 NR3 DFCT1 Q P W C E I R U T Y G H A L S K D J F H E I C N M E I X N O Q M
 Z M X N A O N V A S H J E I O T M O T Y Q P M C N R Y T Q P T O M I K L H J G F
 1012A II II

FL2 V FQ3 NR26 P GR14 FIRST BT
 FOUR REPLACEMENTS DUE YOUR COMMAND POST THIS AFTERNOON RADIO
 TIME OF THEIR ARRIVAL 1016A II II

FL2 V FQ3 NR27 GR18 FIRST BT
 NR4 CD ETUPQ PAITM AOUTL NUBYR HBOUT MAUYT JALKE MJHBV
 JAMCH CVZNA HQPQY MAITY QYRWP HJKLA HFGTE 1017A II II
 FL2 V FQ3 NR28 O GR25 FIRST BT
 NR6 CD WROUY APR TJ MAIYR HIKDA KPQMN XAORP TURAE MAPRY
 HALFKAMELS EKLAO ALEPE HEPTE AOETY QPTYR AMOTY APRVB CZLAM
 RQPUT YAHGS AMOEP NVBCZ 1018A II II
 FL2 V FQ3 NR29 GR17 FIRST BT
 NR8 CD RTPQY AORPE RIQNC MAOTR HGJKL LKAIE AKETIT EKATY
 MAPTY HGNVNB NVKDL LKHSD ZXMMAT TORPD 1019A II II
 FL2 V FQ3 NR30 GR23 FIRST BT
 109 NR32 DFCT1 RTEY UITP MITY AORP RYAL HDLF NJEO MEPE
 NAIT GHJD KELE LEIT AOTP ALEP MAUT YTLS LEIT KJDH
 EPQW QWXZ 1021A II II
 FL2 V FQ3 NR31 GR16 FIRST BT
 NR41 CD QPWQE NAITY MEOPEN NITYH MAITY NEJKL CNALD THOJF
 WPOTM UNKJF CXZBN MAORY HSMDA 1023A II II
 FL2 V FQ3 NR32 GR18 FIRST BT
 NR5 CD REQYT AOTPE OPELT NJIUY BHYTR GVBBHJ MKJNH BHGVF
 VGBHY NURTY NAITY ZASXD CFDER VFGRT UQNZM 1025A II II
 FL2 V FQ3 NR33 GR13 FIRST BT
 RATIONS RUNNING LOW CUT OFF FROM DEPOT BY LINE OF
 INFANTRY CAVALRY 1028A II II

Tape No. 13—Continued

FL2 V FQ3 NR34 GR24 FIRST BT
 NR10 CD QPWOT YIROE JHDLF NAKDL NKTUI NUTYA CUITH SNUTB
 MAOPR HJKLAMAKELMACBZ NAITH MRTNH JNLAI NREQI AXSDF JAPRB
 JRHTY CHUIT FANTE 1030A III
 FL2 V FQ3 NR35 GR19 FIRST BT
 NR01 CD MARIT NAKFL RTAIF AKJHG HSLLDK AKLEP MEITY HADSG
 NAKRP AMEOI NAITU ROPEL MARUQ FNAJB HALRE TEGHU 1032A III

Tape No. 14—100 characters per minute

(Tactical traffic, 20 words per minute)

LX1 V LX8 NR1 GR19 SEVENTH BT
 NR2 CD KOXNT BHTRM NMGHT PEXXN HCVZM CBNET FOTZQ XEETO
 NNEIU IHOIB BUOBE EBBME IZCMX PXEXQ MEBIT NOTEQ 901A III
 110 LX1 V LX8 NR2 GR15 SEVENTH BT
 NR3 CD DFCIJ IORYTT OEXMT ERRSH FINMT DESCN BENJO LOTYH
 ZKIEP QPOGC YCEXN ZEXIN 902A III
 LX1 V LX8 NR3 P GR21 SEVENTH BT
 NR4 CD NEISL INUTY XVFHG MNBYT KJIXX EXCBB MITHY EEDSA
 ADIMA EXITN OPOOE EEDSA IMHTM ADOHO VIRCB EECEN NOTPH NENOM
 903A III
 LX1 V LX8 NR4 GR22 SEVENTH BT
 NR4 CD NKEME AEOEI AVENN QEWRT WERTY RTYU UIOPA
 ASDFG SDFGH DFGHK AQWEX NOTES ENEQT FOXEN ZEXIN PMENT HQHPD III
 MNBYT 904A

LX1 V LX8 NR5 GR19 SEVENTH BT
 NR5 DFCT1 NRJHERISIENMTHNI CSED JHEN KYO YUHJ
 BXZX SSIE SXXE QOPQEIKZ ZXIT UIOK BENT 905A II II
 LX1 V LX8 NR6 GR14 SEVENTH BT
 REQUEST PLANES SENT ON HARRASSING DETAIL TO ENEMYS SOUTHERN LINES
 GROUND STRAFING POSSIBLE 906A II II
 LX1 V LX8 NR7 GR24 SEVENTH BT
 NR56 CD FOPPN NUQES SIEMF FTMNV HFDCQ EPDKN KDBCL REWGX
 FNSTH TFPDE PQNCK CGLXN NQRTY NESTP QWERT RUNJN NESTZ FEXNT
 JELNT HQSPD NIXNT 906A II II
 LX1 V LX8 NR8 GR25 SEVENTH BT
 NR71 CD BNGFG KEUBV KEING KXEUA IERGH BOVWI ILKJN AVCRN
 IEBGN XKEIT XEIEE CDXJN XKEOT AASNT EIMNT XNSIP EKFOT CNJMT
 YZTGM BAYKE OJPAN RUIXT 907A II II
 LX1 V LX8 NR9 GR17 SEVENTH BT
 NR8 DFCT1 URGSIHV EXCL YZTG BYAK OJPA OKKD RIUX
 JANW NYIM NHIM USDT USDTHTF 908A II II
 LX1 V LX8 NR10 GR19 SEVENTH BT
 NR9 DFCT1 ETBL AXMZ DYKV KUOG KOYA INIY YUKA OMGF
 INIY YUKA OMGF OFRZ OVDG JUAC AWRT UHMG 906A
 LX1 V LX8 NR11 GR20 SEVENTH BT
 NR10 CD XORMO HDBAT SAARN XOVEN GOUKT SMANI IBTEN UILOR
 ISOGN ICKYN FYDOT EMDZC IEIRN OLITP ETBNC HQHPD NIXTU 909A II II
 LX1 V LX8 NR12 GOY GR20 SEVENTH BT
 NR69 CD NEOXT IMCEN IUDJH UODAN EIONT KSSOAN CNDJW EOTNE
 NITFO MNTON LWQNT WIEIT NOCIO PAKSK ALSLD DJGHK NOTUN 1010P II II

TM 11-432

SIGNAL CORPS

Tape No. 14—Continued

LX1 V LX8 NR13 GR22 SEVENTH BT
NR11 CD DFCTJ KUNHN HYVVO ZEZEQ WETNP FEXON FERTY INOPT
NYGDN NENTP FERTY EOTNK KPTON NERTY QUION WERNR HRNTN FERMN
I PINT 111OP III

LX1 V LX8 NR14 GR23 SEVENTH BT
NR110 CD FINIT LOTNK ERTYN ESSAY NESTO FOFTK XEZEN NUTTY
NIXTN FOXET TSTNT EASTN TESTN FERTN QUINN WEPTN FIXFJ JIJSSJ
LOJNT ASNSK 555P III

LX1 V LX8 NR15 GR5 SEVENTH BT
KX8 NR41 SEVENTH 444P 449P III III

LX1 V LX8 NR16 GR25 SEVENTH BT
NR19 CD TITEN FEQTY POINM MOENE FERTP ZEXEN CMNGD HRNOW
EANTH FIFTP BEONT SHIEH FEINT ERORQ POTNT OITNQ ERTYJ JNRJN
112 VEMEN ZXCVM QWERJ FIIS 948P III

LX1 V LX8 NR17 GR26 SEVENTH BT
NR21 CDONATP QUIRT WERNJ FERTM ASSAN SASSN DIDQJ FOOFN
OISIO JKMN BISNT ERTY FEMTN Nixon FEMNT IOTNM XIXIN EMMNA
HQHPN HRNEW NTMET QSTMN ZZANM 941A III

LX1 V LX8 NR18 GR16 SEVENTH BT
NR121 DFCT1 WANT FINT POTN MANT EANT QRTY FIXN NOTM
SISN EA1J JIKL LNTPMNT 749A III III

LX1 V LX8 NR19 GR17 SEVENTH BT
NR222 CD FINJY OOPEN FIMEN HQDHN ENETM FONTA WENTJ HRNEW
EOJOP FEMNT LPWNT ALSKN AJKNE NEMNT 933A III III

LX1 V LX8 NR20 GR22 SEVENTH BT
 NR99 CD QUINT WERTPEASNT RUMPO TESNT YUMAN UNIET IOPNT
 TNIMN POINT OMANT EFENT KEEIP IMNIOMENTL ZEJQN FENTPEASTM
 QUIOP 333P III
 LX1 V LX8 NR21 GR15 SEVENTH BT
 NR889 DFCT1 ENTYFINT POKY FEMN QUIT WEAN MEIT OLN
 EMNT PETY FERZ NIME 832P II II
 LX1 V LX8 NR22 GR11 SEVENTH BT
 TROOPS CONCENTRATION EAST OF RIVER PROVING EFFECTIVE FURTHER
 DETAILS LATER 931A II II
 LX1 V LX8 NR23 GR18 SEVENTH BT
 NR44 DFCT1 QJJY WKNN EAET PENT SENK FINT LOSN MEQN
 QPWQ EORI RUTY ALSK KDFJ GHZM NIPT 335A III III
 LX1 V LX8 NR24 GR19 SEVENTH BT
 NR41 CD PEMNT HMAST EMNTY FISNT LOANT EMENT HIHEE EIEN
 LOTZE EANAT EMETP FINTH HIEEM MENTJ EMDJK LINTP 456P III III
 LX1 V LX8 NR25 GR20 SEVENTH BT
 NR100 CD NOWITEMENT WIEMT POZON ZEMNT HUTEN MINIE GHLID
 EMETO HIENT ESHEF FINTPLITIE HEREQ JKHGN NITOP ZEXLN 649A III III
 LX1 V LX8 NR26 P GR21 SEVENTH BT
 NR13 CD FINTO LOTNT HIENT QPOTN MENTA KINTO HHNET LIENT
 MESSE EASY MINTO LINTP HENZQ LITME HEQNT EFFITP HIEMT LPOINT
 949A III III
 LX1 V LX8 NR27 GR16 SEVENTH BT
 NR922 CD HIMET LOPEN QITNT PEMTP HRIOP ZEMIT HIEMT LOANT
 GUEJN JITNP EATOP SIXEN GEMET 848A III III

432514°—42—8
113

Tape No. 14—Continued

LX1 V LX8 NR28 GR25 SEVENTH BT
 NR29 CD ENJUS IHHIT PEMTP EMNTQ LIQNT FEMTZ HIENT LION
 MESSE ESSIS JUMNT HIQNT LOTAN JUMTN QUENT FIENT LOAJJ WJWMT
 AWJAJ EI SHT MONTA EEMTY 934A II II

LX1 V LX8 NR29 GR21 SEVENTH BT
 NR31 DFCT1 EAMNE ITN LOAN MENT FUNT LIAK EANT LUNT
 HIST EANT FOEX LOAT MENT NOTA LOAT JFEN LQON LILA 847A II II

LX1 V LX8 NR30 O GR12 SEVENTH BT
 THREE REPLACEMENTS THIS UNIT ARRIVED YESTERDAY AM ONE SERGANT
 TWO CORPORALS 1039A II II

LX1 V LX8 NR31 GR22 SEVENTH BT
 NR44 DFCT1 EMEM LOAT FINT EAST ENNW HETN LOAT MENT
 EOAQ HIKN NITO POET METO MAST EATT HQNT MOTN FIXT
 114 MEST 125A II II

LX1 V LX8 NR32 P GR17 SEVENTH BT
 NR141 CD NETOL FINTO FITON LEASN SENTA MINTO HQHET FINTO
 MYNTA KINLO QITON MESTO HANTO MENTA 847A II II

LX1 V LX8 NR33 GR17 SEVENTH BT
 NR12 CD HENTANINAS FERTY AUINT MENTA LIANT HETOP FERN
 ZENTO LAXTO MENTA MENTA EFNTA MANTA 846A II II

LX1 V LX8 NR34 GR19 SEVENTH BT
 NR118 CD FENTO LASTOMENTA FERNT HASON MANTOKIKEN FENTA
 MENTA FERMET LISTO PERTO HIEST MENTA FEROZ LIS TO 443A II II

LX1 V LX8 NR35 GR19 SEVENTH BT
 NR119 CD QUINT FERTOLITON MENTA FERTO XERON ZELAT EMATO
 PIOHN VNTTN MNXNT XZNT WIPO MENTO HISTO KEENT 441A II II

LX1 V LX8 NR36 GR23 SEVENTH BT
 NR118 CD QITON FENTN LISTS TO MENTA NOTAL HISTO KENTA POTOI
 MENTA MENTA FISON HERON NOTAP MENTA WIZIZ Z XVNO Z CNTO VNBBN
 EPOJH GHJDN 223A III III

LX1 V LX8 NR37 GR27 SEVENTH BT
 NR1 CD QUITO WESTO EASTN MENTA RUNTA YIYEN YIENT UOONN
 EXONT MENTA MENTA LOSTN MENTAL ZCXNM ZSNTY LONTA MENTA PIOTA
 MENTA METAL ZSILA VETZX WOTET EANTA 221P III III

LX1 V LX8 NR38 GR16 SEVENTH BT
 NR333 DFCT1 EATM MENT MOTN QITO EANT FINT MOTN MENT
 HOTN QOIT MENT HOTA I EAN 449P III III

LX1 V LX8 NR39 GR17 SEVENTH BT
 NR190 CD MENTA FERTO LITIO QITAN SEASON SASAN DGDHG HJKLA
 LADPN NEAT ZXCNM CNTOP MENTA EATOP 444P III III

115 LX1 V LX8 NR40 GO Y GR22 SEVENTH BT
 NR2 CD ASNTA LOSTN MENTA MENTW EASTM FETTO OKOMN NOTAL
 SESIS FERNT LOATN NOTAP HISTO JKGN Q JAST NOATO NATIO ALANT
 ENDAN 758A III III

Tape No. 15—100 characters per minute

(Tactical traffic, 20 words per minute)

FR1 V FR3 NR1 G GR17 SECOND BT
 NR11 CD SEXTA IRTOB JUGBC VOVYD CSJYE QUGYF CERXW WAICR
 YZBIA HETEI ZIGUT GHTED MVOPLE FVJQ 112P III III

FR1 V FR3 NR2 T CDS V BC2 G Y O GR20 SECOND BT
 NR6 CD SIIVA JELLO DUGTN AMQIB UBIIXZ NATSE FOKIA GRALB
 EOPAN TOANC DOMTA IUPAM KWONG TYRWP LQBCD INGWQ OELNS 910A III III

Tape No. 15—Continued

FR1 V FR3 NR3 GR20 SECOND BT
NR7 CD OFGAL YTRAN WOBBOX QUSON XAUNT ELENI JLAEO LOGNY
WPOTN THWON TONWQ THOWA VXARU XOAMI PWRAM LANGQ MAPMZ 921A III III
FR1 V FR3 NR4 G O GR23 SECOND BT
NR9 CD MUYYRQ THOWQ MAYWQ AQISP WOTRN MEIGM JYTFW QPBZX
PWOAM WOAND ALENS DONWI EHTMA DWOSM THAPZ TNWTV ONLUD KAWLC
OXBUV MAORW 924A II II

FR1 V FR3 NR5 P GR19 SECOND BT
NR10 DFCTI WOBO OLKO SYAP WOFK WUWE SYAPEZRS HAQY
WAHU MERI ZULP TAXA AHFY DEPD CYBE FENY 930A II II

FR1 V FR3 NR6 GR13 SECOND BT
ENEMY TANKS HAVE BEEN ROUTED WERE LAST SEEN IN VICINITY
OF ARNEY TOWN 823A II II

116 FR1 V FR3 NR7 GR25 SECOND BT
NR6 CD CYKMX JELAS EUYCA ERRAO CYFFT WAHYU AMQIF UMAHH
IGOHG CYMKX AHPHN YJMJK LANDK ONLYR ALPEM HOISW ALPZS KWACF
EMAQP NYTND MAOTR MAOFW 935A II II

FR1 V FR3 NR8 GR15 SECOND BT
NR8 CD KLYTR MAONF APMWY CIWHI HNBJK CYSTJ TUXGC WVAK
EMZAL NUQWS KINDS QSUDK 921A II II

FR1 V FR3 NR9 P GR16 SECOND BT
NR19 CD HNBJK JMCIK LJOER VWZIL RTVER MKPPFQ DQHKA BZCUO
GSLDM DOXGL FHMLT RSPHD UTHKJ 925A II II

FR1 V FR3 NR10 T CD3 V BC2 G Y O GR18 SECOND BT
NR22 CD JALNM LANKE ALSM ALDNI ALDMS ALRWQ PNEWK MAOLQ
WPAMW OWACV PWTYE AMONE AMPEW UDPEW UDXSZ IUPOQ 829A II II

FR1 V FR3 NR11 GR15 SECOND BT
 NR37 CD YEPOT MAOND MAOWX AGNVB WEKJI GHDJAEUIKJ QESZK
 MCHAUTUJVMOWEPMTPEWY 930A II II
 FR1 V FR3 NR12 GR16 SECOND BT
 MAIN BODY OF SUPPLIES LOCATED AT PUMPKIN PATCH JUNCTION SEND BACK
 GUARD TO MAINTAIN ORDERLY DISTRIBUTION 931A III III
 FR1 V FR3 NR13 Y P GR14 SECOND BT
 NR23 CD XMZJK JIMEF CUMLC YMOAE FIMVC MXDOF JKJWZ CMUTM
 QMONE IRTYU PWRIU 1010A III III
 FR1 V FR3 NR14 GR16 SECOND BT
 NR9 CD MJCHFNCDJDHGDYEIDGERILADWMANOWEQPUOEMAOTD
 MAOTE CXWQZ QPWMX WTEIV 947A III III
 FR1 V FR3 NR15 P GR18 SECOND BT
 NR34 DFCT1 NJUM YIUK WQED ASDE WERFERTG RYTH YUIK
 NYCSZ BHTO OPKB MFKW KLIH CZXX JAWQ 948A III III
 FR1 V FR3 NR16 P GR17 SECOND BT
 NR2 CD XMJZK JINEF CMUCN YJOAE FIMVK XMCOFMQCEACTUMN
 AONES MAOWW VKMIF JISEQ XMFOC KQLWU 958A III III
 FR1 V FR3 NR17 NITE GR19 SECOND BT
 NR7 CD MAOEN TRPME OEMPS MEONA XQYRO PRWMN MWHTZ OMESW
 ENSDX MWORN OTUTM TPWMO WQRSK MWOND OEZXY PWQVT 936A III III
 FR1 V FR3 NR18 GR22 SECOND BT
 NR38 CD MOWXZ NEOWN ETHWN OEWAM WYRND AJAWH ALIRN OWNAW
 OWNAL OENIE QWEOP IUYTQ OISDG LKDHH HJKAS WBNCD AFDSGLJKDH
 MNOVX 939A III III
 FR1 V FR3 NR19 Y GR19 SECOND BT
 NR39 CD LKJMN HGFCV IOPUY FDSER MJKHB FDREW JHBVC WFJUY
 OUIYF HCBSR WUORU EJHDW QOEMC WKDNC QLSIE WJDNV 1017A III III

Tape No. 15—Continued

FR1 V FR3 NR20 GR20 SECOND BT
 NR40 CD WKSJD FUWCN WQDSG KDXZM ASZXM QPWJX RKSNC WKLDH
 QODJV WHDCM QHASC WODNX DLKAM WHDOV ZSWGH WI OFF J KONES 1018A II II

 FR1 V FR3 NR21 GR16 SECOND BT
 NR41 CD ALSKF WURVS WOFBZ QODNC DUWZX OENSVOENAL YSLCM
 ONSAMALEND MIEQD QPROX IEWQZ 1020A II II

 FR1 V FR3 NR22 P GR17 SECOND BT
 NR43 CD WHDSV ALEHD OIEUT WPCKZ JFNMS OQEIV ZXMEY OPETD
 UHFRWE TUOG MVBDU RGBJI OKNGF WSXCF 1039A II II

 FR1 V FR3 NR23 G GR18 SECOND BT
 NR44 CD PLKJY IHYTR HGFRE HJNBV DTJVZ IEKAN QPSOC WIUHD
 QKSJC BHDOJ JIUYE JNXZC MKGEY LMNGH DFTES 1039A II II

 1 FR1 V FR3 NR24 G Y O GR24 SECOND BT
 NR42 DFCT1 QOWI ALKD DNMIC WIOR WJKC AHKJ WOZZ LKU
 LKYUGFTREWSDJKSISONSEREOP HGMKA LDJ EIOZ WDJK
 NFGDNKSJ OZZV 1031A II II

 FR1 V FR3 NR25 GR17 SECOND BT
 NR43 CD MCCIK JINER OIOXD ONETY APEMC NOEAL QJLSF LOEAN
 JAOEN SCXPE ALWON ZENCA PANEQ ZICQV 1032A II II

 FR1 V FR3 NR26 GR20 SECOND BT
 NR44 CD NKJVS QACEM OANSW ZWQYT OENSLETRIN ONEAN EATON
 SHDRL UAITMAPNEM WTEUY UTYYE WORIY AJDHG SLDKG ZNCME 1033A II II

 FR1 V FR3 NR27 GR15 SECOND BT
 NR45 CD WQIUC ALDNG AIEND AIEWQ QOEHC SLRZX WICNG WORN
 QPALZ SHFKE EIFND WNXXZV 1034A II II

FR1 V FR3 NR28 NITE GR16 SECOND BT
 NR47 CD NBHGF GHTYR JKHHUY QFDSE CNVBG DKGJH WORJV KLHJF
 JKUJY HGTRD DHGJL HBVFD HUYFE 1035A II II
 FR1 V FR3 NR29 P GR17 SECOND BT
 NR49 CD MJKHG JHGFD IUYDR NGJHT FGKNB CXZSD SISEZ JDVCM
 JSGCB WI OFG JFDHT DKCNG UYGRD HTFRS 1037A II II
 FR1 V FR3 NR30 GR19 SECOND BT
 NR51 CD JHNNGF HYRTD HJUOI SLFER ZXCCDE GFTER IIGREE GHKJL
 JHGFC VBHRT WQAGO JHGDF QOFHT YFVBR EYRTD OHVDF 1038A II II
 FR1 V FR3 NR31 G GR18 SECOND BT
 NR52 CD UYRFG IUHGF IHVZX REWQA GZXXE HGCVB FTESD OTFJH
 OYHVF GJHFV WTYDF GHUTY FHVGX IYFOY GBDDZX 1039A II II
 FR1 V FR3 NR32 GR24 SECOND BT
 NR54 CD WJNBF HYRTD FGRTS CXZSW BVGDF JGYHR FGJHD
 FSXCV GFHJI HGTYR PDGHR WQADF HKJLG JGBNH JDHTY FWEZX FBGDF
 119 KLJGH BFHGT CDEWS 1024A II II
 FR1 V FR3 NR33 P GR22 SECOND BT
 NR55 CD JHGTY GHRTE FGRTD HJKLN BNHGE JKUIG JKHF TERYTF
 HBNGF DFHGG BCVNM QWRET YRFGH BHGFR FHGJU HDFFGR GKJBB ZCXVE
 WASQR 1025A II II
 FR1 V FR3 NR34 GR17 SECOND BT
 NR57 CD FGTRF HGTYR GHDXZ ZXCVB JHGTY FGRTD WASQW
 LJKHG GHKCV BVGFD GHTEB HFFT JKNNY 1027A II II
 FR1 V FR3 NR35 GR14 SECOND BT
 ENEMY ADVANCING ON OUR LEFT FLANK MACHINE NOT EFFECTIVE SUFFERING
 HEAVY LOSSES ADVISE 1028A II II
 FR1 V FR3 NR36 GR18 SECOND BT
 NR59 CD JHFGT HGFDS DVDR MHHJY HGTYF RDCXZ XWRED GHGTR
 KLCEW XCVDI GTDKN IEUSH GHYDV JBHFT GJBKW 1029A II II

Tape No. 15—Continued

FR1 V FR3 NR37 GR17 SECOND BT
NR60 CD HUSUI BFHRT GDVCE ZX CWE FHGFD FTEHM FHKBV XCBZV
BDTEJ GKHNF EUVDT AZXWW NZCWO IGBEF 1030A II II
FR1 V FR3 NR38 GR18 SECOND BT
NR61 CD AF DSE DFRSW DCXVR NVGHR CHERTF GDFES LKIJM DXWOH
XSIHN GJFFFR DGTVG SUTMR FCEJY CUFVE ZWQLB 1032A II II
FR1 V FR3 NR39 GR19 SECOND BT
NR63 CD FDREW CGFDR BFXCUIUSTV VFTRD HDHTY JHBFG GHYTF
MBNGH FTUIO BVFGGE GF RDW HKYUB BHJTY GJHRT 1GKWP 1033A II II
FR1 V FR3 NR40 P GR22 SECOND BT
NR64 CD JNHFG HFGRF FGTRD JUYIG KNMGR GFHYG BDGER FGHRT
JKYUI FXWRG NBVFG GFDEW ANSWER DFRTG GHYTF GHYUM JHBNF XCDEW
ZERCX 1032A II II

TM 11-432

CODE PRACTICE EQUIPMENT

[A. G. 062.11 (11-19-41).]

BY ORDER OF THE SECRETARY OF WAR:

G. C. MARSHALL,
Chief of Staff.

OFFICIAL:

E. S. ADAMS,
Major General,
The Adjutant General.

DISTRIBUTION:

Bn and H 1, 2, 4, 6, 7, 11 and 17 (2); IC 11 (2).

(For explanation of symbols, see FM 21-6.)

